Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced VDH14TLV

RemotesReplaced Remote Control Instruction Manual

Model: Howell VDH14TLV Compatible Replacement

1. Introduction

This RemotesReplaced remote control is designed as a direct replacement for your original Howell VDH14TLV remote. It offers identical electronic functionality and all the same features as the original, providing a reliable and cost-effective solution. This manual provides essential information for setting up, operating, and maintaining your new remote control.



Image 1.1: Front view of the RemotesReplaced remote control, showing all buttons and layout.

2. Setup

2.1 Battery Installation

Your RemotesReplaced remote control requires two AAA batteries (not included). No setup codes or programming are required; simply insert the batteries, and the remote will be ready for use with your Howell VDH14TLV device.

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image 2.1: Back view of the remote control, highlighting the battery compartment.

3. Operating Instructions

This replacement remote control provides full functionality for your Howell VDH14TLV device. The buttons are laid out similarly to your original remote for intuitive use.

3.1 Basic Functions

- **Power Button:** Press to turn your device on or off.
- **Number Buttons (0-9):** Use to directly select channels or input numerical values.
- **Volume Up/Down (VOL +/-):** Adjusts the audio volume.
- **Channel Up/Down (CH +/-):** Changes the television channel.
- **Mute Button:** Silences the audio output.

3.2 Navigation and Menu Functions

- **Menu Button:** Accesses the main menu of your device.
- **Arrow Buttons (Up, Down, Left, Right):**Navigate through menus and options.
- **OK/Enter Button:** Confirms selections within menus.
- **Exit Button:** Exits the current menu or function.

3.3 Source and Input Selection

- **Source/Input Button:** Cycles through available input sources (e.g., TV, HDMI 1, HDMI 2, AV).

4. Maintenance

4.1 Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote's surface or internal components.

4.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.3 Storage

Store the remote control in a dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace the batteries with fresh AAA batteries.
  - Ensure there are no obstructions between the remote control and your device's infrared receiver.
  - Point the remote directly at the device.
- **Some functions not working:**
  - Verify that your device is powered on and functioning correctly.
  - This remote is a direct replacement; all functions should work as per the original Howell VDH14TLV remote. If specific functions are not working, ensure you are pressing the correct button for the desired action.

6. Specifications

Feature	Specification
Model Number	VDH14TLV (Compatible Replacement)
Brand	RemotesReplaced
Power Source	2 x AAA Batteries

Weight	Approximately 120 Grams
Manufacturer	Linkwebb

7. Warranty and Support

7.1 Warranty Information

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as intended for the Howell VDH14TLV device. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For any questions, troubleshooting assistance, or warranty inquiries, please contact your retailer or the RemotesReplaced customer support. Refer to your purchase documentation for contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097PVJCLC

More documents and user manuals: **https://manuals.plus/**