RemotesReplaced IH 19820 T 15 N

RemotesReplaced Compatible Remote Control for INNO HIT IH 19820 T 15 N User Manual

Model: IH 19820 T 15 N

1. Introduction

This manual provides instructions for the RemotesReplaced compatible remote control, designed as an electronic replacement for the INNO HIT IH 19820 T 15 N original remote. This replacement offers identical functionality to the original unit.

2. Setup

The RemotesReplaced remote control requires no complex setup codes. Simply insert the batteries, and it is ready for use.

2.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.



Figure 1: Rear view of the remote control, highlighting the battery compartment cover.

3. Operating Instructions

This remote control provides access to all functions of your INNO HIT IH 19820 T 15 N device. Point the remote directly at the device's infrared receiver for optimal performance.



Figure 2: Front view of the remote control, displaying all operational buttons.

3.1 Key Functions Overview

- **POWER (●)**: Turns the device on or off.

- **MUTE**: Silences or restores the audio.
- **TV/SAT/DVD/AUX**: Selects the input source.
- **Number Buttons (0-9)**: Directly selects channels or enters numerical data.
- **MENU**: Accesses the main menu of the device.
- **EXIT**: Exits the current menu or function.
- **SHIFT**: Used for accessing secondary functions of certain buttons.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **VOL +/-**: Adjusts the volume level.
- **CH +/- (P +/-)**: Changes channels.
- **SOURCE**: Cycles through available input sources.
- **GUIDE/EPG**: Displays the electronic program guide.
- **INFO**: Displays information about the current program or input.
- **BACK**: Returns to the previous screen or menu.
- **SLEEP**: Sets a sleep timer for the device.
- **NET TV / SMART**: Accesses smart TV features or internet applications.
- **Color Buttons (Red, Green, Yellow, Blue)**: Used for specific functions within menus or applications, as indicated on screen.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's response becomes inconsistent or stops working. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners, as these can damage the remote's surface or internal components.

5. Troubleshooting

- **Remote not responding:**
  - Ensure the batteries are correctly inserted with the correct polarity.
  - Replace old batteries with new ones.
  - Check for any obstructions between the remote control and the device's infrared receiver.
  - Ensure you are pointing the remote directly at the device.
- **Some buttons not working:**
  - This remote is designed to be fully compatible. If specific buttons are not functioning, ensure the device is in the correct input mode (e.g., TV mode for TV functions).
  - If the issue persists, try replacing the batteries.

6. Specifications

Feature	Specification
Brand	RemotesReplaced
Model Number	IH 19820 T 15 N
Compatible With	INNO HIT IH 19820 T 15 N
Battery Type	2 x AAA batteries (not included)
Item Weight	120 Grams

7. Warranty and Support

This RemotesReplaced product comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended for the specified INNO HIT model.
For support or warranty claims, please refer to the contact information provided by your retailer or the RemotesReplaced brand directly. Ensure you have your proof of purchase and the model number (IH 19820 T 15 N) available.

© 2024 RemotesReplaced. All rights reserved.