Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced HSG-1087

RemotesReplaced Compatible Remote Control for Hannspree HSG-1087 User Manual

Model: HSG-1087

1. Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your RemotesReplaced compatible remote control for the Hannspree HSG-1087. This remote is designed to function identically to the original Hannspree HSG-1087 remote, providing all the same features without requiring any complex setup.

2. Setup

2.1 Battery Installation

The remote control requires two (2) AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the latch and slide the battery cover downwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Figure 2.1: Back view of the remote control, showing the battery compartment. Ensure correct battery polarity when inserting.

2.2 Initial Use

This RemotesReplaced remote control is pre-programmed for the Hannspree HSG-1087 and does not require any setup codes or pairing. Once batteries are installed, it is ready for immediate use with your device.

3. Operating Instructions

The remote control provides full functionality for your Hannspree HSG-1087 device. Below is an overview of the main buttons and their functions.



Figure 3.1: Front view of the remote control, highlighting the button layout.



Figure 3.2: Top view of the remote control, showing the infrared (IR) emitter. Ensure this end is pointed towards your device.

3.1 Key Functions

- **POWER (●)**: Turns the device on or off.
- **MUTE**: Mutes or unmutes the audio.
- **TV/SAT/DVD/AUX**: Selects input sources.
- **MENU**: Accesses the main menu.
- **EXIT**: Exits the current menu or function.
- **Number Buttons (0-9)**: Direct channel selection.
- **VOL +/-**: Adjusts the volume level.
- **CH +/-**: Changes channels.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates through menus and confirms selections.
- **BACK**: Returns to the previous screen or menu.
- **INFO**: Displays program information.
- **EPG**: Accesses the Electronic Program Guide.
- **Colored Buttons (Red, Green, Yellow, Blue)**: Functionality varies depending on the current screen or application.
- **NET TV** / **SMART**: Accesses smart TV features or streaming services.

For specific functions related to your Hannspree HSG-1087 device, refer to your device's original user manual.

4. Maintenance

4.1 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2 Cleaning

To clean the remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using abrasive cleaners, alcohol, or solvents, as these can damage the remote's surface or internal components.

4.3 Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Remote is not working.	Dead or incorrectly inserted batteries.	Check battery polarity. Replace batteries with new AAA batteries.
Remote is unresponsive.	Obstruction between remote and device; remote too far from device; IR emitter blocked.	Ensure a clear line of sight to the device's IR receiver. Point the top of the remote directly at the device. Move closer to the device.
Certain buttons do not function.	Device-specific function not supported; button malfunction.	Verify the function is supported by your Hannspree HSG-1087. If other buttons work, the specific button might be faulty. Try replacing batteries.

6. Specifications

Brand: RemotesReplaced

Model Number: HSG-1087

Compatibility: Hannspree HSG-1087

Power Source: 2 x AAA Batteries (not included)

Weight: 120 Grams

Manufacturer: Linkwebb

7. Warranty Information

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote control functions as intended for the specified model. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, accidental damage, unauthorized repairs, or normal wear and tear.

8. Support

For further assistance or if you encounter issues not covered in this manual, please contact the retailer or the RemotesReplaced customer support. When contacting support, please have your product model number (HSG-1087) and proof of purchase ready.
RemotesReplaced specializes in replacement remote controls and maintains an extensive database to ensure compatibility and functionality.

© 2023 RemotesReplaced. All rights reserved. Hannspree is a registered trademark of its respective owner.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097Q2FB7W

More documents and user manuals: **https://manuals.plus/**