RemotesReplaced 19AV734F

RemotesReplaced Replacement Remote Control User Manual

For Toshiba 19AV734F Compatible Televisions

1. Introduction

This manual provides instructions for the RemotesReplaced replacement remote control, designed to be fully compatible with your Toshiba 19AV734F television. This remote offers all the functionalities of the original remote without requiring any complex setup. Simply insert batteries and begin use.

2. Safety Information

- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Ensure batteries are inserted with correct polarity (+ and -).
- Remove batteries if the remote control will not be used for an extended period.
- Keep batteries out of reach of children.

3. Package Contents

- 1 x RemotesReplaced Replacement Remote Control (Model: 19AV734F compatible)

4. Product Overview

Familiarize yourself with the layout and functions of your new remote control.



Figure 1: Front view of the RemotesReplaced replacement remote control. This image displays the full layout of the remote, including the power button, number pad, navigation controls, and various function buttons.



Figure 2: Close-up view of the buttons on the remote control. This image provides a detailed look at the labels and arrangement of the various control buttons, such as volume, channel, menu, and input selection.



Figure 3: Back view of the remote control, highlighting the battery compartment cover. This shows where the batteries are to be inserted.



Figure 4: Top view of the remote control, illustrating the infrared (IR) emitter. This is the component that sends signals to your television.

5. Setup: Battery Installation

Your RemotesReplaced remote control requires two AAA batteries (not included).

1. Locate the battery compartment on the back of the remote control (refer to Figure 3).
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

The remote control is now ready for use. No programming or pairing is required.

6. Operating Instructions

This replacement remote control functions identically to your original Toshiba 19AV734F remote. Point the

remote directly at your television's infrared receiver.

- **Power Button:** Press to turn the television on or off.
- **Number Buttons (0-9):** Use to directly select channels.
- **Volume Up/Down (V+/V-):** Adjusts the sound level.
- **Channel Up/Down (P+/P-):** Changes the television channel.
- **Mute Button:** Silences the television audio.
- **Input/Source Button:** Cycles through available input sources (e.g., HDMI, AV).
- **Menu Button:** Accesses the television's main menu.
- **Navigation Buttons (Up, Down, Left, Right, OK):** Used to navigate through menus and confirm selections.
- **Exit Button:** Closes the current menu or on-screen display.

All other buttons correspond to their original functions on your Toshiba 19AV734F television.

7. Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.

8. Troubleshooting

- **Remote not working:**
  - Check if the batteries are inserted correctly with the proper polarity.
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote control and the television's infrared receiver.
  - Make sure you are pointing the remote directly at the television.
- **Intermittent response:**
  - This often indicates low battery power. Replace the batteries.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the IR signal.

9. Specifications

- **Brand:** RemotesReplaced
- **Model Compatibility:** Toshiba 19AV734F
- **Power Source:** 2 x AAA Batteries (not included)
- **Weight:** Approximately 120 Grams (without batteries)
- **Connectivity:** Infrared (IR)

10. Warranty and Support

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. For warranty claims or technical support, please contact RemotesReplaced customer service through your retailer or the official RemotesReplaced website.
Please retain your proof of purchase for warranty purposes.

© 2024 RemotesReplaced. All rights reserved.