GoVideo DV2130

GoVideo DV2130 DVD/VCR Combination User Manual

Model: DV2130

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your GoVideo DV2130 DVD/VCR Combination unit. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your viewing and recording experience.

Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury to persons. Keep the unit away from water and moisture. Do not block ventilation openings. Refer all servicing to qualified service personnel.

Package Contents

- GoVideo DV2130 DVD/VCR Combination Unit
- Remote Control (with 2 AA batteries)
- Audio/Video RCA Cables
- Power Cord

Setup

Connecting the Unit

Follow these steps to connect your GoVideo DV2130 to your television and other audio/video equipment:

1. **Power Connection:** Connect the power cord to the unit's power input and then to a standard electrical outlet.
2. **Video/Audio Output:** Use the supplied RCA cables (yellow for video, red for right audio, white for left audio) to connect the unit's "Video Out" and "Audio Out" jacks to the corresponding "Video In" and "Audio In" jacks on your television or receiver.
3. **Antenna/Cable Connection (for VCR tuner):** If you plan to record TV programs, connect your antenna or cable TV

line to the "RF In" jack on the back of the unit. Then, connect an RF cable from the unit's "RF Out" jack to your TV's "Antenna In" jack.

4. **Remote Control Batteries:** Insert the two AA batteries into the remote control, ensuring correct polarity.

Refer to the image below for a visual guide to the front panel controls and input/output ports.



Image Description: This image displays the front panel of the GoVideo DV2130 DVD/VCR Combination unit. The unit is silver-gray with two media trays: a DVD tray on the left and a VHS tape slot on the right.
On the left side of the DVD tray, the "GO VIDEO" logo is visible, along with "PROGRESSIVE SCAN" and "DVD VIDEO" indicators. Below the DVD tray are control buttons: "POWER", "PLAY", "REW", "STOP", "FF", and "REC".
Between the DVD and VCR sections, there's a "COPY" button and a "DVD-VCR" selector button.
On the right side, above the VHS slot, "VHS" and "4 HEAD Hi-Fi" are printed, along with the model number "DV2130" and an "EJECT" button. Below the VHS slot, there are "CH" (channel) and "SETUP" buttons, followed by "LINE IN 2" RCA input jacks (yellow for VIDEO, white for L-AUDIO-R, red for R-AUDIO-R). Further to the right, "MP3" and "Kodak" logos are present.
A remote control and a set of yellow, white, and red RCA cables are also visible on top of the unit, packaged in plastic.

Operating Instructions

Basic Playback

- **Playing a DVD:** Press the "DVD-VCR" button to select DVD mode. Press the Eject button next to the DVD tray to open it, place a DVD disc inside, and close the tray. The disc should begin playing automatically. If not, press the "PLAY" button.
- **Playing a VHS Tape:** Press the "DVD-VCR" button to select VCR mode. Insert a VHS tape into the VCR slot. The tape should begin playing automatically. If not, press the "PLAY" button.

One-Touch Copy (DVD to VHS)

The DV2130 features a convenient one-touch copy function to transfer content from DVD to VHS.**Note:** Copying copyrighted material may be illegal. Ensure you have the right to copy the content.

1. Insert the DVD you wish to copy into the DVD tray.
2. Insert a blank VHS tape into the VCR slot.
3. Press the "COPY" button on the front panel. The unit will automatically begin recording the DVD content onto the VHS tape.

Simultaneous Operation

You can watch a DVD while simultaneously recording a television program on VHS. Ensure your antenna/cable is connected to the VCR's "RF In" port.

1. Start playing your DVD.
2. Switch the unit to VCR mode using the "DVD-VCR" button.
3. Tune the VCR to the desired TV channel using the "CH" buttons.
4. Press the "REC" button to begin recording the TV program. The DVD playback will continue independently.

Viewing JPEG Files

The unit supports viewing JPEG image files from CD-R and CD-RW discs.

1. Insert a CD-R or CD-RW disc containing JPEG images into the DVD tray.
2. The unit should automatically detect the disc and display an image browser. Use the remote control to navigate and view your images.

Advanced Features

- **Progressive Scan:** For enhanced video quality on compatible digital televisions, ensure your TV is set to accept a progressive scan signal.
- **Virtual Surround (3D Surround):** Activate this feature through the setup menu for an immersive audio experience.
- **181-Channel Tuner with 7-Event/1-Month Timer:** Program the VCR to record up to 7 events over a one-month period using the remote control and on-screen display. Refer to the on-screen menu for detailed timer programming instructions.

Maintenance

Proper care ensures the longevity and optimal performance of your GoVideo DV2130.

- **Cleaning the Unit:** Wipe the exterior of the unit with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Disc and Tape Care:** Keep DVDs and VHS tapes clean and free of dust and fingerprints. Store them in their cases when not in use. Avoid exposing them to extreme temperatures or direct sunlight.
- **Ventilation:** Ensure the unit has adequate ventilation. Do not block the ventilation slots on the top or sides of the unit.

Troubleshooting

If you encounter problems with your DV2130, refer to the following common issues and solutions:

- **No Power:**
  - Ensure the power cord is securely plugged into both the unit and a working electrical outlet.

- Check if the power outlet is functional by plugging in another device.

- **No Picture/Sound:**
  - Verify that the RCA audio/video cables are correctly connected to both the DV2130 and your television/receiver.
  - Ensure your TV input is set to the correct source (e.g., Video 1, AV, Component).
  - Check the "DVD-VCR" selector button to ensure the correct mode is selected for the media you are trying to play.
  - For VCR playback, ensure the TV is tuned to the correct channel (usually channel 3 or 4) if connected via RF cable.
- **Disc/Tape Not Playing:**
  - Ensure the disc or tape is inserted correctly and is not damaged or dirty.
  - For DVDs, check if the disc is region-compatible with the player.
- **Remote Control Not Working:**
  - Check and replace the AA batteries if necessary, ensuring correct polarity.
  - Ensure there are no obstructions between the remote control and the unit's remote sensor.
  - Point the remote directly at the unit.

If problems persist, contact customer support or a qualified service technician.

Specifications

Feature	Description
Brand	GoVideo
Model	DV2130
Media Type	DVD, VHS, CD-R/CD-RW (for JPEG)
Special Features	Progressive Scan, Virtual Surround (3D Surround), One-Touch Copy (DVD to VHS), Simultaneous Watch DVD/Record TV, JPEG Playback
Tuner	181-Channel Tuner with 7-Event/1-Month Timer
Video Encoding	MPEG-2
Input Video Compatibility	NTSC
Audio Output Mode	Surround
Connector Type	RCA (Audio/Video)
Connectivity Technology	Powerline
Item Weight	12 pounds
Package Dimensions	16.9 x 10.6 x 3.7 inches
Batteries (Remote)	2 AA batteries (included)
UPC	656942152637

Warranty and Support

This product is offered as an Amazon Renewed item. Amazon Renewed products are professionally inspected and tested to work and look like new. If not satisfied with the purchase, renewed products are eligible for replacement or refund under the Amazon Renewed Guarantee. For specific warranty details and support, please refer to the Amazon Renewed program terms or contact your seller.

© 2023 GoVideo. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question