Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC LT60 N7115

JVC 60-inch 4K Ultra HD Smart LED TV User Manual

Model: LT60 N7115

Product Overview

The JVC 60-inch 4K Ultra HD Smart LED TV (Model LT60 N7115) is designed to deliver a superior viewing experience with its vibrant 4K Ultra HD display. This smart television offers purer and more realistic colors, enhancing your entertainment. It features multiple connectivity options, including USB, HDMI, and wired LAN, allowing for versatile media playback and internet access. The integrated optical input supports various audio formats, ensuring clear and natural sound from all viewing angles.



Image: Front view of the JVC 60-inch 4K Ultra HD Smart LED TV, showcasing its slim bezel and stand, with a vibrant image of a boat on blue water displayed on the screen.

Setup Guide

1. Unboxing and Placement

Carefully remove the TV from its packaging. It is recommended to have two people for safe handling. Place the TV on a stable, flat surface or mount it securely to a wall using a compatible VESA mount (sold separately). Ensure adequate ventilation around the TV.

2. Connecting Power

Connect the power cord to the TV's power input and then plug it into a standard electrical outlet. The TV will enter standby mode.

3. Connecting External Devices

- **HDMI Devices:** Connect up to three HDMI devices (e.g., Blu-ray player, game console, cable box) to the HDMI ports on the back of the TV.
- **USB Devices:** Insert USB drives into the two available USB ports for media playback.
- **Wired Network (LAN):** For a stable internet connection, connect an Ethernet cable from your router to the LAN port on the TV.
- **Optical Audio:** Use the optical audio output to connect to a soundbar or home theater system for enhanced audio.

4. Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your preferred language.
- Connect to a Wi-Fi network or confirm wired network connection.
- Scan for available TV channels (if connecting an antenna).
- Agree to terms and conditions for smart features.

Operating Instructions

Basic Functions

- **Power On/Off:** Press the **Power** button on the remote control or the TV.
- **Volume Control:** Use the **Volume Up/Down** buttons to adjust the sound level.
- **Channel Selection:** Use the **Channel Up/Down** buttons or the numeric keypad to change channels.
- **Input Source:** Press the **Source** or **Input** button to switch between connected devices (HDMI 1, HDMI 2, USB, etc.).

Smart TV Features

Your JVC Smart LED TV provides access to a variety of online streaming services and applications. Supported services include Netflix, YouTube, and Amazon Prime Video.

- **Accessing Apps:** Use the remote control's navigation buttons to select and launch applications from the home screen or app menu.
- **Network Connection:** Ensure your TV is connected to the internet via Wi-Fi or Ethernet to access smart features.
- **Software Updates:** Periodically check for and install software updates to ensure optimal performance and access to new features. This can usually be found in the TV's settings menu.

Maintenance

Cleaning the Screen

To clean the screen, gently wipe it with a soft, lint-free cloth. For stubborn marks, slightly dampen the cloth with water or a specialized screen cleaner. Avoid using harsh chemicals, abrasive cloths, or spraying liquid directly onto the screen.

General Care

- Keep the TV away from direct sunlight and heat sources.
- Ensure proper ventilation by not blocking the TV's vents.
- Unplug the TV during lightning storms or when it will be unused for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
No Power	Power cord disconnected; power outlet issue.	Check power cord connection; try a different outlet.
No Picture / Black Screen	Incorrect input source; device not powered on.	Press the **Source** button to select correct input; ensure connected device is on.
No Sound	Volume muted or too low; incorrect audio output settings.	Unmute volume or increase level; check audio settings in TV menu.
Cannot Connect to Wi-Fi	Incorrect password; router issue; TV too far from router.	Verify Wi-Fi password; restart router; move TV closer to router.

Specifications

Feature	Detail
Brand	JVC
Model Name	Smart LED TV
Item Model Number	LT60 N7115
Screen Size	60 inches (153 cm)
Display Technology	LED
Resolution	4K Ultra HD
Refresh Rate	120 Hz
Connectivity Technology	Wi-Fi
Supported Internet Services	Netflix, YouTube, Amazon Prime Video
Included Components	1 x JVC 60-inch 4K UHD Smart LED TV
Special Feature	Wide Viewing Angle

Product Dimensions	145.7 x 17 x 87.2 cm; 20.8 kg
Manufacturer	JVC
First Available Date	June 23, 2021

Warranty and Support

For warranty information and technical support, please refer to the documentation included with your product or visit the official JVC website. Keep your purchase receipt as proof of purchase for warranty claims.
For further assistance, you may contact JVC customer service through their official channels. Details can typically be found on the manufacturer's website or in the product packaging.

© 2024 JVC. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B097SYXDCG

More documents and user manuals: **https://manuals.plus/**