RemotesReplaced IH16820T

RemotesReplaced Compatible Remote Control for Inno Hit IH16820T

Model: IH16820T

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your RemotesReplaced compatible remote control, designed specifically for the Inno Hit IH16820T device. This remote is an electronically identical replacement, ensuring all original functions are available without complex setup.

Setup Instructions

1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Back view of the remote control, highlighting the battery compartment. Ensure correct battery polarity during installation.

2. Initial Use

No setup codes or programming are required. Once batteries are installed, the remote is ready for immediate use with your Inno Hit IH16820T device.

Operating Instructions

This remote control provides full functionality for your Inno Hit IH16820T. Below is a guide to its primary buttons and their functions.



Image: Front view of the remote control, displaying all buttons and their labels.

- **POWER:** Turns the device on or off.
- **MUTE:** Mutes or unmutes the audio.
- **TV** / **SAT** / **DVD** / **AUX:**Selects the input source.
- **MENU:** Accesses the main menu.
- **EXIT:** Exits the current menu or screen.
- **SHIFT:** Used for accessing secondary functions of certain buttons (if applicable).
- **Number Buttons (0-9):** Direct channel selection or numerical input.
- **SOURCE:** Cycles through available input sources.
- **-/--:** Toggles between single and double-digit channel input.
- **GUIDE:** Displays the electronic program guide.
- **Volume Up/Down (V+/V-):** Adjusts the volume level.
- **Channel Up/Down (P+/P-):** Changes the channel.
- **Directional Arrows (Up, Down, Left, Right):** Navigates through menus and options.
- **OK:** Confirms selections in menus.
- **BACK:** Returns to the previous screen or menu.
- **SLEEP:** Sets a sleep timer for the device.
- **TV/DTV:** Switches between analog and digital TV modes.
- **INFO:** Displays information about the current program or input.
- **EPG:** Accesses the Electronic Program Guide.
- **FAV:** Accesses favorite channels list.
- **NET TV** / **SMART:** Accesses smart TV features or internet applications.
- **Color Buttons (Red, Green, Yellow, Blue):** Functions vary depending on the context or application.
- **Playback Controls (Rewind, Play/Pause, Fast Forward):** Controls media playback.

Maintenance

Cleaning the Remote

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid using abrasive cleaners, solvents, or spraying liquids directly onto the remote.

Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries or different types of batteries.

Storage

Store the remote control in a dry place, away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, it is recommended to remove the batteries to prevent leakage.

Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed with the correct polarity.
  - Replace the batteries with new ones.
  - Ensure there are no obstructions between the remote control and the device's infrared receiver.
  - Make sure you are within the effective range of the device.
- **Specific buttons not working:**
  - Clean the remote control, especially around the unresponsive buttons, to remove any dirt or debris.
  - If only specific functions are not working, ensure the correct input source (TV, SAT, DVD, AUX) is selected on the remote.

Specifications

Brand:	RemotesReplaced
Model Number:	IH16820T
Compatible With:	Inno Hit IH16820T
Power Source:	2 x AAA Batteries
Weight:	120 Grams
Manufacturer:	Linkwebb
ASIN:	B097TMJWKF

Warranty Information

This RemotesReplaced compatible remote control comes with a**1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote performs as described. Please retain your proof of purchase for warranty claims.

Support

For further assistance or if you encounter issues not covered in this manual, please refer to the seller's support channels or the RemotesReplaced official website. When contacting support, please have your product model number (IH16820T) and purchase details ready.

© 2026 RemotesReplaced. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question