Burg-Wächter 40010

BURG-WÄCHTER Key Safe 60L SB User Manual

Model: 40010

Introduction Safety Contents Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

This manual provides essential instructions for the installation, operation, and maintenance of your BURG-WÄCHTER Key Safe 60L SB. This key safe is designed for secure storage of keys up to 10.5 cm in length, featuring a 4-digit combination lock and integrated illumination for easy access in low light conditions. Please read this manual thoroughly before use to ensure proper function and safety.

2. Important Safety Information

Always follow the installation instructions provided with the product. Keep the product away from heat sources and do not expose it to extreme temperatures. Do not attempt to disassemble or repair the product yourself. In case of any damage or malfunction, contact a professional for assistance.

3. Package Contents

Verify that all items are present in the package:

- 1x BURG-WÄCHTER Key Safe 60L SB
- Mounting material (screws and anchors)
- 1x Lithium battery (CR2032, 3V)

4. Setup and Installation

4.1. Battery Installation

The key safe requires a CR2032 lithium battery for the integrated illumination feature. Locate the battery compartment, typically on the inside of the safe door or near the combination dials. Insert the provided CR2032 battery, ensuring correct polarity (+/-). The light sensor will activate the illumination in low-light conditions.





Image: Interior view of the key safe, showing the battery compartment and key hooks.

4.2. Wall Mounting

The Key Safe 60L SB is designed for wall mounting indoors or in a sheltered outdoor area. Use the provided mounting material (screws and anchors) for secure installation. Ensure the mounting surface is suitable to support the weight of the safe and its contents.

1. Choose a suitable location for mounting.
2. Hold the safe against the wall and mark the drilling points through the pre-drilled holes on the back panel.
3. Drill holes at the marked positions.
4. Insert the wall anchors (if required for your wall type).
5. Secure the key safe to the wall using the provided screws.





Image: The key safe separated from its mounting plate, illustrating the installation components.

5. Operating Instructions

5.1. Setting the Combination Code

The key safe uses a 4-digit combination code. You can set your individual code from 10,000 possibilities. The factory default code is usually 0-0-0-0. Refer to the specific instructions inside the safe or on a separate leaflet for the exact procedure to change the code. Typically, this involves moving a reset lever or button inside the safe while it is open, setting the new code, and then returning the lever/button to its original position.





Image: Front view of the key safe, displaying the 4-digit combination dials and the light button.

5.2. Opening the Key Safe

1. Enter your 4-digit combination code by rotating the dials. The auto-stop feature helps align the numbers correctly.
2. Once the correct code is entered, pull down the cover or press the release button (location may vary slightly by model) to open the safe door.
3. To close, ensure the door is fully shut and scramble the combination dials to secure the safe.

5.3. Using the Integrated Illumination

The key safe features an integrated light that activates automatically in low-light conditions, making it easier to enter the code and access keys at night. This feature is powered by the CR2032 battery.

6. Maintenance

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** If the integrated light becomes dim or stops working, replace the CR2032 battery. Follow the battery installation steps (Section 4.1).
- **Code Security:** Regularly change your combination code, especially if multiple people have access to it. Keep your code confidential.

7. Troubleshooting

Problem	Possible Cause	Solution
Safe will not open with the correct code.	Incorrect code entered, dials not aligned, or code was changed and forgotten.	Ensure dials are precisely aligned. If the code was changed, try previous codes. If forgotten, contact customer support (note: without the code, opening may require destructive methods).
Integrated light is not working.	Battery is dead or incorrectly installed.	Replace the CR2032 battery, ensuring correct polarity. Check if the environment is dark enough for the light sensor to activate.
Dials are stiff or difficult to turn.	Dirt or debris accumulation.	Clean the dials with a soft, dry cloth. Avoid lubricants that might attract more dirt.

8. Specifications

Model: BURG-WÄCHTER Key Safe 60L SB (Model 40010)

Material: Die-cast zinc

Color: Black

Dimensions (H x W x D): 136 x 85 x 50 mm (5.35" x 3.35" x 1.97")

Weight: Approximately 634 grams (1.4 pounds)

Lock Type: 4-digit combination lock

Special Features: Integrated illumination, magnetic key holder

Battery: 1x CR2032 Lithium 3V (included)

Mounting: Wall mount

9. Customer Support

For further assistance, technical support, or warranty inquiries, please contact BURG-WÄCHTER customer service. Refer to the official BURG-WÄCHTER website for contact details specific to your region.
Website: www.burg.biz

© 2024 BURG-WÄCHTER. All rights reserved.