Member's Mark 31466MAR21-A

Member's Mark Gourmet Kitchen Appliances for Kids Instruction Manual

Introduction

This instruction manual provides important information for the safe and proper use of your Member's Mark Gourmet Kitchen Appliances for Kids. This set includes a toy coffee maker, mixer, and blender, designed to encourage imaginative play and creativity in a fun, interactive way.



Image: The Member's Mark Gourmet Kitchen Appliances set, featuring a toy blender, coffee maker, and stand mixer, all in a vibrant pink color, displayed out of their packaging.

Safety Information

Please read all instructions before use. Adult supervision is recommended at all times when children are playing with this product. This product is intended for children aged 3 years and up. Keep small parts away from younger children to prevent choking hazards. Do not immerse electronic components in water. Use only the specified batteries and ensure correct polarity during installation. Dispose of batteries responsibly.

Package Contents

The Member's Mark Gourmet Kitchen Appliances set includes the following items:

- 1 x Toy Coffee Maker
- 1 x Toy Mixer
- 1 x Toy Blender
- Assorted play accessories (e.g., coffee pods, mixing bowl, cup)
- Batteries for each appliance (2 AAA for Coffee Maker, 2 AAA for Mixer, 2 AA for Blender)



Image: The complete Member's Mark Gourmet Kitchen Appliances set, including the toy coffee maker, mixer, and blender, presented in its original retail packaging.

Setup

1. **Unpacking:** Carefully remove all items from the packaging. Ensure all components listed in the 'Package Contents' section are present.
2. **Battery Installation:** The appliances require batteries for operation. Batteries are included with the product.
    - **Toy Coffee Maker:** Locate the battery compartment on the underside. Open the cover, insert 2 AAA batteries, ensuring correct polarity (+/-). Close the cover securely.
    - **Toy Mixer:** Locate the battery compartment on the underside. Open the cover, insert 2 AAA batteries, ensuring correct polarity (+/-). Close the cover securely.
    - **Toy Blender:** Locate the battery compartment on the underside. Open the cover, insert 2 AA batteries, ensuring correct polarity (+/-). Close the cover securely.

Operating Instructions

These appliances are designed for imaginative play and simulate real kitchen actions without heat or sharp blades.



Image: A young child engaged in imaginative play with the Member's Mark toy kitchen appliances, demonstrating their interactive nature.

Toy Coffee Maker

1. Fill the water reservoir with a small amount of clean, room-temperature water.
2. Insert a play coffee capsule into the designated slot on top of the coffee maker.
3. Place the included toy cup under the dispenser spout.
4. Press the 'Start' button to activate the unit. The coffee maker will simulate brewing, dispensing water into the cup.
5. To stop the brewing simulation, press the 'Start' button again or wait for the cycle to complete.

Toy Mixer

1. Place the mixing bowl onto the mixer base.
2. Attach the mixing attachments (beaters) to the mixer head.
3. Press the power button to activate the mixer. The attachments will rotate, simulating mixing.
4. The mixer head can be lifted or detached from the base for handheld play, offering versatile play options.

5. Press the power button again to turn off the mixer.

Toy Blender

1. Fill the blender pitcher with a small amount of clean, room-temperature water.
2. Securely attach the pitcher to the blender base.
3. Press and hold the button on the base. The blender will simulate blending with lights and spinning action.
4. Release the button to stop the blending action. This safety feature ensures the blender operates only when the button is pressed.

Maintenance

- Clean all surfaces of the appliances with a soft, damp cloth.
- Do not use abrasive cleaners or harsh chemicals, as these may damage the product's finish.
- Never immerse the electronic parts of the coffee maker, mixer, or blender bases in water.
- After each use, empty any water from the coffee maker reservoir and blender pitcher.
- Store the appliances in a clean, dry place away from direct sunlight when not in use.
- Remove batteries if the product will not be used for an extended period to prevent leakage.

Troubleshooting

- **Appliance not turning on:**
  - Check that batteries are inserted with correct polarity (+/-).
  - Ensure batteries are fresh and fully charged. Replace if necessary.
  - For the blender, confirm the button is pressed and held down during operation.
- **Water not dispensing from coffee maker:**
  - Verify that the water reservoir is filled with water.
  - Ensure a play coffee capsule is correctly inserted into its slot.
- **Mixer attachments not spinning:**
  - Confirm the mixer is powered on.
  - Check that the attachments are securely fitted into the mixer head.

Specifications

Brand	Member's Mark
Model Number	31466MAR21-A
ASIN	B098DJX9FQ
Product Dimensions	55.88 cm x 27.94 cm x 12.7 cm (L x W x H)
Product Weight	1.47 kg
Color	Pink

Material Type	Not specified
Educational Objectives	Imaginative Play
Assembly Required	No
Manufacturer Recommended Age	3 years and up
Battery Requirements	Coffee Maker: 2 x AAA (included) Mixer: 2 x AAA (included) Blender: 2 x AA (included)



Image: Detailed dimensional diagram for the toy coffee maker, blender, and stand mixer, indicating their height, width, and depth in centimeters.

Warranty and Support

For product support, warranty inquiries, or to report any issues, please contact Member's Mark customer service. Please retain your proof of purchase for any warranty claims. Specific warranty details may vary by region and retailer.

© 2024 Member's Mark. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question