Minolta MN40WP

Minolta MN40WP Waterproof Digital Camera User Manual

Model: MN40WP

Introduction

This manual provides detailed instructions for the safe and effective use of your Minolta MN40WP Waterproof Digital Camera. Please read this manual thoroughly before operating the camera and retain it for future reference. The Minolta MN40WP is designed for capturing high-resolution photos and videos in various environments, including underwater up to 10 feet.

Package Contents

Verify that all items listed below are included in your package:

- Minolta MN40WP Camera
- USB Cable
- Lithium-Ion Battery
- AC Adaptor
- Carrying Pouch
- Wrist Strap
- 16GB Memory Card
- Instruction Manual (this document)
- Warranty Card

Camera Overview



Figure 1: Front View of Minolta MN40WP Camera. This image displays the front of the red Minolta MN40WP camera, showing the digital lens, flash, and the front LCD screen displaying three children splashing in water.



Figure 2: Rear View of Minolta MN40WP Camera. This image shows the back of the red Minolta MN40WP camera, highlighting the larger rear LCD screen and control buttons on the right side, including zoom, menu, and mode controls.

Key Features:

- **48 Megapixel Sensor:** Captures high-resolution still images.
- **2.7K Quad HD Video:** Records video at 30 frames per second.
- **Dual LCD Screens:** Features a 3.0-inch rear screen and a 2.0-inch front screen for selfies.
- **Waterproof Design:** Submersible up to 10 feet (3 meters).

- **16x Digital Zoom:** Allows for magnification of subjects.
- **Smart Photo Features:** Includes Anti-Shake, Face Detection, Smile Capture, and Panorama mode.

Setup

1. Charging the Battery

Before first use, fully charge the included Lithium-Ion battery. Connect the camera to the AC adaptor using the USB cable. The charging indicator light will illuminate during charging and turn off when complete.

2. Installing the Battery and Memory Card

1. Open the battery/memory card compartment cover on the side of the camera. Ensure the cover is dry before opening.
2. Insert the charged Lithium-Ion battery according to the polarity indicators inside the compartment.
3. Insert the 16GB Micro SD memory card into the designated slot until it clicks into place. Ensure the card is inserted correctly to avoid damage.
4. Close the compartment cover firmly until it locks. For waterproof integrity, ensure the seal is clean and free of debris, and the cover is securely latched.



Figure 3: Camera Ready for Use. This image shows the Minolta MN40WP camera with its front screen displaying a vibrant image of children playing in water, indicating it is powered on and ready for capturing moments.

Operating the Camera

1. Power On/Off

Press the Power button (usually located on the top of the camera) to turn the camera on or off. The LCD screen will activate.

2. Switching Between Screens

The camera features a 3.0-inch rear LCD and a 2.0-inch front LCD. Use the dedicated screen switch button (refer to your camera's physical layout for exact button) to toggle between the two displays. The front screen is ideal for

self-portraits and vlogging.

3. Taking Photos

1. Ensure the camera is in Photo mode. If not, press the Mode button to select Photo mode.
2. Frame your shot using either the front or rear LCD screen.
3. Press the Shutter button halfway to focus, then press fully to capture the image.
4. Use the W (Wide) and T (Telephoto) buttons for 16x digital zoom.



Figure 4: Digital Zoom Capability. This image illustrates the effect of digital zoom, showing a wide shot of multiple hot air balloons and a zoomed-in view of a single balloon, demonstrating the camera's 16x digital zoom feature.

4. Recording Videos

1. Press the Mode button to select Video mode.
2. Press the Shutter button to start recording. A timer or indicator will appear on the screen.
3. Press the Shutter button again to stop recording.



Figure 5: Video Resolution Comparison. This image demonstrates the difference in detail between various video resolutions, from 420p to 2.7K, highlighting the clarity offered by the camera's 2.7K Quad HD video recording capability.

5. Waterproof Operation

The Minolta MN40WP is waterproof up to 10 feet (3 meters). Before submerging the camera, ensure the battery/memory card compartment cover is securely closed and locked. Verify that the rubber seal is clean and free of any foreign particles. After underwater use, rinse the camera with fresh water and dry thoroughly before opening any compartments.



Figure 6: Waterproof Capability. This image shows the Minolta MN40WP camera partially submerged in water with splashes, illustrating its waterproof design suitable for aquatic environments.



Figure 7: Underwater Photography. This image depicts the Minolta MN40WP camera underwater, surrounded by fish and coral, demonstrating its use for capturing marine life.

6. Advanced Features

- **Anti-Shake:** Activates digital image stabilization to reduce blur from camera movement.
- **Face Detection & Smile Capture:** Automatically detects faces and can trigger the shutter when a smile is detected.
- **Panorama Mode:** Allows stitching multiple photos together to create a wide panoramic image.
- **Self-Timer:** Set a delay (e.g., 10 seconds) before the shutter fires.
- **Flash Modes:** Cycle through Auto, On, and Off flash settings.



Figure 8: Anti-Shake Functionality. This image compares two photos of two individuals, one blurred and the other sharp, illustrating the effectiveness of the camera's anti-shake feature in producing clear images.

7. Transferring Files

Connect the camera to a computer using the provided USB cable. The camera will appear as a removable disk, allowing you to copy photos and videos to your computer.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the camera body and screens. For the lens, use a specialized lens cleaning cloth and solution. Avoid abrasive materials.
- **Waterproof Seals:** Regularly inspect the rubber seals around the battery/memory card compartment for dirt, sand, or damage. Clean with a soft cloth and ensure they are free of debris before closing the compartment for waterproof use.
- **Battery Care:** Store the battery in a cool, dry place when not in use. Avoid fully discharging the battery for extended periods.
- **Storage:** When storing the camera for long periods, remove the battery and store the camera in a dry, dust-free environment.

Troubleshooting

Problem	Solution
Camera does not power on.	Ensure the battery is fully charged and correctly inserted. Try charging the battery for at least 2 hours.

Problem	Solution
Poor image quality (blurry/grainy).	Check lighting conditions. Ensure the lens is clean. Activate the Anti-Shake feature. For underwater photos, ensure the Underwater White Balance setting is enabled.
Memory card error.	Ensure the memory card is inserted correctly. Try reformatting the card (this will erase all data). If the issue persists, try a different compatible Micro SD card.
Water leakage after underwater use.	Immediately power off the camera and remove the battery. Ensure the battery/memory card compartment cover was securely closed and the rubber seal was clean and undamaged before submersion. Contact customer support if damage is suspected.
Camera freezes or is unresponsive.	Remove and reinsert the battery to reset the camera.

Specifications

Feature	Detail
Model Name	MN40WP
Photo Sensor Resolution	48 MP
Video Resolution	2.7K QHD (30 FPS)
Digital Zoom	16x
Front Screen Size	2.0 inches
Rear Screen Size	3.0 inches
Water Resistance Level	Waterproof up to 10 feet (3 meters)
Image Stabilization	Digital
Memory Type	Micro SD (16GB card included)
Battery Type	Lithium-Ion
Connectivity	USB
Special Features	Photo Burst, Face Detection, Panorama, Anti-Shake, Smile Capture
Item Weight	8 Ounces
UPC	084438961669

Warranty and Support

The Minolta MN40WP camera comes with a **1 Year Limited Manufacturer Warranty**. Please refer to the included Warranty Card for detailed terms and conditions.
For further assistance or technical support, please visit the official Minolta support website or contact their customer service. A digital version of this user manual may also be available online.

Additional Resources:

- Download User Manual (PDF)

© 2025 Minolta. All rights reserved.