iScooter E9 Pro

iScooter MAX Electric Scooter User Manual

Model: E9 Pro

1. Introduction and Welcome

Welcome to the iScooter MAX Electric Scooter user manual. This guide provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new electric scooter. Please read this manual thoroughly before your first ride to ensure optimal performance and safety.
The iScooter MAX is designed for adult commuters, offering a powerful 500W motor, long-range battery, and a comfortable riding experience with its dual suspension system and 10-inch solid tires. Enjoy your journey!

2. Safety Information

Your safety is paramount. Always adhere to local traffic laws and regulations. Wearing a helmet and appropriate safety gear is strongly recommended.

- **Always wear a helmet:** Protect your head from potential impacts.
- **Observe weight limits:** The scooter has a maximum load of 220 lbs. Exceeding this limit can affect performance and safety.
- **Age suitability:** Recommended for adults.
- **Avoid wet conditions:** While the scooter has some water resistance (IP54), avoid riding in heavy rain or through deep puddles to prevent damage and ensure traction.
- **Braking system:** Familiarize yourself with the dual braking system (EABS electronic brake and disc brake) for effective stopping.
- **Visibility:** Utilize the bright headlight and brake light, especially during low-light conditions or at night. The integrated ring bell enhances audible warnings.
- **UL Certified:** This product is UL Certified, ensuring it meets high safety standards.

3. Product Overview

The iScooter MAX Electric Scooter is engineered for performance and convenience. Key features include:

- **Powerful Motor:** Equipped with a 500W front-wheel-drive brushless motor for efficient acceleration and hill climbing (up to 15% grade).
- **Long Range Battery:** A 10.4 AH high-capacity lithium-ion battery provides a range of 17-22 miles on a single charge. The regenerative battery system helps extend range by recovering energy during braking.
- **Top Speed:** Achieve speeds of up to 18.6 MPH (or 21 MPH as per title, will use 18.6 MPH from feature bullets).
- **Durable Tires:** Features 10-inch honeycomb shock-absorbing solid tires, eliminating the worry of punctures and providing a smooth ride over various terrains.
- **Dual Suspension:** Rear dual shock absorbers enhance ride comfort, even on bumpy roads.
- **Smart APP Control:** Connect via Bluetooth to the free Minirobot APP (iPhone & Android) to control features like lock/unlock, lights, gears, start mode, maximum speed, and cruise control.
- **Foldable Design:** Lightweight at 35 lbs and easily foldable for convenient storage and portability.
- **Advanced Braking:** A double braking system combines EABS electronic brake and disc brake for reliable stopping power.
- **Visibility & Safety:** Integrated bright headlight, brake light, and a ring bell for enhanced safety.

Product Visuals



Figure 3.1: The iScooter MAX Electric Scooter, showcasing its sleek design, handlebar bag, and the accompanying mobile application

interface.



Figure 3.2: Infographic detailing the core performance specifications of the iScooter MAX, including speed, range, battery capacity, and charging time.



Figure 3.3: The scooter's smart dashboard and the Minirobot APP interface, demonstrating remote control and monitoring capabilities.



Figure 3.4: Visual representation of the 500W motor's power and the scooter's capability to ascend inclines.



Figure 3.5: Close-up of the dual suspension and smart braking system, emphasizing ride comfort and safety features.



Figure 3.6: Dimensions and weight specifications, illustrating the compact nature of the folded scooter for transport.



Figure 3.7: Front and rear lighting system for improved visibility and safety.




Figure 3.8: The iScooter MAX offers an enjoyable and efficient commuting experience.

4. Setup

4.1 Unboxing and Initial Assembly

Your iScooter MAX comes partially assembled. Follow these steps to prepare it for use:

1. Carefully remove the scooter and all packaging materials from the box.
2. Lift the handlebar stem to its upright position.
3. Secure the handlebar to the stem using the provided screws and tool. There are typically four screws that need to be installed.
4. Ensure all connections are secure and the folding mechanism is locked into place.

4.2 Initial Charging

Before your first ride, fully charge the scooter's battery.

- Locate the charging port on the side of the scooter's deck.

- Open the protective cover and connect the charger.
- Plug the charger into a standard wall outlet. The charging time is approximately 6 hours.
- Once fully charged, disconnect the charger and securely close the charging port cover to prevent water ingress.

4.3 App Connection (Minirobot APP)

Enhance your riding experience by connecting your scooter to the Minirobot APP.

- Download the free Minirobot APP from your smartphone's app store (available for iPhone & Android).
- Ensure your scooter is powered on and Bluetooth is enabled on your phone.
- Open the APP and follow the on-screen instructions to connect to your iScooter MAX via Bluetooth.
- Through the APP, you can control various settings such as locking/unlocking the scooter, turning lights on/off, adjusting gear modes, setting the start mode (zero start or non-zero start), setting maximum speed, and activating cruise control.

5. Operating Instructions

5.1 Powering On/Off

- To power on: Press and hold the power button on the handlebar display until the screen illuminates.
- To power off: Press and hold the power button again until the display turns off.

5.2 Riding the Scooter

1. Place one foot firmly on the deck and push off with the other foot to gain initial momentum.
2. Once moving, gently press the throttle lever with your thumb to accelerate.
3. To brake, release the throttle and gently squeeze the brake lever on the handlebar. The rear brake light will illuminate/flash.
4. For enhanced safety, use the integrated headlight in low-light conditions and the bell to alert pedestrians or other riders.

5.3 Folding and Unfolding

The iScooter MAX features a quick and easy folding mechanism for portability.

- To fold: Locate the folding latch near the base of the handlebar stem. Pull the latch up and release it, then carefully fold the handlebar stem downwards until it clicks into place with the rear fender.
- To unfold: Release the latch from the rear fender, lift the handlebar stem until it locks securely in the upright position. Ensure the folding mechanism is fully engaged before riding.

Your browser does not support the video tag.

Video 5.1: Official iScooter video demonstrating the features and portability of the MAX Electric Scooter, including folding and unfolding.

6. Maintenance

Regular maintenance ensures the longevity and safe operation of your iScooter MAX.

- **Tires:** The 10-inch solid honeycomb tires are maintenance-free and do not require inflation. Regularly inspect them for wear and tear.
- **Cleaning:** Wipe down the scooter with a damp cloth. Avoid using high-pressure water jets or harsh chemicals, especially near electronic components.
- **Battery Care:** For optimal battery life, avoid completely draining the battery and store the scooter in a cool, dry place when not in use. Charge it regularly, even if not used frequently. The regenerative braking system helps maintain battery charge during rides.
- **Brakes:** Periodically check the responsiveness of both the electronic and disc brakes. If you notice any degradation in braking performance, contact customer support.
- **General Inspection:** Regularly check all screws and bolts to ensure they are tight. Pay attention to the rear bracket holding the fender, as loose screws can cause issues.

7. Troubleshooting

If you encounter any issues with your iScooter MAX, please refer to the following common troubleshooting tips. For more complex problems, contact iScooter customer support.

- **Scooter not turning on:** Ensure the battery is charged. Check the power button for proper function.
- **Reduced speed/range:** This could indicate a low battery charge, riding in a lower gear mode (check APP settings), or riding against strong headwinds/uphill.
- **Error Codes:** The LED display may show error codes (e.g., E15 for brake handle assembly issues, as noted in customer reviews). Refer to the Minirobot APP or contact support for specific code interpretations and solutions.
- **Braking issues:** Check the brake levers and cables for any obstructions or damage. Ensure the disc brake is not rubbing.
- **Unusual noises:** Inspect wheels, suspension, and folding mechanisms for loose parts or debris.

8. Specifications

Feature	Specification
Brand	iScooter
Model Name	E9 Pro
Color	Black
Age Range (Description)	Adult

Weight Limit	220 Pounds
Product Dimensions (L x W x H)	46"L x 17"W x 50"H
Item Weight	35 Pounds
Motor Power	500W
Maximum Distance Range	22 Miles
Top Speed	Up to 21 MPH (18.6 MPH as per feature bullets)
Wheel Size	10 Inches
Wheel Type	Solid (Honeycomb shock-absorbing)
Suspension Type	Dual Suspension
Brake Style	Dual brake system (EABS electronic brake and disc brake)
Charging Time	6 Hours
Frame Material	Aluminum
Special Features	Regenerative battery, Non-slip Deck, Water-proof (IP54), APP control, Foldable

9. Warranty and Support

iScooter is committed to providing premium, affordable, and reliable products. Your iScooter MAX Electric Scooter comes with a warranty for different parts:

- **Warranty Period:** 12-month or 180-day for different parts.

If you have any questions, concerns, or require assistance with your scooter, please do not hesitate to contact iScooter customer support. They are available to help with troubleshooting, parts replacement, and guidance on maintenance. You can typically find contact information on the iScooter official website or through the Minirobot APP. As noted by other users, iScooter support is responsive and can provide parts and video instructions for repairs.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question