Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Starfrit 024615-001-0000

Starfrit 20.885-Quart 1,700-Watt Air Fryer Toaster Oven Instruction Manual

Model: 024615-001-0000

1. Introduction

Thank you for purchasing the Starfrit 20.885-Quart 1,700-Watt Air Fryer Toaster Oven. This appliance is designed to provide versatile cooking options, including air frying, baking, and toasting, with efficient and consistent results. Please read this manual thoroughly before first use to ensure safe and optimal operation.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Oversized foods or metal utensils must not be inserted in a toaster oven as they may create a fire or risk of electric shock.

- A fire may occur if the toaster oven is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any of the following materials in the oven: paper, cardboard, plastic, and the like.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.
- Do not cover crumb tray or any part of the oven with metal foil. This will cause overheating of the oven.
- Extreme caution must be exercised when using containers constructed of other than metal or glass.
- Do not clean with metal scouring pads. Pieces can break off the pad and touch electrical parts, creating a risk of electric shock.
- Do not attempt to dislodge food when the appliance is plugged in.
- Do not operate in an appliance garage or under a wall cabinet.

3. Product Overview

3.1 Components

The Starfrit Air Fryer Toaster Oven comes with several key components designed for versatile cooking.



Figure 3.1: Front view of the Starfrit Air Fryer Toaster Oven with a pizza cooking inside and a plate of french fries next to it.



Figure 3.2: Detailed dimensions of the Starfrit Air Fryer Toaster Oven, highlighting its 23L capacity and various measurements.



Figure 3.3: Illustration of the dual-fan technology for maximum heat airflow within the oven.



Figure 3.4: Interior view of the oven, labeling the air fryer basket, oven rack, baking pan/drip tray, and removable crumb tray.

3.2 Control Panel

The control panel features intuitive dials and buttons for easy operation.

- **Function Dial:** Selects cooking modes (e.g., Air Fry, Bake, Broil, Toast, Dehydrate, Keep Warm).
- **Temperature/Time Dial:** Adjusts temperature and cooking time.
- **LED Display Screen:** Shows current temperature, time, and selected cooking mode.
- **Start/Cancel Button:** Initiates or stops the cooking process.
- **Convection Button:** Activates or deactivates the convection fan for faster, more even cooking.
- **Light Button:** Turns the interior oven light on or off.



Figure 3.5: Close-up of the control panel, indicating the function dial, temperature/time dial, LED display, and various control buttons.

4. Setup

1. Unpack the appliance and all accessories. Remove any packaging materials, stickers, or labels.
2. Clean the air fryer basket, baking pan/drip tray, and oven rack with warm, soapy water. Rinse and dry thoroughly.
3. Wipe the interior and exterior of the oven with a damp cloth.
4. Place the oven on a stable, heat-resistant surface, ensuring adequate ventilation around all sides. Do not place it directly against a wall or under cabinets.
5. Insert the removable crumb tray at the bottom of the oven.
6. Plug the power cord into a grounded electrical outlet.
7. Before first use, it is recommended to run the oven empty for about 15 minutes at 400°F (200°C) to burn off any manufacturing residues. A slight odor or smoke may be present; this is normal. Ensure the area is well-ventilated.

5. Operating Instructions

5.1 Selecting a Cooking Mode

The oven offers 10 preset cooking modes for various dishes.

- Turn the **Function Dial** to select your desired cooking mode (e.g., Air Fry, Bake, Broil, Toast, Dehydrate, Keep Warm).
- The LED display will show the default temperature and time for the selected mode.



Figure 5.1: Examples of food items that can be perfectly cooked using the air fryer toaster oven, including chicken, beef, fish, pizza, fries, toast, and dehydrated foods.

5.2 Adjusting Temperature and Time

You can manually adjust the temperature and time for any cooking mode.

1. After selecting a cooking mode, turn the **Temperature/Time Dial** to adjust the temperature.
2. Press the **Temperature/Time Dial** once to switch to time adjustment, then turn the dial to set the desired cooking time.
3. Press the **Start/Cancel Button** to begin cooking.

5.3 Using the Convection Feature

The convection feature circulates hot air for faster and more even cooking, ideal for baking and air frying.

- Press the **Convection Button** to activate or deactivate the convection fan. The fan icon will appear on the LED

display when active.

- For most air frying recipes, the convection fan should be on. For traditional baking, you may choose to turn it off.

5.4 Cooking Examples

The oven's large capacity allows for various cooking tasks.



Figure 5.2: Illustrates the oven's capacity, capable of holding up to 6 slices of bread or a 12-inch pizza.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and longevity of your appliance.

1. Always unplug the oven and allow it to cool completely before cleaning.
2. Remove the air fryer basket, oven rack, baking pan/drip tray, and removable crumb tray. Wash these accessories in warm, soapy water. They are not dishwasher safe.
3. Wipe the interior walls of the oven with a damp cloth and mild detergent. For stubborn stains, use a non-abrasive cleaner.

4. Clean the exterior of the oven with a damp cloth. Do not use abrasive cleaners or metal scouring pads.
5. Ensure all parts are completely dry before reassembling and storing the oven.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; faulty outlet.	Ensure the power cord is securely plugged into a working outlet. Check your home's circuit breaker.
Food is not cooking evenly.	Overcrowding; incorrect temperature/time; convection fan off.	Do not overcrowd the basket/tray. Adjust temperature and time as needed. Ensure convection fan is on for air frying. Rotate food halfway through cooking.
Smoke coming from the oven.	Excess oil/grease; food residue; first use burn-off.	Clean the crumb tray and interior regularly. Use less oil. For first use, this is normal. If excessive, unplug and contact support.
Controls are unresponsive.	Temporary electronic glitch.	Unplug the unit from the power outlet, wait for 1 minute, then plug it back in.

8. Specifications

Brand: Starfrit

Model Name: Starfrit 20.885-Quart 1,700-Watt Air Fryer Toaster Oven

Model Number: 024615-001-0000

Capacity: 20.89 Quarts (approx. 23 Liters)

Output Wattage: 1700 Watts

Voltage: 230 Volts

Control Method: Touch

Material: Steel (Outer), Stainless Steel (Inner)

Product Dimensions: 16.54 x 13.8 x 15.15 inches

Item Weight: 23.9 pounds

Special Feature: Programmable

Air Frying Technology: Air Fryer

UPC: 069858246152

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Starfrit website. Keep your purchase receipt as proof of purchase for any warranty claims.
Manufacturer: STARFRIT USA INC

© 2025 Starfrit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B098TT9K27

More documents and user manuals: **https://manuals.plus/**