Sandisk SDMX28-016G-G46B

SanDisk Clip Sport Plus MP3 Player User Manual

Model: SDMX28-016G-G46B

1. Introduction

The SanDisk Clip Sport Plus MP3 Player is a lightweight, durable, and water-resistant device designed for active users. It features Bluetooth wireless technology for connecting to headphones, an LCD screen, and an FM radio. This manual provides detailed instructions for setting up, operating, and maintaining your device.



Figure 1: SanDisk Clip Sport Plus MP3 Player

2. What's in the Box

- SanDisk Clip Sport Plus wearable music player
- USB 2.0 transfer cable
- Wired earphones
- Quick start guide

3. Product Features

- **Water-resistant Design:** Tested to withstand water flow (12.5L/min) at 3 minutes (IEC 60529 IPX5). Ensure the device is clean and dry before use.
- **Bluetooth Wireless Technology:** Connects wirelessly to Bluetooth-enabled headphones or speakers for enhanced freedom during activities.

- **Lightweight and Durable:** Designed to clip securely to clothing or gear, making it ideal for workouts.
- **16GB Storage Capacity:** Stores approximately 4000 songs (based on 3.5 min songs @ 128kbps bitrate). Actual user storage capacity may be less.
- **Built-in FM Radio:** Listen to your favorite radio stations. Wired headphones are required for FM radio functionality as they act as the antenna.



Figure 2: Lightweight clip-on design for secure attachment.



Figure 3: Bluetooth wireless technology for wireless listening.



Figure 4: Water-resistant design for active lifestyles.

4. Setup

4.1 Charging the Battery

Before first use, fully charge the device. Connect the SanDisk Clip Sport Plus to a computer's USB port or a USB wall adapter (not included) using the provided USB 2.0 transfer cable. The battery indicator on the screen will show charging status. A full charge typically takes approximately 2 hours.

4.2 Transferring Music and Files

1. Connect the MP3 player to your computer using the USB cable.
2. The device will appear as a removable drive on your computer.
3. Drag and drop your music files (MP3, WMA, AAC, Ogg Vorbis, WAV, FLAC, Audible, Podcasts) into the 'Music' folder on the device.
4. Safely eject the device from your computer before disconnecting the USB cable.

4.3 Pairing Bluetooth Headphones

1. Ensure your Bluetooth headphones are in pairing mode. Refer to your headphone's manual for specific instructions.
2. On the SanDisk Clip Sport Plus, navigate to the **Bluetooth** menu.
3. Select **Search for Devices**.
4. Choose your headphones from the list of available devices.
5. Once paired, the device will typically reconnect automatically when both are powered on and within range.

5. Operating Instructions

5.1 Power On/Off

- To power on: Press and hold the power button (usually the center button) for a few seconds until the screen illuminates.
- To power off: Press and hold the power button until the device shuts down.

5.2 Navigating Menus

Use the directional buttons around the center button to navigate through menus. The center button typically acts as 'Select' or 'Enter', and the back arrow button returns to the previous screen.

5.3 Playing Music

1. From the main menu, select **Music**.
2. Browse by Artist, Album, Songs, Playlists, etc.
3. Select a song or playlist to begin playback.
4. Use the play/pause, skip forward, and skip backward buttons for control.

5.4 Using FM Radio

1. Connect wired earphones to the device. These act as the antenna.
2. From the main menu, select **FM Radio**.
3. Use the navigation buttons to scan for stations or tune manually.

6. Maintenance

6.1 Cleaning

Wipe the device with a soft, dry, lint-free cloth. Avoid using harsh chemicals or abrasive materials, which can damage the screen or casing.

6.2 Water Resistance Guidelines

The device is water-resistant (IPX5 rated), meaning it can withstand splashes and light rain. It is not designed for submersion. Always ensure the device is clean and dry before connecting the USB cable or using it in a dry environment to prevent damage.

7. Troubleshooting

Issue	Solution
Device does not power on.	Ensure the battery is charged. Connect to a power source and try again. If unresponsive, perform a soft reset by holding the power button for 15-20 seconds.

Issue	Solution
Cannot transfer files.	Verify the USB cable is securely connected to both the device and the computer. Try a different USB port or cable. Ensure the device is recognized by your computer.
Bluetooth headphones won't pair.	Ensure headphones are in pairing mode and fully charged. Move the devices closer together. Try unpairing and re-pairing.
No sound from FM Radio.	Ensure wired earphones are securely plugged in, as they function as the antenna. Check volume levels.
Short battery life.	Reduce screen brightness. Turn off Bluetooth when not in use. Ensure the device is fully charged before use. Battery performance may degrade over time.

8. Specifications

Feature	Detail
Brand	Sandisk
Model Name	Clip Sport Plus
Model Number	SDMX28-016G-G46B
Memory Storage Capacity	16 GB
Connectivity Technology	Bluetooth
Special Features	FM Radio, Water-resistant (IPX5)
Screen Size	1.44 Inches (LCD)
Supported Media Type	Micro SDXC (for internal storage, not expandable)
Supported Standards	MP3, WMA, AAC, Ogg Vorbis, WAV, FLAC, Audible, Podcasts
Item Weight	1.28 ounces
Item Dimensions (D x W x H)	0.73"D x 1.69"W x 2.6"H
Manufacturer	Western Digital Technologies, Inc.



Figure 5: Device dimensions for the SanDisk Clip Sport Plus MP3 Player.

9. Official Product Video

Your browser does not support the video tag.

Video 1: An official video demonstrating the features and use of the SanDisk Clip Sport Plus MP3 Player, including its clip-on design, Bluetooth connectivity, and water resistance during workouts.

10. Warranty and Support

10.1 Warranty Information

The SanDisk Clip Sport Plus MP3 Player comes with a**2-year warranty**. Please retain your proof of purchase for warranty claims.

10.2 Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official SanDisk support website or contact their customer service. Refer to the quick start guide for specific contact details or visit www.sandisk.com/support.

© 2024 SanDisk. All rights reserved. SanDisk is a trademark of Western Digital Corporation or its affiliates, registered in the U.S. and other countries. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Western Digital Technologies, Inc. is under license.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question