TP Toys TP656P

TP Toys Treehouse Wooden Play Tower Instruction Manual TP656P

Model: TP656P

1. Introduction

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your TP Toys Treehouse Wooden Play Tower, model TP656P. Please read this manual thoroughly before assembly and retain it for future reference. This play tower is designed to provide a stimulating and fun outdoor play experience for children.





Image 1.1: Overall view of the TP Toys Treehouse Wooden Play Tower, featuring a raised platform, ladder, and roof structure.

2. Safety Information

WARNING! Choking Hazard - Small Parts. Not for children under 3 years.

- Adult supervision is required at all times when children are using the play tower.
- Ensure the play tower is assembled correctly and securely before use.
- Regularly inspect all components for wear, damage, or loose fittings. Tighten all bolts and nuts periodically.
- Do not allow more than the recommended number of users or maximum weight on the play tower at one time.
- Clear the area around the play tower of any obstacles or hazards.
- Install the play tower on a level surface with adequate safety surfacing (e.g., wood chips, sand, rubber mulch) to absorb falls.
- Keep hands and feet clear of moving parts during play.
- Do not modify the product in any way, as this may compromise its safety.

3. Setup & Assembly

Assembly of the TP Toys Treehouse Wooden Play Tower requires adult supervision and typically two adults for efficient construction. All necessary hardware and detailed instructions are included in the packaging. Please ensure all parts are present before beginning assembly.

3.1 Pre-Assembly Checklist

- Verify all wooden components are free from damage or splinters.
- Confirm all hardware (screws, bolts, nuts, washers) is accounted for.
- Gather necessary tools: screwdriver, wrench, hammer, measuring tape.
- Select a level, clear area for installation, ensuring sufficient safety clearance around the structure.

3.2 Assembly Steps

1. Begin by assembling the base frame of the play tower.
2. Attach the vertical support posts to the base, ensuring they are plumb and secure.
3. Construct the main platform, which forms the floor of the treehouse.
4. Install the side panels and railings for the upper play area.
5. Assemble and attach the ladder securely to the platform.
6. Construct and attach the roof structure.
7. Install any additional features, such as the integral under-platform area for a sand or ball pit.
8. Perform a final check of all connections, ensuring all bolts and screws are tightened.



Image 3.1: Close-up view of the wooden ladder and the sturdy base frame, illustrating the construction details.



Image 3.2: Detailed view of the wooden platform, showing the plank construction and secure fastenings.

4. Operation

The TP Toys Treehouse Wooden Play Tower is designed for children aged 36 months to 8 years. It accommodates multiple users, with a maximum combined user weight of 110 lbs (50 kg).

4.1 General Usage Guidelines

- Children should use the ladder to access the upper platform.
- The integral under-platform area can be used as a shaded sandpit or ball pit.
- Encourage imaginative play within the structure.
- Ensure children understand and follow safety rules, such as not pushing or crowding.



Image 4.1: Two children engaging in play within the upper section of the wooden treehouse tower.



Image 4.2: A child standing on the platform of the wooden treehouse, looking out.

5. Maintenance

Regular maintenance is crucial to ensure the longevity and safety of your play tower.

- **Weekly Inspection:** Check for loose bolts, screws, or connections. Tighten as necessary.
- **Monthly Inspection:** Examine all wooden components for splinters, cracks, or signs of rot. Sand down splinters and replace severely damaged parts.
- **Cleaning:** Clean the wooden surfaces periodically with a mild soap and water solution. Avoid harsh chemicals.
- **Wood Treatment:** As a wooden product, it may benefit from periodic treatment with a child-safe wood sealant or stain to protect against weathering and prolong its life. Follow the manufacturer's recommendations for wood care products.
- **Ground Anchoring:** Ensure the play tower remains securely anchored to the ground, especially after heavy winds or rain.

6. Troubleshooting

Problem	Possible Cause	Solution
Structure feels wobbly or unstable.	Loose bolts or uneven ground.	Tighten all assembly bolts. Ensure the play tower is on a level surface. Consider additional ground anchors if necessary.
Wood shows signs of weathering (fading, minor cracks).	Exposure to elements.	Apply a child-safe wood sealant or stain. This is normal for natural wood products.
Splinters on wooden surfaces.	Natural wear and tear of wood.	Carefully sand down affected areas until smooth.

7. Specifications

Model Number: TP656P

Brand: TP Toys

Material: Wood

Built Dimensions: 4ft 6" x 2ft 11" x 6ft 11.86" (137.7cm x 89.7cm x 213cm)

Product Dimensions (packaged): 137.16 x 213.36 x 88.9 cm; 36.32 kg

Maximum Combined User Weight: 110 lbs / 50 kg

Recommended Age: 36 months - 8 years

Assembly Required: Yes

Number of Windows: 2

UPC: 875412006564

8. Warranty & Support

For specific warranty information, please refer to the documentation included with your purchase or visit the official TP Toys website. In case of missing parts, damaged components, or questions regarding assembly and use, please contact the retailer or TP Toys customer support directly.
Keep your proof of purchase for any warranty claims.

© 2024 TP Toys. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question