Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Buture Pro

BuTure CR20 Handheld Vacuum Cleaner User Manual

Model: CR20

Introduction

Thank you for purchasing the BuTure CR20 Handheld Vacuum Cleaner. This manual provides essential information for the safe operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and keep it for future reference.

Important Safety Instructions

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.
- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not charge the unit outdoors.

- Recharge only with the charger specified by the manufacturer. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- Under abusive conditions, liquid may be ejected from the battery; avoid contact. If contact accidentally occurs, flush with water. If liquid contacts eyes, additionally seek medical help. Liquid ejected from the battery may cause irritation or burns.

Package Contents

Please check the package contents upon opening to ensure all items are present and undamaged.

- BuTure CR20 Handheld Vacuum Cleaner Unit
- Charging Base / Wall Mount
- Power Adapter
- Extension Tube (for stick vacuum configuration)
- Floor Brush
- 2-in-1 Crevice Tool / Brush Nozzle
- Sofa Nozzle
- Cleaning Brush
- User Manual



Image: All components of the BuTure CR20 Handheld Vacuum Cleaner and its accessories, including the main unit, charging base, various nozzles, and power adapter.

Product Overview

Familiarize yourself with the main components of your vacuum cleaner.



Image: The BuTure CR20 handheld vacuum cleaner docked in its charging base, alongside its various cleaning attachments and power adapter.

- **Main Unit:** Contains the motor, dustbin, and battery.
- **Dustbin:** Collects dust and debris. Features one-touch emptying.
- **Filtration System:** Double washable filters (stainless steel and HEPA-type) for efficient particle capture.
- **LED Indicator:** Displays battery status and charging.
- **Charging Base:** Provides a convenient storage and charging solution.
- **Attachments:**
  - **Floor Brush:** For general floor cleaning (when used as a stick vacuum).
  - **2-in-1 Crevice Tool** / **Brush Nozzle:** Versatile tool for tight spaces and dusting.

- **Sofa Nozzle:** Designed for upholstery and fabric surfaces.



Image: A visual representation of the multifunctional accessories: (1) Floor Brush for general cleaning, (2) 2-in-1 Nozzle for crevices and dusting, and (3) Sofa Nozzle for upholstery.

Setup

1. Initial Charging

Before first use, fully charge the vacuum cleaner. This typically takes several hours. The LED indicator lights will show the charging progress.

1. Connect the power adapter to the charging base.
2. Plug the power adapter into a wall outlet.
3. Place the vacuum cleaner onto the charging base. Ensure it is securely seated.



Image: The BuTure CR20 vacuum cleaner docked in its charging station, illustrating the connection of the power adapter for charging. The image also highlights built-in protections against overvoltage, overcurrent, and overheating.

2. Assembly (Optional for Stick Vacuum Use)

For floor cleaning, assemble the vacuum into its stick configuration.

1. Attach the extension tube to the main vacuum unit until it clicks into place.
2. Attach the floor brush to the other end of the extension tube until it clicks into place.

Operating Instructions

1. Power On/Off

Press the power button located on the handle to turn the vacuum cleaner on or off.

2. Suction Modes

The BuTure CR20 offers two suction modes for different cleaning needs:

- **Standard Mode (11 KPa):** Provides up to 30 minutes of runtime, suitable for everyday dust and light debris.

- **Max Mode (17 KPa):** Provides powerful suction for stubborn dirt and pet hair, with a runtime of approximately 15 minutes.

Toggle between modes using the mode selection button (if available, otherwise it's usually a second press of the power button or a dedicated button).



Image: The vacuum cleaner shown in two scenarios, illustrating its two-speed vacuum design: 11KPa suction for up to 30 minutes (suitable for light cleaning) and 17KPa suction for up to 15 minutes (for deeper cleaning).

3. Using Attachments

Select the appropriate attachment for your cleaning task:

- **Floor Brush:** Ideal for hard floors and low-pile carpets when used as a stick vacuum.
- **2-in-1 Crevice Tool / Brush Nozzle:** Use the crevice tool for narrow gaps, corners, and edges. Slide the brush down for dusting delicate surfaces like keyboards or car vents.
- **Sofa Nozzle:** Effective for cleaning upholstery, pet beds, and car seats.



Image: The BuTure CR20 handheld vacuum cleaner in use, demonstrating its LED illumination feature for cleaning dark areas such as under car seats.



Image: The BuTure CR20 handheld vacuum cleaner effectively cleaning crumbs and debris from a table surface, highlighting its powerful 17KPa suction.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

1. Emptying the Dustbin

Empty the dustbin after each use or when the MAX fill line is reached.

1. Hold the vacuum cleaner over a trash can.
2. Press the dustbin release button to open the bottom flap and empty the contents.
3. Close the dustbin flap securely.



Image: The BuTure CR20 vacuum cleaner illustrating its one-touch debris emptying feature, allowing for quick and hygienic disposal of collected dirt into a waste bin.

2. Cleaning the Filters

The BuTure CR20 features a washable double filtration system. Clean filters regularly to maintain suction power.

1. Twist and pull to remove the dustbin from the main unit.
2. Remove the stainless steel filter and the HEPA-type filter from the dustbin.
3. Rinse both filters under running water until the water runs clear.
4. Allow filters to air dry completely for at least 24 hours before reassembling. Do not use the vacuum with wet filters.
5. Reassemble the filters and dustbin, then attach them back to the main unit.



Image: The washable double filtration system of the BuTure CR20 vacuum cleaner, showing the stainless steel and HEPA-type filters being rinsed under water. This system is designed to block 99.9% of particles, allergens, and bacteria.

3. Cleaning Attachments and Main Unit

Wipe down attachments and the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.

Troubleshooting

If you encounter issues with your vacuum cleaner, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the vacuum cleaner fully.
	Power button not pressed correctly.	Ensure the power button is pressed firmly.
Low suction power.	Dustbin is full.	Empty the dustbin.

Problem	Possible Cause	Solution
	Filters are dirty or clogged.	Clean and dry the filters thoroughly.
	Nozzle or hose is blocked.	Check for and remove any blockages in the nozzle, extension tube, or main unit intake.
Vacuum stops suddenly during use.	Battery is depleted.	Recharge the vacuum cleaner.
	Overheating protection activated.	Turn off the vacuum and allow it to cool down for at least 30 minutes before resuming use. Check for blockages.
Charging indicator lights not working.	Charger not properly connected.	Ensure the power adapter is securely plugged into the outlet and the charging base.
	Vacuum not seated correctly on charging base.	Adjust the vacuum on the charging base until the charging indicator lights activate.

Specifications

Feature	Detail
Brand	Buture Pro
Model Number	CR20
Power	170 Watts
Voltage	170 Volts
Suction Power	Up to 17000 PA (17 KPa)
Battery Type	Lithium-ion
Battery Capacity	3000 mAh
Runtime	Up to 30 minutes (Standard Mode)
Noise Level	70 dB
Weight	2.44 Kilograms
Color	Yellow
Form Factor	Handheld
Filtration System	Washable Double Filtration

Warranty and Support

BuTure Pro products are designed and manufactured to the highest quality standards. For warranty information or technical support, please refer to the warranty card included in your package or contact BuTure Pro customer service through the retailer where you purchased the product. Please have your model number (CR20) and purchase date ready when contacting support.

For further assistance, you may visit the official BuTure website or contact their support team directly. Contact information is typically found on the product packaging or the official brand website.

© 2024 BuTure Pro. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0991T2H56

More documents and user manuals: **https://manuals.plus/**