Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

The Cut Buddy 2007

The Cut Buddy Trim Buddy Cordless Beard & Hairline Trimmer Instruction Manual

Model: 2007

Introduction

This manual provides detailed instructions for the safe and effective use, maintenance, and care of your The Cut Buddy Trim Buddy Cordless Beard & Hairline Trimmer. Please read this manual thoroughly before first use and retain it for future reference.

Safety Information

Important Safety Precautions:

- Always keep the trimmer away from water sources.
- Avoid contact with eyes and nose.
- Do not use on infants.
- Always unplug the trimmer before cleaning.
- Always follow the recommended cleaning and maintenance procedures.
- Always supervise children when using the trimmer.
- Always store the trimmer out of reach of children when not in use.
- Always dispose of the trimmer in accordance with local regulations.

Package Contents

Verify that all items are present in your package:

- The Cut Buddy Trim Buddy Cordless Trimmer
- 4 Guard Combs (1.5mm, 3mm, 4.5mm, 6mm)
- Cleaning Brush
- USB Charging Cable
- Protective Cap
- Carry Case
- The Original Cut Buddy Hair and Beard Shaping Tool



Image: The complete package contents of the Trim Buddy, showing the trimmer, four guard combs, the shaping tool, charging cable, and carry case.

Setup

1. **Initial Charge:** Fully charge the trimmer before its first use. Connect the USB charging cable to the trimmer's charging port and a suitable USB power source. The LCD display will indicate charging status. A full charge provides up to 2 hours of cordless use.
2. **Attaching Guard Combs:** Select the desired guard comb (1.5mm, 3mm, 4.5mm, or 6mm) for your preferred hair length. Align the guard comb teeth with the trimmer blades and gently push until it clicks securely into place.



Image: Detailed view of the trimmer highlighting its stainless steel T-type cutter head, adjustable lever, LCD display, and charging port.

Operating Instructions

1. **Preparation:** Ensure your hair or beard is clean and dry before being cut.
2. **Power On:** Press and hold the power button to turn on the trimmer. Allow the trimmer to run for a short time before starting to trim.
3. **Attaching Guard Combs:** Align guard comb teeth with trimmer blades and then gently push the guard into place until it clicks.
4. **Trimming:** Slide the cutting head with a slight tilt over your skin without applying excessive pressure to trim your hair or beard. Only cut small amounts of hair at a time; attempting to cut too much hair too quickly may cause the cutting head to jam. Cut the hair progressively until you reach the desired length.
5. **Fine Trimming/Edging:** For closer trimming, edging, or detailing, remove the guard comb and use the trimmer without attachment.
6. **Using the Shaping Tool:** The included Cut Buddy Hair and Beard Shaping Tool can be used to assist in crafting precise

edges for your beard and hairline. Position the tool against your skin to create a guide for the trimmer.



Image: Demonstrates the trimmer's use for edging, lining, and fading, showing a man precisely grooming his beard and hairline.



Image: A user demonstrating the application of The Cut Buddy shaping tool to achieve a clean beard line with the trimmer.



Image: Illustrates the different guard sizes (1.5mm, 3.0mm, 4.5mm, 6.0mm) and shows examples of precise beard edging, hair lining, and hair detailing achievable with the trimmer.

Maintenance

Cleaning

1. After each use, turn off and unplug the trimmer.
2. Use the provided cleaning brush to remove any loose hairs from the blades and the trimmer body.
3. The trimmer is IPX4 water-resistant, allowing for easy rinsing under running water. Ensure the trimmer is unplugged before rinsing. Do not submerge the entire unit.

Oiling

1. Oil the trimmer head from time-to-time if you use the trimmer regularly.
2. Use non-corroding oil, such as sewing machine oil.
3. Remove the comb attachment.
4. Apply 1-2 drops of oil between the cutting teeth.
5. Turn the trimmer on briefly to distribute the oil.
6. Wipe away any excess oil by wiping with a cloth.

Storage

Store the trimmer and power cable in a dry area with low humidity and away from direct sunlight and other heat sources. Keep the oil and brush away from children.



Image: The trimmer shown under running water, illustrating its water-resistant design for easy cleaning.



Image: A visual guide detailing steps for using the trimmer, along with instructions for proper storage and oiling of the blades.

Troubleshooting

If you encounter issues with your Trim Buddy, consider the following:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. Connect it to the charger and check the LCD display.
- **Poor cutting performance or pulling hair:**
  - Clean the blades thoroughly to remove any trapped hair or debris.
  - Apply a few drops of oil to the blades as per the "Oiling" instructions.
  - Ensure the guard comb is correctly attached and not loose.
  - Avoid cutting large amounts of hair at once; take smaller passes.
- **Battery not holding charge:** Ensure the charging cable and adapter are functioning correctly. If issues persist, contact customer support.

Specifications

Brand	The Cut Buddy
Model Number	2007
Item Weight	454 Grams (1 Pound)
Item Package Dimensions (L x W x H)	8.11 x 4.25 x 2.64 inches
Power Source	Battery Powered

Material	Acrylonitrile Butadiene Styrene, Plastic
Color	Black
Battery Life	Up to 2 hours use time
Guard Comb Sizes	1.5mm, 3mm, 4.5mm, 6mm
Water Resistance	IPX4 (Splash resistant)



Image: Information on the trimmer's battery life, showing 2 hours of use time, a 1200 mAh battery capacity, and 2 hours charging time.

Warranty and Support

For warranty information or technical support, please contact The Cut Buddy customer service. Refer to the product packaging or the official The Cut Buddy website for current contact details.
Manufacturer: The Cut Buddy

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0992P4YN3

More documents and user manuals: **https://manuals.plus/**