Owigift LGT2554

Owigift Starter Motor Replacement Manual

For Husqvarna LGT2554 and compatible Lawn Mower Tractors

Introduction

This manual provides essential information for the installation, operation, and maintenance of your Owigift replacement starter motor. This starter motor is designed to provide reliable starting power for various Husqvarna LGT series lawn mower tractors, including models such as LGT2554. Please read this manual thoroughly before installation and use to ensure proper function and safety.

Safety Information

Always prioritize safety when working with machinery and electrical components. Failure to follow these safety guidelines may result in injury or damage to equipment.

- **Disconnect Battery:** Before beginning any installation or maintenance, always disconnect the negative battery cable first, followed by the positive cable, to prevent accidental starting or electrical shock.
- **Wear Protective Gear:** Use appropriate personal protective equipment (PPE) such as safety glasses and gloves.
- **Ensure Proper Tools:** Use the correct tools for the job to avoid damaging components or causing injury.
- **Work in a Well-Ventilated Area:** Ensure adequate ventilation, especially when working with batteries.
- **Consult Tractor Manual:** Refer to your specific Husqvarna lawn mower tractor's owner's manual for detailed instructions on accessing and replacing the starter motor, as procedures may vary slightly by model.
- **Professional Installation:** If you are unsure about any step, seek assistance from a qualified technician.

Parts List

Verify that all components are present before beginning installation.

- Owigift Replacement Starter Motor (1 unit)
- Mounting Hardware (if included, otherwise reuse existing)



Figure 1: Owigift Replacement Starter Motor. This image shows the main body of the starter motor, featuring its metallic casing and the electrical terminal at the top, secured with a nut and washer. The golden-colored end cap with multiple screw holes is visible, indicating the mounting points.

Setup and Installation

Follow these steps carefully to install the replacement starter motor. Refer to your tractor's service manual for specific torque specifications and component locations.

1. **Prepare the Tractor:** Park the lawn mower tractor on a level surface. Engage the parking brake. Turn off the engine and remove the ignition key.
2. **Disconnect Battery:** Disconnect the negative (-) battery cable first, then the positive (+) battery cable.
3. **Locate Old Starter Motor:** Identify the existing starter motor on your Husqvarna tractor. It is typically located near

the engine flywheel.

4. **Disconnect Wiring:** Carefully disconnect the electrical wiring from the old starter motor. This usually involves a main power cable and a smaller solenoid wire. Note their positions for reinstallation.
5. **Remove Old Starter Motor:** Unbolt the old starter motor from its mounting points. There are typically two or three mounting bolts. Support the motor as you remove the last bolt to prevent it from falling.
6. **Inspect Mounting Area:** Clean any debris or corrosion from the mounting surface on the engine block.
7. **Install New Starter Motor:** Position the Owigift replacement starter motor into the mounting location. Align the bolt holes and hand-tighten the mounting bolts.
8. **Secure Mounting Bolts:** Tighten the mounting bolts evenly to the manufacturer's specified torque. Do not overtighten.
9. **Reconnect Wiring:** Reconnect the electrical wiring to the new starter motor. Ensure the main power cable is securely fastened to the large terminal and the solenoid wire to the smaller terminal. Double-check all connections for tightness.
10. **Reconnect Battery:** Reconnect the positive (+) battery cable first, then the negative (-) battery cable.
11. **Test Functionality:** Attempt to start the tractor to verify the new starter motor is functioning correctly. Listen for a strong cranking sound.

Operating Instructions

The Owigift starter motor is designed to operate seamlessly with your Husqvarna lawn mower tractor's existing electrical system. No special operating procedures are required beyond the standard starting sequence for your tractor.

- Ensure the tractor's battery is fully charged.
- Follow the starting procedure outlined in your Husqvarna tractor's owner's manual (e.g., engage parking brake, set throttle, depress clutch/brake pedal, turn ignition key).
- If the engine does not start on the first attempt, wait a few seconds before trying again to allow the starter motor to cool. Avoid prolonged cranking.

Maintenance

The Owigift starter motor is a sealed unit and requires minimal maintenance. However, regular checks of related components can prolong its lifespan and ensure reliable operation.

- **Battery Condition:** Regularly check your tractor's battery for proper charge and clean terminals. A weak battery can put excessive strain on the starter motor.
- **Electrical Connections:** Periodically inspect all electrical connections to the starter motor and battery for corrosion or looseness. Clean and tighten as necessary.
- **Mounting Security:** Ensure the starter motor remains securely mounted to the engine block.
- **Avoid Over-Cranking:** Do not continuously crank the engine for extended periods if it fails to start. This can overheat and damage the starter motor.

Troubleshooting

If you experience issues with your starter motor, consult the following table before seeking professional assistance.

Symptom	Possible Cause	Solution

Symptom	Possible Cause	Solution
Starter motor does not engage or click.	Dead or weak battery. Loose or corroded battery terminals. Faulty ignition switch. Safety interlock switch engaged.	Charge or replace battery. Clean and tighten battery terminals. Test and replace ignition switch if necessary. Ensure all safety switches (e.g., seat, PTO, brake) are disengaged.
Starter motor cranks slowly.	Weak battery. Corroded battery cables. Engine oil too thick (cold weather).	Charge or replace battery. Inspect and clean battery cables and connections. Use appropriate oil viscosity for ambient temperature.
Starter motor spins but engine does not crank.	Bendix drive (starter gear) not engaging flywheel. Damaged flywheel teeth.	This indicates an internal starter motor issue or flywheel damage. Professional inspection and repair/replacement may be required.

Specifications

Technical details for the Owigift Replacement Starter Motor.

- **Brand:** Owigift
- **Manufacturer:** Owigift
- **Wattage:** 1.4 KW
- **Material:** Copper
- **Compatible Models (Partial List):** Husqvarna LGT2554, LGT 2554, 96043006100, 96043006101, 96043007400, 96043009400, 96045001500, 96045001501, 96045001502, 96045001503, 96045001504, 96045001701
- **UPC:** 718997293984
- **ASIN:** B099491Y14

Warranty and Support

For specific warranty information regarding your Owigift replacement starter motor, please refer to the product packaging or contact Owigift customer support directly. Keep your proof of purchase for warranty claims.
If you require further assistance or have questions not covered in this manual, please contact Owigift customer service through the retailer where the product was purchased or visit the official Owigift website for contact details.

© 2024 Owigift. All rights reserved.