ZdalaMit CT-RC1US-19

ZdalaMit Infrared Replacement Remote Control User Manual

Model: CT-RC1US-19

1. Introduction

This manual provides instructions for the ZdalaMit Infrared Replacement Remote Control. This remote is designed to function as a direct replacement for original remote controls of various Toshiba Smart TV models. It operates using infrared technology and does not feature voice control.

2. Safety Information

- Do not expose the remote control to direct sunlight or heat sources.
- Avoid dropping or subjecting the remote to strong impacts.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period.
- Keep batteries out of reach of children.

3. Package Contents

The package contains the following item:

- 1x ZdalaMit Infrared Replacement Remote Control

Note: Batteries are not included and must be purchased separately.

4. Setup

4.1. Installing Batteries

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery cover.
3. Insert two (2) 1.5V AAA alkaline batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.

4. Close the battery cover securely.

Once batteries are installed, the remote control is ready for use. No programming or pairing is required for this infrared remote.



Image: Back view of the remote control, showing the battery compartment.

5. Operating the Remote Control

This infrared remote control provides standard functions for your compatible Toshiba Smart TV. Point the remote directly at the TV's infrared receiver for optimal performance.




Search
prm video
NETFLX
PATNR 1
PATNR 2



Image: Front view of the ZdalaMit replacement remote control, displaying all buttons.

5.1. Button Functions

- **Power Button ( )**: Turns the TV on or off.
- **Search Button**: Accesses the TV's search function.
- **Back Button (↩)**: Returns to the previous screen or menu.
- **Home Button (⌂)**: Navigates to the TV's home screen.
- **Menu Button (☰)**: Opens the TV's main menu or options.
- **Directional Pad (Up, Down, Left, Right)**: Navigates through menus and selections.
- **OK/Select Button**: Confirms a selection.
- **Rewind ( )**: Rewinds media playback.
- **Play/Pause ( )**: Plays or pauses media playback.
- **Fast Forward ( )**: Fast forwards media playback.
- **Volume Up (+)**: Increases the TV volume.
- **Volume Down (-)**: Decreases the TV volume.
- **Mute ( )**: Mutes or unmutes the TV sound.
- **Channel Up/Down (TV icon)**: Changes TV channels.
- **Dedicated App Buttons (e.g., "prm video", "NETFLIX", "PATNR 1", "PATNR 2")** Provides direct access to specified streaming applications.

6. Compatibility

This ZdalaMit Infrared Replacement Remote Control is compatible with the following Toshiba Smart TV models:

- 65LF711U20
- 55LF711U20
- 50LF621U19
- TF-50A810U19
- TF50A810U19
- 55LED2160P
- 43LED2160P
- 50LED2160P
- 50LF621U19
- 43LF621U19
- CT-RC1US-19 (Remote Model)
- 32LF221U19
- 43LF421U19
- 43LF711U20
- 50LF711U20

Important Note: This is an infrared remote control. It does not support voice control functions. If your TV is in a "Searching for your remote" or pairing mode that requires a voice remote, this remote will not function until that step is skipped or completed with an appropriate voice-enabled remote. Once the TV is out of this mode, this remote will

function.

7. Troubleshooting

Problem	Solution
Remote is not responding.	◦ Ensure batteries are inserted correctly with the correct polarity. ◦ Replace old batteries with new 1.5V AAA alkaline batteries. ◦ Point the remote directly at the TV's infrared receiver. ◦ Ensure there are no obstructions between the remote and the TV.
Some buttons do not work.	◦ Verify that your TV model is listed in the compatibility section. ◦ This remote does not have voice control; voice-related functions will not work. ◦ Ensure the TV's software is up to date.
TV is stuck in "Searching for your remote" mode.	This infrared remote cannot bypass this step if it requires a voice remote. You must skip or complete this pairing step using an original voice remote or by following your TV's specific instructions to bypass it. Once the TV is out of this mode, this remote will function.

8. Specifications

- **Brand:** ZdalaMit
- **Model:** CT-RC1US-19 (Replacement Remote)
- **Type:** Infrared Remote Control
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Special Feature:** Pre-programmed (no setup required after battery installation)
- **Color:** Black
- **Product Dimensions:** 6 x 1.2 x 0.5 inches
- **Item Weight:** 1.59 ounces (without batteries)
- **Compatible Devices:** Toshiba Smart Televisions (specific models listed in Section 6)

9. Maintenance

- Clean the remote control with a soft, dry cloth. Do not use liquid cleaners.
- Avoid exposing the remote to extreme temperatures or humidity.
- If the remote is not used for an extended period, remove the batteries to prevent leakage.

10. Warranty and Support

This product is designed for reliable performance. For any questions or support needs regarding this ZdalaMit replacement remote control, please refer to the retailer or manufacturer's customer service channels where the product was purchased.

Note: Specific warranty details may vary by retailer. Please retain your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question