Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM US800-0920131

HOMCOM 10.5 Quart Air Fryer Oven Instruction Manual

Model: US800-0920131

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons. Read all instructions carefully before operating this appliance.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Maintain at least 4 inches of space on all sides of the appliance for proper ventilation.

2. Product Overview and Components

The HOMCOM 10.5 Quart Air Fryer Oven is a versatile countertop appliance designed for air frying, roasting, and more. It features a digital LED screen and touch controls for easy operation.

2.1 Main Unit



Image: The HOMCOM 10.5 Quart Air Fryer Oven, showcasing its compact design and front control panel.

2.2 Included Accessories

Your air fryer oven comes with a variety of accessories to enhance your cooking experience:



Image: A visual representation of the various accessories included with the air fryer oven, such as air flow racks, a drip tray, rotisserie basket, rotisserie lift, chicken fork, rotating basket, and rotisserie stand.

- **3 x Air Flow Racks:** For multi-level cooking and air circulation.
- **1 x Drip Tray:** Collects excess oil and food particles for easier cleaning.
- **1 x Rotisserie Basket:** Ideal for tumbling smaller items like fries or nuts.
- **1 x Rotisserie Lift:** Tool for safely removing the rotisserie spit or basket.
- **1 x Chicken Fork:** For roasting whole chickens or larger cuts of meat.
- **1 x Rotating Basket:** Similar to the rotisserie basket, designed for even cooking of small items.
- **1 x Rotisserie Stand:** For holding the rotisserie spit or basket after removal.

2.3 Product Features

- **10.5 Quart Capacity:** Suitable for family meals and entertaining.
- **1500W Power:** Ensures quick and efficient heating.
- **Digital LED Screen with Touch Controls:** For precise temperature and time adjustments.

- **8 Preset Cooking Menus:** Convenient one-touch cooking for common dishes.
- **360° Hot Air Circulation:** Provides even cooking and crispy results.
- **Non-Stick Coating:** For easy food release and cleaning.
- **Inclined Design:** Allows for direct visibility and easy operation of the control panel.



Image: The air fryer oven highlighting its 10.5 quart capacity, suitable for 3-5 persons.



Image: Diagram illustrating the 360-degree hot air circulation technology within the air fryer oven, emphasizing time-saving, quick and even heating, and crispy food with less oil.

3. Setup and First Use

1. **Unpack:** Carefully remove all packaging materials and accessories from the box.
2. **Clean:** Wash all removable parts (racks, drip tray, etc.) in warm, soapy water. Wipe the interior and exterior of the main unit with a damp cloth. Dry thoroughly.
3. **Placement:** Place the air fryer oven on a stable, level, heat-resistant surface, ensuring at least 4 inches of clearance from walls and other appliances for proper ventilation.
4. **First Use Burn-Off:** Before cooking food, plug in the appliance and run it empty at 400°F (200°C) for approximately 10-15 minutes. This helps to burn off any manufacturing residues and odors. A slight odor or smoke may be present during this initial use; this is normal. Ensure the area is well-ventilated.
5. **Cool Down:** Allow the appliance to cool completely after the burn-off cycle.

4. Operating Instructions

The HOMCOM Air Fryer Oven features an intuitive digital LED touchscreen for easy control of cooking functions.



Image: Close-up of the air fryer oven's inclined digital LED touchscreen, showing temperature display and various function icons, designed for direct visibility and easy operation.

4.1 Basic Operation

1. **Prepare Food:** Place your food on the appropriate accessory (air flow rack, rotisserie basket, etc.). Ensure the drip tray is at the bottom to catch any drippings.
2. **Insert Accessories:** Carefully slide the accessory with food into the oven. Close the door securely.
3. **Power On:** Plug the appliance into a grounded electrical outlet. The control panel will illuminate.
4. **Select Function:**
    - **Manual Setting:** Press the Temperature (Temp) and Time buttons to adjust to your desired settings using the '+' and '-' icons.
    - **Preset Menus:** Select one of the 8 preset icons (French Fries, Pizza, Bread, Meat, Fish, Drying, Poultry, Cakes) for

automatic time and temperature settings. You can adjust these presets manually if needed.

5. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle.
6. **Monitor Cooking:** Use the internal light button to check on your food without opening the door.
7. **End of Cooking:** The oven will beep when the cooking cycle is complete. Carefully remove the food using oven mitts and the rotisserie lift tool if applicable.
8. **Power Off:** Unplug the appliance from the wall outlet after use.

4.2 Preset Cooking Menus

The air fryer oven includes 8 convenient preset functions:



Image: A graphic displaying the 8 preset cooking menus available on the HOMCOM Air Fryer Oven: French Fries, Pizza, Bread, Meat, Fish, Drying, Poultry, and Cakes.

- French Fries
- Pizza
- Bread

- Meat
- Fish
- Drying (Dehydrate)
- Poultry
- Cakes

These presets offer optimized time and temperature settings for common dishes. You can adjust these settings manually to suit your preferences.

4.3 Rotisserie Function

The rotisserie function allows for even roasting of whole chickens or other meats using the chicken fork, or for tumbling smaller items in the rotisserie basket.

Your browser does not support the video tag.

Video: Demonstration of the HOMCOM Air Fryer Oven's rotisserie function, showing a whole chicken and skewers rotating for even cooking. This video highlights the large capacity and versatility for various dishes.

1. Assemble the chicken fork or rotisserie basket with your food.
2. Insert the rotisserie spit into the designated slots inside the oven.
3. Select the desired cooking time and temperature, or use a relevant preset.
4. Press the Rotisserie icon on the control panel to activate rotation.
5. Press Start/Pause to begin cooking.



Image: A person carefully placing food on rotisserie skewers into the HOMCOM Air Fryer Oven, demonstrating the ease of loading the appliance for rotisserie cooking.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer oven.



Image: A dishwasher rack with various air fryer accessories, indicating that many components are dishwasher safe for easy cleaning.

1. **Unplug and Cool:** Always unplug the air fryer oven and allow it to cool completely before cleaning.
2. **Clean Accessories:** All removable accessories (air flow racks, drip tray, rotisserie basket, chicken fork, etc.) are dishwasher safe. Alternatively, wash them in warm, soapy water using a non-abrasive sponge. Rinse thoroughly and dry.
3. **Clean Interior:** Wipe the interior of the oven with a damp cloth and mild detergent. For stubborn food residue, a non-abrasive brush can be used. Avoid harsh chemicals or abrasive cleaners.
4. **Clean Exterior:** Wipe the exterior of the appliance with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.
5. **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

6. Troubleshooting

If you encounter issues with your air fryer oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; appliance not assembled correctly.	Ensure the power cord is securely plugged into a working outlet. Check if the door is fully closed.
Food is not cooked evenly.	Overcrowding; incorrect temperature/time; food not turned/shaken.	Do not overcrowd the basket/racks. Adjust temperature/time. Turn or shake food halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; fatty food cooking.	Clean the drip tray and interior thoroughly. For fatty foods, ensure the drip tray is in place and consider reducing temperature slightly.
Appliance emits a burning plastic smell.	Initial burn-off; new appliance odor.	This is normal during first few uses. Ensure good ventilation. If odor persists after several uses, contact customer support.
Rotisserie function not working.	Rotisserie spit/basket not properly installed; function not activated.	Ensure the rotisserie spit/basket is correctly seated in the internal gears. Press the Rotisserie icon on the control panel.

7. Specifications

- **Model:** US800-0920131
- **Capacity:** 10.5 Quarts
- **Power:** 1500 Watts
- **Control Method:** Touch Control
- **Max Temperature Setting:** 400 °F (200 °C)
- **Product Dimensions (D x W x H):** 13.25" x 13.25" x 14.25"
- **Material:** Polypropylene (Outer), Glass (Door)
- **Color:** Black
- **UPC:** 842525151382



Image: Diagram showing the dimensions of the HOMCOM Air Fryer Oven: 13.25 inches deep, 13.25 inches wide, and 14.25 inches high.

8. Warranty and Support

For warranty information or customer support, please refer to the warranty card included with your purchase or visit the official HOMCOM website. Keep your proof of purchase for any warranty claims.
For further assistance, you may contact HOMCOM customer service through their official channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B099K1QJ2Q

More documents and user manuals: **https://manuals.plus/**