Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

USA Toyz UT-ASGMNI-EXT

USA Toyz Astroshot Gemini Extreme Shooting Game Instruction Manual

Introduction

The USA Toyz Astroshot Gemini Extreme Shooting Game is designed to enhance target accuracy and provide engaging physical gameplay. This multi-player set includes a dynamic moving target, foam ball popper air guns, and soft foam balls, suitable for both indoor and outdoor use. It encourages active play and can be enjoyed by children aged 6 and up.



Image: The complete Astroshot Gemini Extreme Shooting Game set.

What's in the Box

Your Astroshot Gemini Extreme package contains the following components:

- 1 Astroshot Moving Standing Shooting Target
- 2 Air Popper Toy Foam Blaster Guns
- 30 Soft Foam Balls (15 blue, 15 orange)



Image: All components included in the Astroshot Gemini Extreme set.

Safety Information

Warning: Toys should be used under adult supervision.

- Do not aim guns at eyes or face.
- Use only the foam balls provided or compatible soft foam balls.
- Keep small parts away from children under 3 years of age to prevent choking hazards.

Setup and Assembly

1. **Assemble the Target Stand:** Connect the plastic poles and connectors to form the freestanding target frame. Ensure all connections are secure.
2. **Attach the Target Fabric:** Secure the fabric target sheet to the assembled frame. The target features four scoring holes with mesh pockets to catch the foam balls.

3. **Install Batteries (for Moving Target):** The moving target requires (4) AA batteries (not included). Open the battery compartment on the base of the target stand, insert the batteries according to polarity, and close the compartment securely.
4. **Prepare the Air Guns:** No batteries are required for the air popper guns.



Image: The moving target game set up for play.

Operating Instructions

Using the Air Popper Guns:

1. **Load Foam Balls:** Insert up to 10 soft foam balls into the barrel of each air popper gun.
2. **Prime the Gun:** Hold the gun firmly and pull the pump handle back and forth to build air pressure.
3. **Shoot:** Aim at the target and push the pump handle forward quickly to launch the foam balls. The harder you pump, the further the balls will travel (up to 26 ft).



Image: Steps for loading and firing the air popper gun.

Operating the Moving Target:

1. **Power On:** Locate the power switch on the base of the target stand and turn it to the 'ON' position.
2. **Select Speed Mode:** The target features dual-speed side-to-side movement. Select your desired speed setting for varied challenge levels.
3. **Aim and Score:** Shoot the foam balls into the four scoring holes of varying sizes on the oscillating target to score points.



Image: Detail of the target's movement mechanism.

Maintenance

- **Cleaning:** Wipe down the plastic components and target fabric with a damp cloth as needed. Do not submerge electronic parts in water.
- **Storage:** When not in use, disassemble the target stand and store all components in the original packaging or a suitable container to prevent loss or damage. Remove batteries if storing for extended periods.
- **Foam Balls:** Keep foam balls clean and dry. Replace any damaged or worn-out balls to ensure optimal performance.

Troubleshooting

- **Gun Not Firing Consistently:** Ensure foam balls are properly loaded and the pump handle is pulled back and pushed forward with sufficient force. Check for any obstructions in the barrel.
- **Target Not Moving:** Verify that the (4) AA batteries are correctly installed and not depleted. Ensure the power switch is in the 'ON' position. Check for any physical obstructions preventing movement.

- **Missing or Damaged Parts:** Refer to the manufacturer's contact information for assistance with replacement parts.

Specifications

Feature	Detail
Product Dimensions	12 x 16 x 43 inches (Target Stand)
Item Weight	3.27 pounds
Item Model Number	UT-ASGMNI-EXT
Manufacturer Recommended Age	6 years and up
Power Source (Target)	4 AA Batteries (not included)
Gun Operation	Air-powered (no batteries required)

Warranty and Support

For warranty information, technical support, or to inquire about replacement parts, please contact USA Toyz customer service. Refer to the product packaging or the official USA Toyz website for the most current contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B099QGKB7M

More documents and user manuals: **https://manuals.plus/**