Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Necchi NCL-668

Necchi NCL-668 Steam Iron User Manual

Model: NCL-668

Introduction

Thank you for choosing the Necchi NCL-668 Steam Iron. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

Safety Instructions

- Always unplug the iron from the power outlet when filling with water, emptying, or when not in use.
- Do not leave the iron unattended while it is connected to the power supply.
- Keep the iron and its cord out of reach of children.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- Use the iron only for its intended purpose.
- The iron features a safety shut-off with thermal fuse and overheat protection. If the iron overheats, it will automatically shut off.

Product Overview

The Necchi NCL-668 is a powerful 2600W steam iron designed for efficient garment care. It features a durable ceramic soleplate, a 280ml water tank, and a 360-degree swivel cord for ease of use. Key functions include adjustable temperature control, variable steam, steam burst, vertical steam, and a self-cleaning function.



Figure 1: Front view of the Necchi NCL-668 Steam Iron, showcasing its ergonomic design, control dial, and water tank.



Figure 2: Underside view of the Necchi NCL-668 Steam Iron, highlighting the ceramic soleplate with steam vents and the "AUTOCLEAN" marking.

Setup

1. **Unpacking:** Carefully remove the iron from its packaging. Retain the packaging for future storage or transport.
2. **First Use:** Before first use, wipe the soleplate with a soft, damp cloth to remove any manufacturing residues.

3. **Filling the Water Tank:**
    - Ensure the iron is unplugged.
    - Open the water tank cover.
    - Fill the 280ml transparent water tank with clean tap water up to the MAX mark. Do not overfill.
    - Close the water tank cover securely.
4. **Power Connection:** Plug the VDE plug into a suitable 230V power outlet. The power indicator light will illuminate.

Operating Instructions

Temperature Control

The iron features an adjustable temperature control dial. Rotate the dial to select the appropriate temperature setting for your fabric type. Always check the garment's care label before ironing. The power indicator light will turn off when the desired temperature is reached and cycle on/off during ironing to maintain the temperature.

Dry Ironing

For dry ironing, ensure the steam control is set to the '0' (no steam) position. Select the desired temperature and wait for the iron to heat up.

Steam Ironing

For steam ironing, ensure the water tank is filled. Set the temperature to the steam range (usually indicated on the dial). Once the iron reaches the set temperature, adjust the variable steam control to the desired steam output.

Steam Burst and Spray Function

- **Steam Burst:** Press the steam burst button for an extra surge of steam to remove stubborn wrinkles. Wait a few seconds between bursts to allow the steam to regenerate.
- **Spray Function:** Press the spray button to mist the fabric with water, which helps in smoothing out creases.

Vertical Steam

The vertical steam function allows you to steam hanging garments, drapes, or upholstery. Hold the iron vertically, close to the fabric, and press the steam burst button. Ensure the iron is at its maximum temperature setting for optimal vertical steam performance.

Maintenance

Cleaning the Soleplate

If the soleplate becomes dirty, clean it with a damp cloth and a non-abrasive cleaner. Do not use metallic scouring pads or abrasive cleaners as they can damage the ceramic coating.

Self-Cleaning Function

The iron is equipped with a self-cleaning function to remove mineral deposits and impurities from the steam vents. Follow these steps:

1. Fill the water tank to the MAX level.
2. Set the steam control to '0' (no steam).
3. Plug in the iron and set the temperature to maximum.

4. Once the iron reaches maximum temperature, unplug it.
5. Hold the iron horizontally over a sink.
6. Press and hold the self-clean button (if available, otherwise use the steam burst button repeatedly while shaking the iron gently). Hot water and steam will be expelled from the soleplate, carrying impurities with them.
7. Continue until the water tank is empty.
8. Plug the iron back in and let it heat up to dry the soleplate.

Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron upright in a safe, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; thermostat set too low; safety cut-off activated.	Check power connection; try another outlet; set temperature higher; allow iron to cool and reset.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to '0'; mineral deposits.	Fill water tank; set temperature to steam range; adjust steam control; perform self-cleaning.
Water leaking from soleplate.	Temperature too low for steam; water tank overfilled; steam control not fully closed for dry ironing.	Increase temperature; do not overfill; ensure steam control is '0' for dry ironing.
Brown stains on fabric.	Mineral deposits in water tank/steam vents; dirty soleplate.	Perform self-cleaning; clean soleplate.

Specifications

Feature	Detail
Model Number	NCL-668
Brand	Necchi
Power	2600 Watts
Voltage	230 Volts
Water Tank Capacity	280 ml
Soleplate Material	Ceramic
Weight	1.07 Kilograms
Cord Type	360-degree swivel cord
Safety Features	Overheat protection, safety cut-off with thermal fuse
Functions	Spray, Variable Steam, Steam Burst, Vertical Steam, Self-Cleaning

Warranty and Support

Information regarding product warranty and customer support contact details was not available in the provided product data. Please refer to the product packaging or the retailer's website for specific warranty terms and support information. For any issues not covered in this manual, please contact the retailer or an authorized service center.

© 2023 Necchi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B099QLW7L9

More documents and user manuals: **https://manuals.plus/**