Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Kaiser KSW-5003

Kaiser KSW-5003 Rechargeable Speaker

INSTRUCTION MANUAL

Introduction

This manual provides essential information for the safe and efficient operation of your Kaiser KSW-5003 Rechargeable Speaker. Please read this manual thoroughly before using the product and retain it for future reference.

Product Features

- **10W RMS Power Output:** Delivers clear and robust audio.
- **Bluetooth Connectivity:** Wireless audio streaming with a range of up to 10 meters.
- **Karaoke Function:** Supports microphone input for karaoke sessions.
- **Multiple Input Options:** Includes USB, Micro-USB, Miniplug, Plug, and SD card reader for versatile media playback.
- **Rechargeable Battery:** Provides portable use with approximately 3 hours of battery life.
- **RGB Circle Light:** Integrated lighting effects to enhance the audio experience.
- **KSR-Link Technology:** Allows connection of two KSW-5003 speakers for enhanced stereo sound.

Package Contents

Ensure all items are present in the package:

- Kaiser KSW-5003 Rechargeable Speaker
- USB Charging Cable
- Auxiliary Audio Cable
- Wired Microphone
- Instruction Manual

Setup

1. Initial Charging

Before first use, fully charge the speaker for approximately 2 hours using the provided USB charging cable. Connect the Micro-USB end to the speaker's charging port and the USB-A end to a compatible USB power adapter (not included) or computer USB port. The charging indicator light will show the charging status.

2. Powering On/Off

Locate the ON/OFF switch on the control panel. Slide the switch to the 'ON' position to power on the speaker. Slide it to the 'OFF' position to power off.



Figure 1: Back panel with power switch and input ports.

Operating Instructions

1. Bluetooth Pairing

1. Power on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select 'KSW-5003' from the list. Once paired, the speaker will emit a confirmation tone, and the LED light will stop

flashing.

2. Using USB/Micro SD Card

Insert a USB drive or Micro SD card into the corresponding port on the speaker. The speaker will automatically detect the media and begin playback. Use the playback control buttons (previous/next track, play/pause) on the speaker to manage your music.

3. Auxiliary Input

Connect an external audio device using the provided 3.5mm auxiliary cable. Insert one end into the speaker's AUX port and the other end into your device's audio output. The speaker will switch to AUX mode automatically.

4. Karaoke Function

Connect the wired microphone to the microphone input port on the speaker. Adjust the microphone volume as needed. The speaker's karaoke function allows you to sing along with your music.

5. FM Radio

Press the 'MODE' button to switch to FM radio mode. Use the previous/next track buttons to scan for radio stations. Press and hold the play/pause button to auto-scan and save available stations.

6. Light Effects

Press the dedicated light button on the control panel to cycle through different RGB light modes or turn the lights off.



Figure 2: Top control panel for managing functions.

7. KSR-Link (True Wireless Stereo)

To connect two KSW-5003 speakers for TWS functionality:

1. Ensure both speakers are powered on and in Bluetooth mode, but not yet paired with any device.
2. On one speaker, press and hold the 'MODE' button until you hear a confirmation tone, indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, they will emit another confirmation tone.
4. Now, connect your device to one of the speakers via Bluetooth as described in step 1. Both speakers will play audio simultaneously.

8. Volume and Bass Control

Use the volume buttons (+/-) on the control panel to adjust the master volume. The 'BASS' button can be used to enhance or reduce the bass output.



Figure 3: Front view of the speaker showcasing the RGB lighting.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker at least once every three months if not in regular use.
- **Water Resistance:** This speaker is not waterproof. Avoid exposure to water or high humidity.

Troubleshooting

Problem	Possible Solution

Problem	Possible Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source using the USB cable.
Cannot pair via Bluetooth.	Ensure the speaker is in pairing mode. Turn off Bluetooth on other devices to avoid interference. Move closer to the speaker.
No sound from speaker.	Check volume levels on both the speaker and the connected device. Ensure the correct input mode (Bluetooth, AUX, USB/SD) is selected.
Microphone not working.	Ensure the microphone is securely plugged into the correct port. Check the microphone's ON/OFF switch if applicable.
KSR-Link (TWS) not connecting.	Ensure both speakers are KSW-5003 models and are not connected to any other Bluetooth device. Follow the TWS pairing steps carefully.

Specifications

Model: KSW-5003

Brand: Kaiser

Power Output: 10W RMS

Speaker Size: 7.62 cm (3 inches) woofer diameter

Frequency Response: 4 KHz

Connectivity: Bluetooth, Auxiliary (Miniplug), USB, Micro SD

Bluetooth Range: Up to 10 meters

Audio Channels: 2.0 (Mono output mode)

Battery Life: Approximately 3 hours

Control Method: Manual buttons, Remote control (if included)

Material: Plastic

Dimensions (DxWxH): 15 x 16 x 29 cm

Weight: 1 kg



Figure 4: Speaker dimensions.

Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support or service inquiries, please contact Kaiser customer service through their official website or the contact information provided on the product packaging.
Keep your purchase receipt as proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B099XCXH9G

More documents and user manuals: **https://manuals.plus/**