Tefal EY705D51

T-fal Easy Fry XXL Air Fryer & Grill Combo Instruction Manual

Brand: Tefal | **Model:** EY705D51

Introduction

Welcome to the instruction manual for your new T-fal Easy Fry XXL Air Fryer & Grill Combo. This versatile appliance is designed to simplify your cooking process, offering a healthier way to prepare your favorite meals. With its advanced Air Pulse technology, you can achieve crispy, delicious results with significantly less oil. This manual provides essential information on setup, operation, maintenance, and troubleshooting to ensure you get the most out of your appliance.

Important Safety Information

- Always read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Keep the appliance and its cord out of reach of children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Always unplug the appliance after use and before cleaning.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm free space on the back and sides and 10 cm free space above the appliance.
- Hot air is released through the air outlet openings. Keep your hands and face at a safe distance from the openings.
- The surfaces may become hot during use. Do not touch hot surfaces. Use handles or knobs.

Product Overview

Components



The T-fal Easy Fry XXL Air Fryer & Grill Combo features a sleek black and stainless steel design, with a large capacity basket and an intuitive digital control panel on top.

- Main Unit with Digital Control Panel
- Removable Cooking Basket
- Non-stick Grill Plate
- Power Cord

Control Panel



The top-mounted digital touch screen provides easy access to all cooking functions, including preset programs, temperature, and time adjustments.

Setup and First Use

1. Unpack the appliance and all accessories. Remove any packaging materials, stickers, or labels.
2. Clean the cooking basket and grill plate thoroughly with hot water, some dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a moist cloth.
4. Place the appliance on a stable, horizontal, and level surface. Do not place the appliance on non-heat-resistant surfaces.
5. Insert the grill plate into the cooking basket.
6. Plug the appliance into a grounded wall outlet.

Product Overview Video

Your browser does not support the video tag.

This video provides a comprehensive overview of the T-fal Easy Fry & Grill XXL, demonstrating its features and components for initial setup.

Operating Instructions

Basic Operation

1. Place the food ingredients into the cooking basket. Do not overfill the basket.
2. Slide the cooking basket back into the appliance. Ensure it is fully inserted for the appliance to operate.
3. Press the power button to turn on the appliance.
4. Adjust the temperature and time using the up/down arrows on the touch screen.
5. Press the start button to begin cooking. The appliance will automatically pause if the basket is removed and resume when reinserted.

Using Preset Programs

The T-fal Easy Fry XXL comes with 8 convenient preset programs for common dishes:

- Fries
- Chops
- Shrimp
- Pizza
- Grilled Burgers
- Fish
- Chicken
- Cake

Simply select the desired program from the touch screen, and the appliance will automatically set the optimal temperature and time. You can manually adjust these settings if needed.



Prepare complete meals in minutes, such as roasted chicken with vegetables or grilled salmon with asparagus, thanks to the efficient cooking capabilities.



The XXL 5.9-quart capacity allows you to cook large quantities, such as a 5 lb. chicken or 4 quarter-pound burgers, making it perfect for feeding the whole family.

Cooking Guide

Air Frying Tips

- For best results, shake or toss smaller ingredients halfway through the cooking time.
- Lightly brush oil on fresh ingredients for extra crispiness.
- Do not overcrowd the basket to ensure even cooking and browning. Cook in batches if necessary.
- Use oven-safe dishes or molds in the basket for baking items like cakes or quiches.

Grilling Tips



Enjoy guilt-free frying and mess-free grilling with the T-fal Easy Fry XXL, which uses 99% less fat than traditional deep frying methods.

- Preheat the grill plate for a few minutes to achieve optimal searing.
- For perfect grill marks, ensure the food is placed directly on the grill plate.
- The cast-aluminum non-stick grill plate minimizes splatter, making indoor grilling cleaner.



Experience significantly less mess when grilling with the air fryer compared to traditional stovetop methods, as fat and residue collect neatly below the grill plate.

Maintenance and Cleaning

- Always unplug the appliance and allow it to cool down completely before cleaning.
- The cooking basket and grill plate are non-stick and can be easily cleaned with warm water and dish soap. Avoid abrasive cleaning materials.
- Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive cleaners.
- Ensure all parts are completely dry before storing or next use.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Food is not cooked evenly.	Basket is overcrowded.	Cook smaller batches or shake/toss ingredients more frequently.
Food is not crispy.	Not enough oil or incorrect temperature.	Lightly brush with oil or increase temperature/cooking time.
White smoke comes out of the appliance.	Grease from previous use or fatty ingredients.	Clean the basket and grill plate thoroughly. For fatty foods, ensure proper ventilation.

Specifications



The appliance's compact design, measuring 10.94"D x 13.31"W x 13.11"H, allows it to fit comfortably on most kitchen countertops.

Feature	Detail
Model Name	EY705D51
Brand	Tefal
Capacity	5.8 Liters (5.9 Quarts)
Product Dimensions	10.94"D x 13.31"W x 13.11"H
Item Weight	13 Pounds
Color	Black & Stainless Steel
Material	Stainless Steel
Output Wattage	1500 Watts
Voltage	110 Volts
Control Method	Touch
Special Feature	Programmable
Air Frying Technology	Air Pulse technology
Has Nonstick Coating	Yes
Is Dishwasher Safe	No

Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official T-fal website. Keep your proof of purchase for any warranty claims.

© 2024 T-fal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question