Disney LAS4027

Disney LAS4027 Smart Watch User Manual

Model: LAS4027 | Brand: Disney

Introduction

This manual provides essential information for the setup, operation, and maintenance of your Disney LAS4027 Smart Watch. Please read this manual thoroughly before using your device to ensure proper function and longevity.





Figure 1: Disney LAS4027 Smart Watch - Front View
This image displays the front of the Disney LAS4027 Smart Watch, featuring a light blue casing and strap with a Lilo & Stitch character on the digital watch face. The watch face shows an analog clock display with the character Stitch at the center.

Product Features

- **Touch Dial:** Intuitive touchscreen interface with Lilo & Stitch design themes.
- **Silicone Bracelet:** Durable and comfortable silicone strap featuring logo print.
- **Integrated Functions:** Includes a selfie camera, gaming capabilities, fitness tracker, alarm, stopwatch, timer, voice recorder, and calculator.



Figure 2: Smart Watch Features Overview
This image illustrates the various smart features of the Disney LAS4027 Smart Watch, including icons for camera, video recording, games, fitness tracking, time display, voice recording, and a calculator, all presented alongside the watch itself.

Setup

1. Initial Charging

Before first use, fully charge the smart watch. Connect the included USB cable to the watch's USB port and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status.

2. Powering On/Off

- **To Power On:** Press and hold the power button (usually on the side of the watch) until the screen illuminates.

- **To Power Off:** Press and hold the power button until a power-off option appears on the screen, then confirm.

3. Setting Time and Date

Navigate to the 'Settings' menu on the watch's touchscreen. Select 'Time' or 'Date & Time' to manually adjust the current time, date, and time format (12-hour or 24-hour). Some models may automatically sync time upon initial setup if connected to a device, though this model does not connect to a phone.

Operating Instructions

Navigation

The watch features a touchscreen interface. Swipe left or right to navigate between different applications and screens. Tap an icon to open an application. Swipe down from the top of the screen to access quick settings or notifications (if applicable).

Using Key Features

- **Camera:** Tap the camera icon to open the camera application. Tap the screen to take a photo. Photos are saved to the watch's internal storage.
- **Games:** Select the 'Games' icon to access pre-loaded games. Use the touchscreen to interact with the games.
- **Fitness Tracker:** The fitness tracker monitors steps taken. Access this feature to view daily step counts.
- **Alarm:** Set multiple alarms through the 'Alarm' application. You can customize alarm times and sounds.
- **Voice Recorder:** Use the 'Voice Recorder' to record short audio clips.
- **Calculator:** The 'Calculator' application provides basic arithmetic functions.





Figure 3: Smart Watch Side View and Strap Detail
This image provides a side view of the Disney LAS4027 Smart Watch, highlighting the light blue silicone strap adorned with multiple Stitch characters. The watch face displays an analog clock with a patterned background.

Maintenance and Care

- **Cleaning:** Wipe the watch screen and strap with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** This watch is not waterproof. Avoid exposing it to water, rain, or excessive moisture.
- **Storage:** Store the watch in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the watch regularly.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Watch does not power on.	Low battery; device frozen.	Charge the watch for at least 30 minutes. If still unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
Screen is unresponsive.	Software glitch; screen damage.	Restart the watch. Ensure the screen is clean and dry. If the issue persists, contact support.
Battery drains quickly.	Frequent use of features; old battery.	Reduce usage of power-intensive features like games or camera. Ensure the watch is fully charged. Battery life naturally degrades over time.

Specifications

Feature	Detail
Brand	Disney
Model	LAS4027
Operating System	Doesn't connect to phone
Compatible Devices	Smartphone (Note: Does not connect to phone for OS functions, but may be compatible for charging/data transfer)
Special Features	Alarms, Stopwatch, Selfie Camera, Gaming, Fitness Tracker, Timer, Voice Recorder, Calculator
Display Technology	LCD
Display Type	Digital
Power Source Type	Battery operated
Batteries Included	Yes (1 A battery required, included)
Battery Cell Composition	Lithium Ion
Wireless Standard	Bluetooth (for internal functions, not phone connectivity)
Connector Type	USB
Human Interface Input	Touchscreen
Rechargeable Battery	Yes
Color	Blue




SPEAKER
POWER
TOUCH SCREEN
USB
GAMES
VOICE RECORDER
CAMERA
TIMER
VIDEO RECORDER
ALARM
FITNESS TRACKER
CALCULATOR
5 DIGITAL CLOCK FACES
5 ANALOG CLOCK FACES
Disney
6+



Figure 4: Smart Watch Packaging and Feature Highlights
This image shows the retail packaging for the Disney LAS4027 Smart Watch, with the watch visible inside. The packaging highlights key features such as speaker, power button, USB port, games, voice recorder, timer, camera, video recorder, alarm, fitness tracker, calculator, and options for both digital and analog clock faces.

Warranty and Support

Information regarding product warranty and customer support was not provided in the available product data. Please refer to the product packaging or the manufacturer's official website for warranty details and support contact information.

Official Product Videos

No official product videos from the seller were found in the provided data for this model.

© 2023 Disney. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question