Dyson V8

Dyson V8 Origin+ Cordless Stick Vacuum Cleaner User Manual

Model: V8 | Brand: Dyson

Introduction

The Dyson V8 Origin+ Cordless Stick Vacuum Cleaner is engineered for powerful, versatile, and lightweight cleaning. Designed to tackle various surfaces and messes, it offers the convenience of cordless operation with strong suction capabilities. This manual provides essential information for setting up, operating, and maintaining your Dyson V8 Origin+ to ensure optimal performance.



Image: The Dyson V8 Origin+ Cordless Stick Vacuum Cleaner, showcasing its compact design and main components within its packaging.

Setup

1. Unpacking and Assembly

Carefully remove all components from the packaging. Your Dyson V8 Origin+ comes with various attachments designed for different cleaning tasks. Connect the desired cleaning head (e.g., the long wand for floor cleaning or the short head for handheld use) to the main unit until it clicks securely into place.

2. Initial Charging

Before first use, fully charge the vacuum cleaner. Connect the charger to the docking station (if wall-mounted) or directly to the vacuum's charging port. A full charge provides up to 40 minutes of run time. The battery indicator lights will show the charging status.

Operating Instructions

1. Powering On and Off

To operate the vacuum, press and hold the power trigger. Release the trigger to turn off the vacuum. The Dyson V8 Origin+ features two power modes: standard and MAX. Use the slider switch on the main unit to toggle between these modes. The MAX mode provides stronger suction for tougher messes but reduces battery life.

2. Using Attachments

The Dyson V8 Origin+ is highly versatile due to its range of attachments:

- **Short Head (Handheld Mode):** Ideal for quick clean-ups, upholstery, pet hair, and crumbs on surfaces like couches. Its lightweight design makes it easy to maneuver in tight spaces.
- **Long Wand with Cleaner Head:** Attach the long wand for floor cleaning. This configuration allows for easy vacuuming of large floor areas, including carpets, rugs, and hard floors (tile, wood). The cleaner head is designed to pivot, enabling you to reach under furniture and around obstacles with ease.
- **Crevice Tool:** Use this narrow attachment to clean tight gaps, corners, and edges, such as between couch cushions or along baseboards.
- **Combination Tool:** This tool features both a wide nozzle and a brush. Use the nozzle for general debris and extend the brush for dusting delicate surfaces or dislodging stubborn dirt.

Maintenance

1. Emptying the Dust Bin

To maintain optimal suction, empty the dust bin regularly, especially when debris reaches the "MAX" fill line. Hold the vacuum over a trash bin, then pull the red lever upwards to release the bin's base and empty the contents. Push the lever back down to close the bin securely.

2. Washing the Filter

The Dyson V8 Origin+ features a washable HEPA filter. For best performance, wash the filter at least once a month, or more frequently with heavy use. Twist the filter counter-clockwise to remove it from the top of the main unit. Rinse the filter under cold running water until the water runs clear. Squeeze out excess water and allow it to air dry completely for at least 24 hours before reinserting. Do not use detergents or place in a tumble dryer.

Troubleshooting

- **No Power/Short Run Time:** Ensure the battery is fully charged. Check the charging cable and power outlet. If the issue persists, the battery may need replacement.

- **Reduced Suction:** Empty the dust bin. Check for blockages in the cleaner head, wand, or main unit. Ensure the filter is clean and dry, and correctly reinserted.
- **Unusual Noises:** This often indicates a blockage. Turn off the vacuum and check all parts for obstructions. If a rotating brush is jammed, clear any tangled hair or debris.

Specifications

Feature	Detail
Brand	Dyson
Model Number	V8
Special Feature	Portable
Filter Type	HEPA Filter
Included Components	Brush
Cordless	Yes
Capacity	0.14 Gallons
Wattage	120 watts
Runtime	Up to 40 minutes
Recommended Uses	Carpet, Hard Floors
Form Factor	Stick
Color	Purple
Product Dimensions	9.8"L x 8.2"W x 49"H
Battery Type	Lithium-Ion
Noise Level	84 dB
Item Weight	5.72 pounds
UPC	679541319140

Warranty and Support

For detailed warranty information and customer support, please refer to the official Dyson website or contact Dyson customer service directly. Keep your proof of purchase for warranty claims. Dyson provides support for product registration, troubleshooting, and genuine spare parts.
Online Support: www.dyson.com/support
Phone Support: Refer to your region's Dyson website for local contact numbers.

© 2024 Dyson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question