Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

My Brand JCFA-201

Jordan Air Fryer 2.5L, 1200W Instruction Manual

Model: JCFA-201

Brand: My Brand

1. Introduction

Thank you for purchasing the Jordan Air Fryer. This appliance is designed to provide a healthier way to cook your favorite foods, using hot air circulation to fry, grill, bake, and roast with little to no oil. Please read this instruction manual carefully before using the appliance and keep it for future reference.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Always unplug the appliance from the power outlet when not in use and before cleaning. Allow it to cool down completely before handling.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Keep the appliance and its cord out of reach of children.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place the appliance against a wall or against other appliances. Leave at least 10 cm of free space on the back and sides and 10 cm of free space above the appliance.
- Hot air is released through the air outlet opening. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- The surfaces may become hot during use. Do not touch hot surfaces directly. Use handles or knobs.
- Do not use the appliance for any purpose other than described in this manual.

3. Product Components

Familiarize yourself with the parts of your Jordan Air Fryer:

- Main Unit Housing
- Temperature Control Knob
- Timer Knob
- Air Inlet
- Frying Basket with Handle
- Frying Pan (drawer)
- Air Outlet (at the back)



Figure 1: Jordan Air Fryer 2.5L, 1200W, model JCFA-201. This image displays the main unit, including the temperature and timer control knobs on the top and front, and the pull-out frying basket handle. The appliance is black and has a sleek, compact design, suitable for any kitchen counter.

4. Setup and First Use

1. **Unpacking:** Remove all packaging materials and stickers.
2. **Initial Cleaning:** Clean the frying basket and pan with hot water, dish soap, and a non-abrasive sponge. Wipe the inside and outside of the appliance with a damp cloth.
3. **Placement:** Place the appliance on a stable, horizontal, and heat-resistant surface. Ensure there is adequate ventilation around the unit.
4. **Pre-heating (First Use):** For the first use, it is recommended to run the air fryer empty for about 10 minutes at 200°C to burn off any manufacturing residues. A slight odor may be present, which is normal.

5. Operating Instructions

The Jordan Air Fryer features analog controls for easy operation.

1. **Prepare Food:** Place the food you wish to cook into the frying basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the frying pan with the basket back into the appliance.
3. **Set Temperature:** Turn the temperature control knob to your desired temperature (80-200°C).
4. **Set Timer:** Turn the timer knob to the required cooking time (0-30 minutes). The appliance will start heating.
5. **Cooking Process:** During cooking, the indicator light will illuminate. For some foods, you may need to shake the basket halfway through the cooking time to ensure even browning. To do this, pull out the pan by the cool-touch handle, shake the basket, and then slide it back in.
6. **Completion:** When the timer reaches zero, a bell sound will indicate that the cooking process is complete. Carefully pull out the pan and remove the cooked food.



Figure 2: The Jordan Air Fryer in use, with the basket containing french fries. This image illustrates the versatility of the appliance by showcasing various food items that can be prepared, such as pizza, roasted chicken, potato wedges, dried fruit, and fried shrimp, highlighting its multi-functional capabilities.

Cooking Guidelines (Approximate)

The following table provides general guidelines. Cooking times and temperatures may vary based on food quantity, size, and desired crispiness.

Food Item	Temperature	Time	Notes
French Fries (frozen)	200°C	15-20 min	Shake halfway
Chicken Wings	180°C	18-25 min	Turn halfway
Fish Fillet	160°C	10-15 min	
Vegetables (mixed)	180°C	10-15 min	Shake halfway

6. Maintenance and Cleaning

Regular cleaning will ensure optimal performance and extend the lifespan of your air fryer. Always unplug the appliance and allow it to cool completely before cleaning.

- **Frying Basket and Pan:** The frying basket and pan are easily removable and dishwasher-safe. For stubborn food residues, soak them in hot water with dish soap for about 10 minutes before cleaning.
- **Interior:** Wipe the interior of the appliance with a damp cloth. For any baked-on food, use a non-abrasive sponge. Do not use metal scouring pads or harsh abrasive cleaners.
- **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaning agents.
- **Heating Element:** Clean the heating element with a cleaning brush to remove any food residues.
- **Storage:** Ensure all parts are clean and dry before storing the appliance in a cool, dry place.

7. Troubleshooting

If you encounter any issues with your air fryer, please refer to the following table before contacting support.

Problem	Possible Cause	Solution
Appliance does not turn on.	The appliance is not plugged in.	Plug the main plug into an earthed wall socket.
	The timer is not set.	Turn the timer knob to the desired cooking time.
Food is not cooked evenly.	Too much food in the basket.	Reduce the amount of food in the basket.
	Food not shaken/turned.	Shake or turn food halfway through cooking.
White smoke comes from the appliance.	Fat residues from previous use.	Clean the frying pan and basket thoroughly after each use.
	Excess oil/fat on food.	Ensure food is not excessively oily. Pat dry if necessary.

8. Specifications

- **Model:** JCFA-201
- **Power:** 1200W
- **Capacity:** 2.5 Liters
- **Temperature Range:** 80°C - 200°C
- **Timer:** 0 - 30 minutes
- **Dimensions (Product):** 30 x 25 x 25 cm
- **Weight (Item):** 2.74 kg
- **Motor:** 100% Copper
- **Special Feature:** Oil-free frying

9. Warranty and Support

This Jordan Air Fryer comes with a**2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
For technical support, service, or warranty inquiries, please contact your retailer or the manufacturer's customer service. Contact details can typically be found on the product packaging or the retailer's website.

© 2024 My Brand. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09B2HPN4W

More documents and user manuals: **https://manuals.plus/**