**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Ariete 1829

# Ariete Chopper Instruction Manual

**Model: 1829**

## 1. Introduction

Thank you for purchasing the Ariete Chopper Model 1829. This appliance is designed to simplify your food preparation tasks, offering efficient chopping and slicing. Please read this instruction manual carefully before using the appliance for the first time to ensure safe and optimal operation. Keep this manual for future reference.

## 2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons.

- Read all instructions before use.
- Do not immerse the motor unit in water or other liquids.
- Keep hands and utensils away from the moving blades during operation to prevent injury.
- Ensure the appliance is unplugged before assembling, disassembling, or cleaning.
- This appliance is not intended for use by children or persons with reduced physical, sensory, or mental capabilities unless supervised.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Avoid contact with moving parts.

## 3. Product Overview and Components

The Ariete Chopper Model 1829 consists of the following main components:

- **Motor Unit:** The top section containing the 400-watt motor and control button.
- **Lid:** Connects the motor unit to the chopping bowl.
- **Chopping Blade:** Sharp blades for processing food. Handle with care.
- **Chopping Bowl:** Transparent container for food processing.
- **Anti-slip Base:** Provides stability during operation.




Image 1: Ariete Chopper Model 1829. A hand is shown pressing the orange top button of the white motor unit, which is assembled on top of the clear chopping bowl with blades visible inside. The base is also orange.

## 4. Setup and Assembly

Before first use, wash all parts that will come into contact with food (chopping bowl, lid, and blades) in warm soapy water, then rinse and dry thoroughly. The motor unit should only be wiped with a damp cloth.

1. Place the anti-slip base on a clean, dry, and stable surface.
2. Carefully place the chopping blade onto the central pin inside the chopping bowl. Ensure it is securely seated.
3. Add the food ingredients you wish to chop into the chopping bowl. Do not overfill.
4. Place the lid onto the chopping bowl, ensuring it is properly aligned and locked into place.
5. Position the motor unit onto the lid, aligning the grooves.
6. Plug the appliance into a suitable power outlet.

## 5. Operating Instructions

To operate the Ariete Chopper:

1. Ensure the appliance is correctly assembled and plugged in.
2. Press down firmly on the top of the motor unit to activate the chopping blades.
3. Use short, pulsing actions for coarse chopping, or hold down for a few seconds for finer results. Do not operate continuously for more than 30 seconds. Allow the motor to rest between cycles.
4. Monitor the consistency of the food through the transparent bowl.
5. Release pressure from the motor unit to stop the blades.
6. Unplug the appliance from the power outlet before disassembling.
7. Carefully remove the motor unit, then the lid, and finally the chopping blade before emptying the contents.

## 6. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your Ariete Chopper.

- Always unplug the appliance before cleaning.
- **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse in water.
- **Chopping Bowl, Lid, and Blades:** These parts are dishwasher safe. Alternatively, wash them in warm soapy water, rinse thoroughly, and dry immediately. Handle blades with extreme care as they are very sharp.
- Do not use abrasive cleaning agents or scouring pads, as these may scratch the surfaces.
- Store the appliance in a dry place, away from direct sunlight and out of reach of children.

## 7. Troubleshooting

| Problem | Possible Cause | Solution |
|---|---|---|
| Appliance does not start. | Not plugged in; motor unit not correctly assembled; safety switch not engaged. | Check power connection; ensure motor unit is properly seated on the lid; ensure lid is locked onto the bowl. |
| Blades are not chopping effectively. | Bowl is overfilled; ingredients are too large or hard; blades are dull. | Reduce food quantity; cut ingredients into smaller pieces; contact customer support if blades are dull. |
| Motor stops during operation. | Overheating due to continuous use; food jammed. | Unplug and let cool for 15-20 minutes; clear any jammed food and reduce load. |

## 8. Specifications

- **Model Number:** 1829
- **Brand:** Ariete
- **Power:** 400 Watts
- **Voltage:** 240 Volts
- **Material:** Plastic (body), Stainless Steel (blades)
- **Item Weight:** Approximately 500 g
- **Special Features:** Multipurpose
- **Product Care:** Hand Wash (motor unit), Dishwasher Safe (bowl, lid, blades)

## 9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your purchase or visit the official Ariete website. Do not attempt to repair the appliance yourself; contact authorized service personnel for assistance.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

**Open the live page**

**https://manuals.plus/asin/B09BDNMX9W**

More documents and user manuals: **https://manuals.plus/**