Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aigostar 213732

Aigostar Wireless Doorbell Instruction Manual

Model: 213732

Product Overview

The Aigostar Wireless Doorbell provides a reliable and convenient solution for your home or office. This innovative doorbell features a self-powered transmitter, eliminating the need for batteries, and a waterproof design for outdoor durability. With 36 selectable melodies and 3 adjustable volume levels, it offers customization to suit your preferences. Its strong signal penetration ensures a wide operating range of up to 150 meters, making it suitable for various environments. Key features include:

- **Self-Powered Transmitter:** No batteries required for the outdoor button.
- **Waterproof Design:** Built to withstand rain and temperature changes.
- **Wide Operating Range:** Up to 150 meters (500 feet) in open areas.
- **Customizable Chimes:** Choose from 36 different melodies.
- **Adjustable Volume:** 3 levels of volume control.
- **Easy Installation:** Quick setup with double-sided tape or screws.



Image: The self-powered wireless doorbell, emphasizing its battery-free operation, long lifespan, and waterproof capabilities.

Product Components

The Aigostar Wireless Doorbell package includes the following components:

- 1 x Self-Powered Transmitter (Outdoor Unit)
- 1 x Plug-in Receiver (Indoor Unit)
- Mounting Hardware (Double-sided adhesive tape, Screws, Wall anchors)
- User Manual (This document)



Image: The Aigostar wireless doorbell set, showing the self-powered transmitter and the plug-in receiver.



Image: Detailed dimensions of both the transmitter and receiver units, indicating their compact size.

Installation Guide

Receiver Installation:

1. Identify a suitable indoor power outlet within range of your desired transmitter location.
2. Plug the receiver directly into the power outlet. Ensure it is securely seated.
3. The receiver is now powered and ready to pair with the transmitter.



Image: Side view of the plug-in receiver, highlighting the chime selection and volume control buttons.

Transmitter Installation (Outdoor Unit):

The transmitter can be installed using either the provided double-sided adhesive tape or screws.

Method 1: Using Double-Sided Adhesive Tape

1. Clean the surface where you intend to mount the transmitter. Ensure it is dry and free of dust or debris.
2. Tear off the protective film from one side of the double-sided adhesive tape.
3. Attach this side of the tape firmly to the back of the transmitter.
4. Tear off the protective film from the other side of the tape.
5. Press the transmitter firmly onto the desired mounting surface (e.g., door frame, wall) for at least 30 seconds to ensure strong adhesion.

Method 2: Using Screws

1. Use a screwdriver to gently pry open the back cover of the transmitter.
2. Mark the desired drilling points on the wall using the holes on the back cover as a guide.
3. Drill holes at the marked points and insert the wall anchors (if necessary for your wall type).
4. Align the back cover with the drilled holes and secure it to the wall using the provided screws.
5. Once the back cover is securely mounted, align the main body of the transmitter with the back cover and push it firmly until it clicks into place.



Image: Visual guide demonstrating both double-sided tape and screw installation methods for the doorbell transmitter.

Note: The transmitter is self-powered and does not require batteries or external wiring. Ensure the mounting location is within the effective range of the receiver.

Operating Instructions

Pairing the Transmitter and Receiver:

The doorbell set usually comes pre-paired. If re-pairing is needed or if you add additional transmitters/receivers:

1. Plug the receiver into a power outlet.
2. Press and hold the volume button on the receiver for approximately 5 seconds until you hear a "ding" sound and the LED indicator flashes. This indicates it's in pairing mode.
3. Immediately press the transmitter button once. The receiver will chime, confirming successful pairing.

4. Test the doorbell by pressing the transmitter button. The receiver should chime.

Changing Melodies:

The receiver offers 36 different melodies to choose from.

- Press the "Chime Selection" button (usually indicated by a music note icon) on the side of the receiver to cycle through the available melodies.
- Once you find a melody you like, stop pressing the button. The selected melody will be saved.

Adjusting Volume:

The receiver has 3 adjustable volume levels.

- Press the "Volume Control" button (usually indicated by a speaker icon) on the side of the receiver to cycle through the volume levels (High, Medium, Low).
- Select the desired volume level.



Image: Depiction of the doorbell in action, showing a delivery person pressing the outdoor unit and the indoor receiver chiming.



Image: Examples of suitable environments for the doorbell, including home, office, hospital, hotel, classroom, and yard.

Maintenance

- **Cleaning:** Wipe the doorbell units with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Transmitter:** As the transmitter is self-powered, no battery replacement is needed. Ensure the button mechanism remains free of debris for optimal performance.
- **Receiver:** Keep the receiver plugged into a dry, indoor power outlet.
- **Environmental Conditions:** While the transmitter is waterproof, extreme weather conditions (e.g., prolonged submersion, direct high-pressure water jets) should be avoided.
- **Signal Interference:** If you experience signal issues, ensure the receiver is not placed near large metal objects or

other devices that may cause electromagnetic interference.

Troubleshooting

Problem	Possible Cause	Solution
Doorbell does not ring.	• Receiver not plugged in or powered. • Transmitter and receiver are not paired. • Distance between units is too far or too many obstacles. • Transmitter button is stuck or damaged.	• Ensure receiver is securely plugged into a working outlet. • Re-pair the transmitter and receiver (refer to "Pairing" section). • Reduce the distance or remove obstacles (e.g., thick walls, metal structures). • Check the transmitter button for free movement.
Short operating range.	• Excessive interference from other electronic devices. • Thick walls or metal structures blocking the signal.	• Relocate the receiver away from potential sources of interference. • Try repositioning the receiver or transmitter to minimize signal obstruction.
Receiver LED flashes but no sound.	• Volume is set to minimum or muted.	• Press the "Volume Control" button to increase the volume.

Technical Specifications

Brand:	Aigostar
Model Number:	213732
Color:	Black
Product Dimensions:	10 x 10 x 10 cm (approximate)
Item Weight:	130 grams
Power Source (Transmitter):	Self-powered (Kinetic energy)
Power Source (Receiver):	AC Plug-in
Operating Range:	Up to 150 meters (500 feet) in open areas

Melodies:	36 selectable chimes
Volume Levels:	3 adjustable levels
Waterproof Rating (Transmitter):	Yes (designed for outdoor use)
Batteries Included:	No
Country of Origin:	China



Image: Illustration showing the doorbell's wide operating range of 150 meters (500 feet).



Image: Graphic indicating the doorbell's temperature resistance from -20°C (-4°F) to 60°C (140°F).



Image: Visual representation of musical notes, symbolizing the 36 available melodies.

Warranty and Support

For warranty information and customer support, please refer to the official Aigostar website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.
Online Support: Visit the Aigostar Store on Amazon for more product information and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I pair the transmitter with the responder for the Aigostar 213732 wireless doorbell?

If your Aigostar 213732 transmitter is not pairing with the receiver, please follow these specific steps to reset the connection: Enter Pairing Mode: Plug the receiver into a power outlet. Press and hold the...

Read full answer

Open the live page

https://manuals.plus/asin/B09BJNDB3T

More documents and user manuals: **https://manuals.plus/**