Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Vpcok Direct DE5666

Vpcok Direct DE5666 Multifunction Electric Food Chopper User Manual

Model: DE5666 | Brand: Vpcok Direct

Introduction

The Vpcok Direct DE5666 Multifunction Electric Food Chopper is designed for efficient food preparation in your kitchen. This appliance features a powerful 400W motor, a 1.2L stainless steel bowl, and four sharp stainless steel blades, making it suitable for chopping, mixing, and blending various ingredients. This manual provides essential information for safe and effective use, maintenance, and troubleshooting.



Image: The Vpcok Direct DE5666 Multifunction Electric Food Chopper, showcasing its compact design and stainless steel bowl, surrounded by fresh ingredients.

Product Overview

The Vpcok Direct DE5666 food chopper is equipped with features designed for convenience and performance:

- **Powerful 400W Motor:** Ensures quick and uniform chopping of ingredients.
- **1.2L Stainless Steel Bowl:** Durable, resistant to scratches and corrosion, and dishwasher safe. Allows processing of larger quantities.
- **4 Stainless Steel Blades:** Designed for efficient and fast processing, outperforming two-blade systems.
- **Overheat Protection:** Safeguards the motor from high-temperature damage.
- **Anti-slip Mat:** Provides stability during operation.
- **Transparent Top Cover:** Allows monitoring of the chopping process.

Components

The package includes the following components:

- Motor Unit
- Transparent Lid
- 4-Blade Assembly
- 1.2L Stainless Steel Bowl
- Anti-slip Rubber Mat
- Scraper



Image: An exploded diagram showing the motor unit, transparent lid, 4-blade assembly, stainless steel bowl, anti-slip mat, and scraper.

Setup

Follow these steps to set up your food chopper for first use:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the stainless steel bowl, blade assembly, and lid with warm, soapy water before first use. Rinse thoroughly and dry.
3. **Position:** Place the anti-slip rubber mat on a clean, dry, and stable surface.
4. **Assemble Bowl:** Place the stainless steel bowl onto the anti-slip mat.
5. **Insert Blades:** Carefully place the 4-blade assembly onto the central shaft inside the bowl. Handle blades with care as they are sharp.
6. **Add Ingredients:** Place your desired ingredients into the bowl. Do not exceed the MAX fill line. For solid ingredients, cut them into smaller pieces (e.g., carrots, meat) to prevent jamming.
7. **Secure Lid:** Place the transparent lid onto the bowl, ensuring it is properly aligned and secured.
8. **Attach Motor Unit:** Position the motor unit onto the lid, aligning it correctly.



Image: A visual guide demonstrating the assembly process: 1) Install blade shaft, 2) Add ingredients, 3) Mount motor unit, 4) Start operation.

Operating Instructions

To operate your Vpcok Direct DE5666 food chopper, follow these steps:

1. **Connect Power:** Plug the appliance into a suitable power outlet.
2. **Select Speed:** The appliance features two speed modes for different ingredient types.
    - **Mode I (Soft Ingredients):** Suitable for parsley, fruits, garlic, peppers, lettuce, chili.
    - **Mode II (Solid Ingredients):** Suitable for meat, carrots, pumpkin, nuts, potatoes.
3. **Start Operation:** Press and hold the power button on the top of the motor unit to begin chopping.
4. **Monitor Process:** Use the transparent lid to observe the chopping process. Release the button once the desired consistency is achieved.
5. **Pulse Function:** For coarse chopping or to control consistency, use short pulses by pressing and releasing the button repeatedly.
6. **Safety Feature:** The appliance is designed with overheat protection. If the motor overheats, it will automatically shut off. Allow it to cool down before resuming operation.
7. **After Use:** Unplug the appliance from the power outlet before disassembling or cleaning.



Image: A diagram illustrating recommended ingredients for Speed Mode I (soft) and Speed Mode II (solid), such as onions, tomatoes, lettuce, chili for soft, and carrots, meat, nuts, potatoes for solid.

Official Product Videos

How to Use the Product

Video: A demonstration of the Vpcok Direct food chopper in use, showing its assembly and operation for various ingredients.

Multifunctional Blender for Meat and Vegetables

Video: This video illustrates the versatility of the food chopper, demonstrating its use for both meat and vegetables to achieve different consistencies.

Maintenance and Cleaning

Proper maintenance ensures the longevity and hygiene of your food chopper:

1. **Disassembly:** Carefully remove the motor unit, then the lid, and finally the blade assembly from the bowl.
2. **Blade Care:** Handle the blades with extreme caution due to their sharpness.
3. **Washing:** The stainless steel bowl, blade assembly, and lid are dishwasher safe. Alternatively, wash these parts with warm, soapy water, rinse thoroughly, and dry immediately.
4. **Motor Unit:** Wipe the motor unit with a damp cloth. Never immerse the motor unit in water or any other liquid.
5. **Storage:** Ensure all parts are completely dry before storing. Store the appliance in a cool, dry place.



Image: Visual representation of cleaning the food chopper, showing the bowl being rinsed and then placed in a dishwasher for convenience.

Troubleshooting

If you encounter any issues with your food chopper, refer to the following troubleshooting guide:

- **Appliance does not turn on:**
  - Check if the power cord is securely plugged into the outlet.
  - Ensure the motor unit, lid, and bowl are correctly assembled and locked into place.
  - The overheat protection might be activated. Unplug the appliance and let it cool down for at least 30 minutes before trying again.
- **Blades are not chopping effectively:**
  - Ensure ingredients are cut into appropriate sizes, especially hard items.
  - Do not overfill the bowl beyond the MAX line.
  - Check if the blade assembly is correctly seated on the central shaft.
- **Motor sounds strained:**
  - This may indicate that the bowl is overfilled or the ingredients are too hard. Reduce the quantity or cut ingredients into smaller pieces.
  - Switch to a higher speed mode if available and appropriate for the ingredients.

Specifications

Feature	Specification
Brand	Vpcok Direct
Model Number	DE5666
Power	400W
Bowl Capacity	1.2 Liters
Bowl Material	Stainless Steel
Blade Material	Stainless Steel (4 blades)
Dimensions	16.5 x 16.5 x 24 cm
Weight	1.3 kg
Power Source	Electric (corded)
Special Features	Automatic shut-off (overheat protection)
Dishwasher Safe Parts	Bowl, blade assembly, lid

Warranty and Support

Your Vpcok Direct DE5666 Multifunction Electric Food Chopper is covered by a **2-year warranty** from the date of purchase.

For any questions, technical assistance, or warranty claims, please contact our customer service. Ensure you have your purchase receipt and product model number available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09BV83TGD

More documents and user manuals: **https://manuals.plus/**