Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mondaine A995.CLOCK.17SBV

Mondaine A995.CLOCK.17SBV Swiss Railways Wall Clock Instruction Manual

Model: A995.CLOCK.17SBV

Introduction

This manual provides essential information for the setup, operation, and maintenance of your Mondaine A995.CLOCK.17SBV Swiss Railways Wall Clock. Designed with the iconic Swiss station clock aesthetic, this 40cm aluminum quartz clock is a dust-resistant timepiece suitable for various indoor environments.

Product Overview

The Mondaine A995.CLOCK.17SBV is a 40cm diameter wall clock featuring a silver aluminum case, a white dial, and the distinctive red second hand. It operates on a quartz movement, ensuring accurate timekeeping.



Image: Front view of the Mondaine A995.CLOCK.17SBV Swiss Railways Wall Clock, showcasing its white dial, black hour and minute hands, and the iconic red second hand with a circular tip.



Image: Rear view of the Mondaine A995.CLOCK.17SBV Swiss Railways Wall Clock, showing the battery compartment, time setting knob, and wall mounting hook.

Setup

1. Unpacking

Carefully remove the clock from its packaging. Inspect for any visible damage. Retain packaging for future transport or storage.

2. Battery Installation

1. Locate the battery compartment on the back of the clock.

2. Open the battery compartment cover.
3. Insert two (2) AA batteries, ensuring correct polarity (+/-). The clock requires 2 AA batteries, which are included.
4. Close the battery compartment cover securely.

3. Mounting the Clock

1. Choose a suitable indoor location for wall mounting. Ensure the surface can support the clock's weight (approximately 1050g).
2. Install a sturdy screw or hook into the wall at the desired height.
3. Hang the clock using the integrated mounting hook on the back.

Operating Instructions

Setting the Time

1. Locate the time-setting knob on the back of the clock, typically near the battery compartment.
2. Gently turn the knob clockwise or counter-clockwise to adjust the hour and minute hands to the correct time.
3. The red second hand will begin to move once the batteries are correctly installed and the time is set.

Maintenance

Cleaning

- To clean the clock, wipe the aluminum case and glass with a soft, dry, lint-free cloth.
- Avoid using abrasive cleaners, solvents, or chemical sprays, as these may damage the finish or internal components.

Battery Replacement

- When the clock's movement becomes erratic or stops, it is time to replace the batteries.
- Follow the battery installation steps (Section 2.2) to replace the two (2) AA batteries.
- Dispose of used batteries responsibly according to local regulations.

Troubleshooting

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly installed batteries.	Check battery polarity. Replace with fresh AA batteries.
Incorrect time displayed	Time not set correctly.	Adjust the time using the setting knob on the back.
Erratic second hand movement	Low battery power.	Replace batteries with new ones.

Specifications

- **Model:** A995.CLOCK.17SBV
- **Brand:** Mondaine
- **Movement:** UTS 800.374 Quartz
- **Case Material:** Aluminum

- **Case Back:** Screwed
- **Glass:** Hardened Mineral Glass
- **Diameter:** 40 cm (15.75 inches)
- **Weight:** 1050 g
- **Power Source:** Battery Powered (2 AA batteries, included)
- **Water Resistance:** Dust Resistant
- **Display Type:** Analog
- **Special Feature:** Red second hand
- **Indoor/Outdoor Usage:** Indoor

Warranty

This Mondaine clock is covered by a manufacturer's warranty. Please refer to the warranty card included with your product or visit the official Mondaine website for detailed warranty terms and conditions.

Support

For further assistance, technical support, or inquiries regarding your Mondaine A995.CLOCK.17SBV Swiss Railways Wall Clock, please visit the official Mondaine website or contact their customer service department. Contact information can typically be found on the manufacturer's website or in the product packaging.

Mondaine Official Website: www.mondaine.com

© 2023 Mondaine. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09C5WNV6G

More documents and user manuals: **https://manuals.plus/**