Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

De'Longhi ECAM292.33.SB

De'Longhi Magnifica Evo ECAM292.33.SB Automatic Coffee Machine User Manual

Model: ECAM292.33.SB

Introduction

This manual provides comprehensive instructions for the safe and efficient operation, maintenance, and troubleshooting of your De'Longhi Magnifica Evo ECAM292.33.SB automatic coffee machine. Please read all instructions carefully before using the appliance and retain this manual for future reference.
The De'Longhi Magnifica Evo ECAM292.33.SB is designed to deliver a variety of coffee beverages from freshly ground beans, including espresso and cappuccino, with ease and precision. It features an intuitive control panel, an integrated grinder with 13 settings, and a manual milk frother for customized milk-based drinks.

Important Safety Instructions

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock, and personal injury, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or personal injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended household use.

Setup

1. Unpacking the Machine

Carefully remove the coffee machine from its packaging. Ensure all components are present: the machine, drip tray, water tank, coffee grounds container, and power cord. Remove any protective films or packaging materials.



Image: The De'Longhi Magnifica Evo ECAM292.33.SB coffee machine, showcasing its sleek silver design, control panel, and two freshly brewed espressos, alongside a glass of frothed milk.

2. Initial Cleaning and Assembly

- Wash the water tank, drip tray, and coffee grounds container with warm water and mild detergent. Rinse thoroughly and dry.
- Insert the drip tray and coffee grounds container back into the machine.
- Fill the water tank with fresh, cold water up to the MAX level and insert it into the machine.

3. Adding Coffee Beans

Open the coffee bean lid on top of the machine. Pour fresh coffee beans into the hopper. Do not overfill. Ensure no foreign objects are present in the bean hopper.



Image: A close-up view of a hand adjusting the grind setting dial located within the coffee bean hopper, illustrating the machine's 13 adjustable grind settings.

4. First Use and Priming

- Plug the machine into a grounded power outlet.
- Turn on the machine using the power button. The machine will perform an automatic rinsing cycle. Place a container under the coffee spouts to collect the water.
- Follow any on-screen prompts or indicator lights for initial setup, such as water hardness settings.

Operating Instructions

1. Control Panel Overview

The Magnifica Evo features an intuitive soft-touch control panel with color icons for easy selection of beverages and functions.



Image: A detailed view of the machine's soft-touch control panel, highlighting the illuminated icons for various coffee selections like Espresso, Coffee, and Long, demonstrating its user-friendly interface.

- **Power Button:** Turns the machine on/off.
- **Beverage Selection Icons:** Directly select Espresso, Coffee, Long, Americano, and other pre-programmed drinks.

- **Steam Button:** Activates the manual milk frother.
- **My Latte Function:** Allows customization of milk-based drinks.

2. Making Coffee (from beans)

1. Ensure the water tank is filled and the bean hopper contains coffee beans.
2. Place one or two cups under the coffee spouts.
3. Select your desired beverage (e.g., Espresso, Coffee) by touching the corresponding icon. The machine will automatically grind the beans and brew the coffee.
4. To adjust the aroma intensity, press the aroma button before selecting the drink.

3. Using Pre-Ground Coffee

This machine also allows the use of pre-ground coffee for a single serving.

1. Press the pre-ground coffee button (usually indicated by a spoon icon).
2. Open the pre-ground coffee funnel and add one level scoop of pre-ground coffee. Do not add more than one scoop.
3. Place a cup under the coffee spouts and select your desired beverage.

4. Using the Manual Milk Frother

The manual milk frother allows you to prepare creamy milk foam for cappuccinos and lattes, or dispense hot water for teas.



Image: A hand holding a stainless steel milk pitcher positioned under the traditional steam wand, demonstrating the preparation of frothed milk.

1. Fill a pitcher with cold milk (dairy or plant-based).
2. Press the Steam button on the control panel. Wait for the indicator light to become steady.
3. Submerge the steam wand into the milk and turn the steam knob to release steam. Move the pitcher up and down to create foam.
4. Once desired foam is achieved, turn off the steam knob and clean the wand immediately.
5. For hot water, place a cup under the steam wand and turn the steam knob.

Genießen Sie einzigartige Rezepte auf Knopfdruck



Image: A display of various coffee beverages, including espresso, long coffee, and milk-based drinks, illustrating the machine's capability to prepare multiple recipes.

Maintenance

Regular maintenance ensures optimal performance and longevity of your coffee machine. The Magnifica Evo features automatic cleaning functions and dishwasher-safe components for convenience.

1. Daily Cleaning

- **Drip Tray and Coffee Grounds Container:** Empty and rinse daily. These components are dishwasher-safe.
- **Coffee Spouts:** Wipe with a damp cloth.
- **Water Tank:** Rinse daily and refill with fresh water.

2. Cleaning the Manual Milk Frother

After each use, clean the steam wand to prevent milk residue buildup.

1. Wipe the outside of the steam wand with a damp cloth.
2. Briefly release steam to clear any internal milk residue.
3. If the nozzle is blocked, use the cleaning tool provided to clear the hole.

3. Cleaning the Brewing Unit

The brewing unit should be rinsed regularly (at least once a month) under running water.

1. Turn off and unplug the machine.
2. Open the service door (usually on the side or front).
3. Press the two red release buttons and pull the brewing unit out.
4. Rinse thoroughly under running tap water. Do not use detergents.
5. Allow it to air dry completely before reinserting.

4. Descaling

The machine will indicate when descaling is required. Use only De'Longhi descaler solution.

1. Empty the water tank and coffee grounds container.
2. Pour the descaler solution into the water tank, then fill with water up to the indicated level.
3. Place a large container (at least 1.5L) under the coffee spouts and steam wand.
4. Follow the instructions on the machine's display or in the full user manual for the specific descaling cycle.
5. After descaling, perform several rinsing cycles with fresh water.

Troubleshooting

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty; brewing unit blocked; coffee spouts blocked.	Fill water tank; clean brewing unit; clean coffee spouts.
Coffee is too weak.	Grind setting too coarse; insufficient coffee dose; old coffee beans.	Adjust grind to finer setting; increase coffee dose (if adjustable); use fresh coffee beans.
Machine leaks water.	Water tank not correctly inserted; drip tray full; internal component issue.	Ensure water tank is fully seated; empty drip tray; contact customer support if issue persists.
Milk frother not producing foam.	Steam wand blocked; milk not cold enough; incorrect milk type.	Clean steam wand; use cold milk; try different milk type.
"Descaling" light is on.	Machine requires descaling.	Perform the descaling procedure as described in the Maintenance section.

For more detailed troubleshooting, please refer to the complete user manual available on the De'Longhi website or contact customer support.

Specifications

Brand	De'Longhi

Model Number	ECAM292.33.SB
Color	Silver
Dimensions (L x W x H)	24 x 43.99 x 35.99 cm
Capacity	1.8 Liters
Power	1450 Watts
Voltage	230 Volts
Material	Plastic
Auto-off Function	Yes
Special Features	Manual Milk Frother
Item Weight	11.7 Kilograms
Spare Parts Availability	10 Years
Country of Origin	Romania



Image: A diagram illustrating the physical dimensions of the De'Longhi Magnifica Evo coffee machine, with measurements for width (240mm), depth (440mm), and height (360mm).

Warranty and Support

Your De'Longhi Magnifica Evo ECAM292.33.SB coffee machine comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage. For technical assistance, spare parts, or to locate an authorized service center, please visit the official De'Longhi website or contact their customer support directly. Keep your proof of purchase handy when seeking support.
Spare parts are available for up to 10 years from the date of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CGSCBK5

More documents and user manuals: **https://manuals.plus/**