Daewoo DWTT11M2NUFW

Daewoo DWTT11M2NUFW Twin Tub Washing Machine User Manual

Model: DWTT11M2NUFW | Brand: Daewoo

1. Introduction

Thank you for choosing the Daewoo DWTT11M2NUFW Twin Tub Washing Machine. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read this manual thoroughly before using the washing machine and keep it for future reference.

This twin tub washing machine is designed for household use, offering a washing capacity of 11 kg and a spin capacity of 7.8 kg. It features two independent motors for simultaneous washing and spinning, along with multiple wash cycles to suit various fabric types.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Ensure the washing machine is connected to a properly grounded power outlet.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the machine during operation.
- Do not wash waterproof materials as this may cause abnormal vibration.
- Unplug the machine before cleaning or performing any maintenance.
- Do not immerse the electrical parts in water.
- Ensure the spin tub lid is closed before starting the spin cycle.

3. Product Overview and Components

Familiarize yourself with the different parts of your Daewoo twin tub washing machine.



Figure 3.1: Front view of the washing machine, showing the white cabinet and black top with control knobs.



Figure 3.2: Angled view of the washing machine, highlighting its compact design.



Figure 3.3: Side view showing the corrugated drain hose attached to the unit.



Figure 3.4: Top view with the wash tub and spin tub lids open, showing the pulsator in the wash tub.



Figure 3.5: Close-up of the removable lint filter located inside the wash tub.

Key Components:

- **Wash Tub:** For washing clothes with water and detergent. Features a pulsator for effective cleaning.
- **Spin Tub:** For spinning clothes to remove excess water.
- **Control Panel:** Includes knobs for wash timer, wash type, drain/rinse selector, and spin timer.
- **Water Inlets:** Two inlets for filling water into the wash tub.
- **Drain Hose:** For gravity drainage of water.
- **Lint Filter:** Collects lint during the wash cycle for easy cleaning.

4. Setup and Installation

Proper setup ensures optimal performance and safety of your washing machine.

4.1 Unpacking

Carefully remove all packaging materials. Inspect the machine for any damage incurred during transit. Keep packaging materials away from children.

4.2 Placement

Place the washing machine on a firm, level surface to prevent vibration and noise. Ensure there is adequate space around the machine for ventilation and operation. The dimensions of the product are approximately 43.18 cm (depth) x 73.66 cm (width) x 86.36 cm (height).



Figure 4.1: Product dimensions for placement planning.

4.3 Electrical Connection

Connect the power cord to a standard electrical outlet. The machine operates at 1 Volt (as per specifications, though this seems unusually low for a washing machine and might be a data error, users should verify local voltage requirements). Ensure the outlet is properly grounded.

4.4 Water Supply

Connect the water supply hoses to the two water inlets on the machine and to your household water taps. Ensure connections are tight to prevent leaks.

4.5 Drainage

This model features gravity drainage. Position the drain hose to allow water to flow freely into a floor drain or a utility sink. Ensure the hose is not kinked or blocked. Note that this model does not have an automatic drain pump.

5. Operating Instructions

Follow these steps for effective washing and spinning.

5.1 Preparing Laundry

- Sort clothes by fabric type, color, and degree of soiling.
- Empty pockets and close zippers.
- For heavily soiled items, pre-soak if necessary.

5.2 Washing Process

1. **Load Clothes:** Place sorted laundry into the wash tub. Do not overload; ensure clothes can move freely.
2. **Add Water:** Fill the wash tub with water to the desired level. The machine has a 3-level water indicator.
3. **Add Detergent:** Add the appropriate amount of detergent. This model includes a softener dispenser.
4. **Select Wash Cycle:** Choose between "Normal" and "Fuerte" (Strong) cycles using the wash type knob.
5. **Set Wash Timer:** Turn the wash timer knob to set the desired washing time, up to 15 minutes.
6. **Start Washing:** The machine will begin washing.
7. **Drain Water:** Once the wash cycle is complete, set the drain/rinse selector to "Desagüe" (Drain) to empty the water via gravity.
8. **Rinse (Manual):** After draining, refill the tub with clean water for rinsing. You may agitate briefly or perform a manual rinse cycle.

5.3 Spinning Process

1. **Transfer Clothes:** Carefully transfer the washed and rinsed clothes from the wash tub to the spin tub. Distribute them evenly.
2. **Close Lid:** Ensure the spin tub lid is securely closed.
3. **Set Spin Timer:** Turn the spin timer knob to set the desired spinning time, up to 5 minutes for Express spin.
4. **Start Spinning:** The spin cycle will begin.
5. **Remove Clothes:** Once the spin cycle is complete, the machine will sound an alarm. Open the lid and carefully remove the spun clothes.

6. Maintenance and Care

Regular maintenance helps prolong the life of your washing machine.

6.1 Cleaning the Lint Filter

The lint filter should be cleaned after every few washes to ensure efficient operation. It is easily removable for cleaning.

1. Remove the lint filter from the wash tub.

2. Open the filter and remove any accumulated lint.
3. Rinse the filter under running water.
4. Reinsert the clean filter into its position in the wash tub.

6.2 Cleaning the Exterior

Wipe the exterior cabinet with a soft, damp cloth. Do not use abrasive cleaners or solvents that could damage the polypropylene cabinet.

6.3 Winterization (if applicable)

If the machine is stored in an area where temperatures may drop below freezing, drain all water from the hoses and tubs to prevent damage from freezing.

7. Troubleshooting

This section provides solutions to common issues you might encounter.

Problem	Possible Cause	Solution
Machine does not start	Not plugged in; power outage; lid not closed (spin tub).	Check power connection; check circuit breaker; ensure lids are properly closed.
Water does not drain	Drain hose kinked or blocked; drain hose not positioned correctly for gravity drain.	Straighten drain hose; ensure drain hose is lower than the machine's base and positioned over a drain.
Excessive vibration/noise during spin	Clothes unevenly distributed in spin tub; machine not level.	Rearrange clothes evenly; adjust machine's position to ensure it is level.
Water leaks	Hose connections loose; drain hose not secured.	Tighten water inlet hose connections; ensure drain hose is properly placed.
Lint on clothes	Lint filter is full or not properly installed.	Clean the lint filter and ensure it is correctly reinserted.

If the problem persists after attempting these solutions, please contact Daewoo customer support.

8. Specifications

Feature	Detail
Brand	Daewoo
Model Number	DWTT11M2NUFW
Color	White
Product Dimensions (D x W x H)	43.18 x 73.66 x 86.36 cm
Weight	19 kg

Feature	Detail
Wash Capacity	11 Kilograms
Spin Capacity	7.8 Kilograms
Voltage	1 Voltios (Please verify local voltage requirements)
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic
Annual Energy Consumption	1 Kilowatt (This seems to be an annual consumption, not per cycle)
Noise Level	6 Sones
Special Features	Softener dispenser
Access Location	Top Load
Cycle Options	Normal, Fuerte (Strong)

9. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Daewoo website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Daewoo. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question