Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY BN59-01357B

ALLIMITY BN59-01357B Voice Remote Control User Manual

Model: BN59-01357B

1. Introduction

This manual provides instructions for the setup, operation, and maintenance of your ALLIMITY BN59-01357B Voice Remote Control. This remote is designed as a replacement for various Samsung QLED 4K Smart TV models from 2021, including Q80A, Q70A, and Q60A Series.



Image 1: The ALLIMITY BN59-01357B Voice Remote Control, featuring a sleek black design with various control buttons and a prominent voice command button.

2. Package Contents

- 1 x ALLIMITY BN59-01357B Voice Remote Control

3. Setup

3.1 Battery Installation

The remote control requires two (2) AAA alkaline batteries (not included) for operation.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards to open the compartment.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image 2: Illustration showing the open battery compartment of the remote control, indicating where to insert two AAA alkaline batteries.

3.2 Pairing the Remote Control

The remote control typically pairs automatically with your Samsung TV when the TV is first turned on. If automatic pairing does not occur, follow these steps to manually pair the remote:

1. Point the remote control directly at the remote control sensor of your Samsung TV.
2. Press and hold the **Return** button and the **Play**/**Pause** buttons simultaneously for 3 seconds or more.
3. Release the buttons once the pairing indicator appears on your TV screen, confirming successful pairing.



Image 3: Diagram illustrating the voice remote controller and instructions for pairing it with a Samsung TV by holding the Return and Play/Pause buttons.

4. Operating Instructions

The BN59-01357B remote control provides intuitive access to your Samsung Smart TV functions. Key buttons include:

- **Power Button:** Turns the TV on or off.
- **Voice Command Button:** Activates the voice assistant for hands-free control.
- **Number Pad (123):** Accesses the virtual number pad on screen.
- **Navigation Pad (Up/Down/Left/Right/Enter):** Navigates menus and selects items.
- **Return Button:** Returns to the previous screen or menu.
- **Home Button:** Accesses the Smart Hub.

- **Volume Up/Down:** Adjusts the TV volume.
- **Channel Up/Down:** Changes TV channels.
- **Quick Access Buttons:** Dedicated buttons for services like Netflix, Prime Video, and Samsung TV Plus.

5. Compatible TV Models

This replacement voice remote control is compatible with the following Samsung QLED 4K Smart TV models (2021 Series):

- **Q80A Series:** QN50Q80A, QN55Q80A, QN65Q80A, QN75Q80A, QN85Q80A (and variants like QN50Q80AAFXZA, QN50Q80AAF)
- **Q70A Series:** QN55Q70A, QN65Q70A, QN75Q70A, QN85Q70A (and variants like QN55Q70AAFXZA, QN55Q70AAF)
- **Q60A Series:** QN32Q60A, QN43Q60A, QN50Q60A, QN55Q60A, QN60Q60A, QN65Q60A, QN70Q60A, QN75Q60A, QN85Q60A (and variants like QN32Q60AAFXZA, QN32Q60AAF)
- **Other Compatible Models:** QN900A, QN800A, QN90A, QN85A, LS03A Series (e.g., QN65QN900AFXZA, QN50QN90AAFXZA, QN43LS03AAFXZA)

Note: This list includes common model prefixes. If your specific model number is not listed but falls within the 2021 QLED 4K Smart TV Q80A, Q70A, or Q60A series, the remote is likely compatible. For further assistance, please contact customer support.

6. Specifications

Feature	Detail
Model Number	BN59-01357B
Product Dimensions	7 x 2 x 0.6 inches (approximately 17.8 x 5.1 x 1.5 cm)
Item Weight	1.8 ounces (approximately 51 grams)
Power Source	2 x AAA Alkaline Batteries (not included)
Connectivity Technology	Bluetooth
Compatible Devices	Samsung QLED 4K Smart TVs (2021 models)
Special Feature	Voice Control, Ergonomic Design



Image 4: Visual representation of the remote control's dimensions, showing a length of approximately 16 cm (6.3 inches) and a width

of approximately 3.5 cm (1.38 inches).

7. Troubleshooting

- **Remote Not Responding:**
  - Ensure batteries are correctly inserted with the correct polarity.
  - Replace old batteries with new AAA alkaline batteries.
  - Re-attempt the pairing process (Section 3.2).
  - Ensure there are no obstructions between the remote and the TV's sensor.
- **Voice Control Not Working:**
  - Confirm the remote is successfully paired with the TV.
  - Check TV settings to ensure voice control is enabled.
  - Speak clearly and directly into the remote's microphone.
- **Intermittent Connectivity:**
  - Move closer to the TV.
  - Ensure no other devices are causing Bluetooth interference.
  - Re-pair the remote control.

If you continue to experience issues after following these troubleshooting steps, please contact customer support for further assistance.

8. Maintenance

- Keep the remote control dry. Moisture can damage the internal circuits.
- Avoid exposing the remote to extreme temperatures.
- Clean the remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Remove batteries if the remote control will not be used for an extended period to prevent battery leakage.
- Handle the remote with care; avoid dropping it or subjecting it to strong impacts.

9. Warranty and Support

For any questions, concerns, or if the remote control you received does not function as expected, please contact ALLIMITY customer service. Our team is available to provide professional suggestions and support.
Please refer to your purchase documentation for specific warranty details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CP8J9WB

More documents and user manuals: **https://manuals.plus/**