**ALLIMITY AMT-2IN1-BN59-01357A-01357B-BL-VC-all**

# ALLIMITY Voice Remote Control User Manual

Model: BN59-01357A / BN59-01357B

## Introduction

This manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your new ALLIMITY BN59-01357A / BN59-01357B Voice Remote Control. This remote is designed as a replacement for various 2021 Samsung Smart TV models, including QN900A, QN800A, QN90A, QN85A, LS03A, Q80A, Q70A, and Q60A Series.
Please read this manual carefully before using the remote control to ensure proper functionality and to maximize your viewing experience.

## Setup

### 1. Inserting Batteries

The remote control requires two (2) AA batteries (not included). Follow these steps to insert them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the indicators inside the compartment.
4. Slide the battery cover back into place until it clicks securely.



Image: Rear view of the remote control, illustrating the open battery compartment ready for AA battery insertion.

### 2. Pairing the Remote Control

For voice control and full functionality, the remote control needs to be paired with your Samsung

Smart TV. The pairing process typically involves these steps:

1. Ensure your TV is turned on.
2. Point the remote control towards the TV.
3. Press and hold the **Return** button (curved arrow) and the **Play/Pause** button simultaneously for at least 3 seconds. Some models may require holding the **Return** and **Volume Up** buttons.
4. A pairing message should appear on your TV screen, indicating that the remote is connecting.
5. Release the buttons once the pairing message appears or the remote successfully connects.

If pairing is unsuccessful, try replacing the batteries and repeating the process. Refer to your TV's user manual for specific pairing instructions if needed.

## Operating the Remote Control

The ALLIMITY remote control provides intuitive access to your Samsung Smart TV's features. Below is an overview of key buttons and their functions:



Image: Front view of the ALLIMITY remote control, highlighting its button layout.

### Basic Functions

- **Power Button** (*Red Circle with Line*): Turns the TV on or off.
- **Voice Assistant Button** (*Microphone Icon*): Activates the voice assistant feature for commands and searches.
- **Number Pad / Color Buttons** (*123 / Colored Dots*): Accesses the virtual number pad or specific color functions depending on the context.
- **Multi-View / Source Button** (*Rectangle with Plus Icon*): Switches input sources or activates multi-view mode.
- **Navigation Pad** (*Circular Pad with Center Button*): Navigates menus and selects items.
- **Return Button** (*Curved Arrow*): Returns to the previous screen or menu.
- **Home Button** (*House Icon*): Opens the Smart Hub or Home screen.
- **Play/Pause Button** (*Triangle and Two Vertical Lines*): Controls media playback.
- **Volume Buttons** (*+/- Bar*): Adjusts the volume up or down. Press the center of the bar to mute/unmute.
- **Channel Buttons** (*Up/Down Arrows with CC/VD*): Changes channels up or down. Press the center of the bar to access the channel list or CC/VD options.
- **Dedicated App Buttons** (*Netflix, Prime Video, Samsung TV Plus*): Direct access to these streaming services.

### Voice Control

To use the voice control feature, press and hold the **Voice Assistant Button** (microphone icon) and speak clearly into the remote. Release the button when you are finished speaking. This feature allows you to search for content, change settings, or control smart home devices connected to your TV.

## Maintenance

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

## Troubleshooting

If you encounter issues with your remote control, refer to the table below for common problems and their solutions:

| Problem | Possible Cause | Solution |
|---|---|---|
| Remote not responding. | Dead batteries, remote not paired, obstruction. | Replace batteries. Re-pair the remote (see Setup section). Ensure no objects are blocking the signal path to the TV. |
| Voice control not working. | Remote not paired for voice, microphone blocked, TV settings. | Ensure the remote is properly paired for voice. Check if anything is covering the microphone. Verify voice assistant settings on your TV. |
| Buttons are sticky or unresponsive. | Dirt or debris under buttons. | Clean the remote surface with a soft, dry cloth. Avoid liquid cleaners. |
| Remote frequently disconnects. | Interference, low battery, distance. | Replace batteries. Reduce distance to TV. Minimize interference from other electronic devices. |

## Specifications

- **Model Numbers:** BN59-01357A, BN59-01357B
- **Product Material:** Plastic
- **Product Dimensions:** 7 x 2 x 0.6 inches
- **Item Weight:** 1.8 ounces

- **Batteries Required:** 2 x AA batteries
- **Connectivity Technology:** Bluetooth
- **Compatible Devices:** Samsung Smart TVs (2021 Models) including QN900A, QN800A, QN90A, QN85A, LS03A, Q80A, Q70A, Q60A Series.

## Warranty Information

This product is a replacement remote control. For specific warranty details, please refer to the terms and conditions provided by your original point of purchase or contact the seller directly. Keep your purchase receipt as proof of purchase.

## Customer Support

If you have any questions, require further assistance, or if the remote control does not function as expected after following the troubleshooting steps, please contact the seller or manufacturer directly. Provide your product model number (BN59-01357A / BN59-01357B) and a detailed description of the issue for prompt support.

© 2024 ALLIMITY. All rights reserved.