Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY MBE090-ZRC-400

Allimity ZRC-400 Replaced Remote Control User Manual

Model: MBE090-ZRC-400

Introduction

This user manual provides comprehensive instructions for the Allimity ZRC-400 Replaced Remote Control. Designed as a direct replacement, this remote offers seamless compatibility with various Dynex TV models, ensuring a hassle-free experience without the need for complex setup or programming. Simply insert batteries, and it's ready for use.

Compatibility

The Allimity ZRC-400 Replaced Remote Control is compatible with the following Dynex TV models:

- DX-22L150A11
- DX-37L200A12
- DX-15L150A11
- DX19L150A11
- DX-46L262A12
- DX-40L130A11
- DX-46L150A11
- DX-40L261A12
- DX-46L260A12
- DX-46L261A12
- DX-32L230A12
- DX-46L230A12
- DX-24L230A12
- DX-15E220A12
- DX-42E250A12
- DX-40L150A11
- DX-32L200A12
- DX-24L150A11
- DX-24L200A12

- DX-26L100A13
- DX-32L100A13
- DX-26L150A11
- DX-32L220A12
- DX-32L150A11
- DX-37L150A11

Features

- No setup or programming required.
- Direct replacement for original Dynex TV remotes.
- Easy access to all standard TV functions.
- Operates on 2 AAA batteries (not included).

Setup: Battery Installation

To begin using your Allimity ZRC-400 remote control, you will need to install two AAA batteries. Follow these steps:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring that the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.





Image: Back of the remote control with the battery cover removed, showing the battery slots.
This image illustrates the open battery compartment on the back of the Allimity ZRC-400 remote, clearly showing the two slots for AAA batteries and the correct polarity markings.

Once batteries are installed, the remote is ready for immediate use with compatible Dynex TV models.

Operating Instructions

The Allimity ZRC-400 remote control provides intuitive access to all essential television functions. Below is a guide to the primary buttons and their uses:




1
2
3
4
5
6
7
8
9
RECALL
—
0
INFO
GUIDE
ENTER
MENU
EXIT
MUTE
VOL+
VOL–
FAVORITE
CH
CH
VIDEO
HDMI
TV
COMP
MTS/SAP
VGA
ZOOM
SLEEP
CH-LIST
PICTURE
AUDIO
CCD



Image: Front view of the Allimity ZRC-400 remote control.

This image displays the full layout of the Allimity ZRC-400 remote control, highlighting the arrangement and labeling of all functional buttons.

Power and Input Control

- **POWER** ( ): Turns the TV on or off.
- **INPUT**: Cycles through available video input sources (e.g., HDMI, AV, Component).

Channel and Volume Control

- **VOL+** / **VOL-**: Increases or decreases the volume level.
- **CH▲** / **CH▼**: Changes the TV channel up or down.
- **MUTE**: Toggles the sound on or off.

Navigation and Menu

- **MENU**: Opens the TV's main menu for settings and options.
- ▲ / ▼ / ◄ / ► (Arrow Buttons): Navigates through menu options.
- **ENTER**: Confirms a selection within the menu.
- **EXIT**: Closes the current menu or on-screen display.
- **INFO**: Displays current channel information or program details.
- **GUIDE**: Accesses the electronic program guide (if available).

Number Pad and Special Functions

- **0-9**: Directly enters channel numbers.
- **-** (Dash): Used for entering sub-channels (e.g., 7-1).
- **RECALL**: Switches between the current and previously viewed channel.
- **FAVORITE**: Accesses favorite channels list.
- **VIDEO** / **HDMI** / **TV** / **VGA** / **COMP**: Direct input selection buttons.
- **MTS/SAP**: Toggles between audio modes (Mono, Stereo, SAP/MTS).
- **ZOOM**: Adjusts the screen zoom level.
- **SLEEP**: Sets a timer for the TV to turn off automatically.
- **CH-LIST**: Displays the channel list.
- **PICTURE**: Accesses picture settings.
- **AUDIO**: Accesses audio settings.
- **CCD**: Activates Closed Captioning.

Troubleshooting

If your Allimity ZRC-400 remote control is not functioning as expected, consider the following common issues and solutions:

- **Remote is unresponsive:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.

- Check for any obstructions between the remote control and the TV's infrared sensor.
- Ensure you are within the effective range of the TV's IR receiver.

- **Certain buttons do not work:**
  - This remote is a direct replacement and should work with all listed compatible Dynex TV models. If a specific button does not function, verify that the corresponding feature is supported by your TV model.
  - Clean the remote's surface and buttons to ensure no debris is interfering with button presses.

Specifications

Feature	Detail
Model Number	MBE090-ZRC-400
Product Dimensions	6 x 1 x 0.5 inches
Item Weight	2 ounces
Batteries Required	2 AAA batteries (not included)
Color	Black
Special Feature	No Programming Required
Compatible Devices	Television (Specific Dynex models)

Warranty and Support

This Allimity ZRC-400 Replaced Remote Control comes with a**60-day warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as described.
For any questions, concerns, or support inquiries regarding your remote control, please contact the seller or manufacturer directly through your purchase platform. Please have your order details and product model number (MBE090-ZRC-400) available for faster assistance.

© 2024 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09D3M74R8

More documents and user manuals: **https://manuals.plus/**