BOWERY HILL BH-4752-2016294

BOWERY HILL 4-Piece Dining Chair Set User Manual

Model: BH-4752-2016294

Introduction

Thank you for purchasing the BOWERY HILL 4-Piece Dining Chair Set. This manual provides essential information for the safe assembly, proper use, maintenance, and troubleshooting of your new dining chairs. Please read these instructions carefully before assembly and retain them for future reference.

Important Safety Information:

- Always follow the assembly instructions carefully to ensure safety.
- Do not use power tools for assembly unless specifically instructed, as overtightening can damage the wood.
- Ensure all parts are securely fastened before use.
- Keep small parts and packaging materials away from children.
- This product is intended for indoor use only.

Parts List

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- Chair Back (A) x 4
- Chair Seat (B) x 4
- Front Legs (C) x 4
- Back Legs (D) x 4 (often integrated with chair back)
- Front Stretcher (E) x 4
- Side Stretchers (F) x 8
- Hardware Pack (G): Screws, Washers, Allen Wrench



Image: Front view of a single dining chair, showing the seat, backrest with cut-out design, and turned front legs.

Assembly Instructions

Follow these steps carefully to assemble each dining chair. It is recommended to assemble chairs on a soft, clean surface to prevent scratching.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a protected surface. Check against the parts list.
2. **Attach Front Legs:** Secure the Front Legs (C) to the underside of the Chair Seat (B) using the provided screws and washers from the Hardware Pack (G). Do not fully tighten screws yet.
3. **Attach Chair Back:** Connect the Chair Back (A) to the rear of the Chair Seat (B) using the appropriate screws and washers. Ensure the cut-out design faces the correct direction. Do not fully tighten.

4. **Install Stretchers:** Attach the Front Stretcher (E) between the two front legs. Attach the Side Stretchers (F) between the front and back legs on each side. Use the provided screws and washers.
5. **Final Tightening:** Once all components are loosely assembled, place the chair on a flat, level surface. Apply gentle downward pressure to ensure all legs are even. Then, systematically tighten all screws using the Allen wrench until secure. Do not overtighten.
6. **Repeat for Remaining Chairs:** Follow the same steps for the other three chairs in the set.



Image: Detailed view of a turned leg, highlighting the craftsmanship and connection points for assembly.

Usage Guidelines

To ensure the longevity and safety of your dining chairs, please observe the following guidelines:

- **Intended Use:** These chairs are designed for seating purposes in an indoor dining or kitchen environment.
- **Weight Capacity:** Each chair has a recommended maximum weight capacity of approximately 300 lbs (136 kg). Exceeding this limit may cause damage or injury.
- **Even Surface:** Always use the chairs on a flat, level surface to prevent wobbling and ensure stability.
- **Avoid Standing:** Do not stand on the chairs.
- **Gentle Movement:** When moving chairs, lift them rather than dragging them to prevent damage to legs and flooring.



Image: A set of four dining chairs with upholstered seats, positioned around a dining table in a home setting.

Care and Maintenance

Regular care will help maintain the appearance and structural integrity of your BOWERY HILL dining chairs.

Wood Frame Care:

- **Dusting:** Dust regularly with a soft, dry cloth.

- **Cleaning:** For deeper cleaning, wipe with a damp cloth and mild wood cleaner, then immediately dry with a clean, soft cloth.
- **Avoid Moisture:** Protect from excessive moisture and spills. Wipe up spills immediately.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or cracking.
- **Heat:** Keep away from direct heat sources like radiators or fireplaces.

Upholstered Seat Care:

- **Vacuuming:** Vacuum regularly using an upholstery attachment to remove dust and debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner following the product instructions, testing on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use harsh detergents, bleach, or abrasive cleaners on the fabric.

General Maintenance:

- **Check Hardware:** Periodically check and retighten all screws and bolts to ensure stability. Do this every 3-6 months or if the chair feels wobbly.

Troubleshooting

Here are solutions to common issues you might encounter with your dining chairs:

- **Chair Wobbles:**
  - Ensure the chair is on a flat, even surface.
  - Check all assembly screws and bolts. Loosen them slightly, press down firmly on the seat to level the chair, then retighten all hardware securely.
- **Loose Parts:**
  - If any part feels loose, immediately stop using the chair.
  - Identify the loose connection and tighten the corresponding screws or bolts using the provided Allen wrench.
- **Squeaking Noises:**
  - Squeaking often indicates loose joints. Retighten all assembly hardware.
  - If squeaking persists, disassemble the affected joint, apply a small amount of wood glue (not included) to the dowels or joint surfaces, and reassemble, ensuring a tight fit.

Specifications

Brand:	BOWERY HILL
Model Number:	BH-4752-2016294
UPC:	195493056204
Color:	Walnut Brown (Frame), Grey (Upholstery)
Material:	Solid Oak Wood, Rubberwood, Polyester Fabric, Foam Fill
Product Dimensions (per chair):	22"D x 17.9"W x 38.6"H (55.9 cm D x 45.5 cm W x 98 cm H)
Item Weight (per chair):	Approximately 13.8 lbs (6.26 kg)

Maximum Weight Recommendation (per chair):	300 lbs (136 kg)
Included Components:	4 Dining Chairs (requires assembly)
Indoor/Outdoor Usage:	Indoor Only



Image: A single dining chair with key dimensions (height, width, depth) clearly marked.

Warranty Information

For detailed warranty information regarding your BOWERY HILL 4-Piece Dining Chair Set, please refer to the product description on the original purchase platform or contact the seller directly. Manufacturer warranty details are typically provided at the point of sale or within the product packaging.

Customer Support

If you have any questions, require replacement parts, or need further assistance with your BOWERY HILL dining chairs, please contact the retailer from whom you purchased the product. You may also visit the official BOWERY HILL website for additional support resources.
When contacting support, please have your model number (BH-4752-2016294) and UPC (195493056204) readily available.

© 2023 BOWERY HILL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question