Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Garza 400614G

Garza Digital Programmable Timer (Digital Pack 2) Instruction Manual

Model: 400614G

1. Introduction

Thank you for choosing the Garza Digital Programmable Timer. This device is designed to automatically control the power supply to your electrical appliances, allowing you to set specific ON/OFF times throughout the day and week. This helps in managing energy consumption and enhancing convenience in your home or office.

1.1. Product Overview

The Garza Digital Programmable Timer is a versatile plug-in device that offers precise control over connected appliances. It features an LCD screen for easy programming and monitoring, along with multiple programming options to suit various needs.



Image 1.1: Two Garza Digital Programmable Timers, showing the front panel with LCD display and control buttons.

1.2. Package Contents

- 2 x Garza Digital Programmable Timers
- 1 x Instruction Manual (this document)

2. Safety Information

Please read all safety instructions carefully before using the device. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- **Indoor Use Only:** This timer is designed for indoor use in dry locations. Do not use it outdoors or in damp environments.
- **Electrical Rating:** Do not exceed the maximum load of 16A, 3680W. Overloading the timer can cause overheating and fire hazards.
- **Child Protection:** The timer features integrated child protection shutters in the socket to prevent accidental insertion of objects.
- **Voltage:** Ensure the timer is connected to a 230V~ 50Hz power supply.
- **Cleaning:** Disconnect from power before cleaning. Use a dry cloth; do not use liquid cleaners.
- Do not disassemble or attempt to repair the device. Refer all servicing to qualified personnel.

3. Product Features

The Garza Digital Programmable Timer offers a range of features for efficient appliance control:

- **Multiple Programs:** Up to 8 ON/OFF programs can be set per day.
- **Weekly Scheduling:** Program specific ON/OFF times for individual days or groups of days (7-day weekly programming).
- **Time Format:** Option to display time in 24-hour or 12-hour format.
- **Predefined Functions:** Includes special modes such as 'Vacation' and 'Random' for enhanced security or convenience.
- **LCD Screen:** Clear digital display for easy viewing of time and program settings.
- **Child Protection:** Integrated safety shutters in the socket.





Image 3.1: Front view of the Garza Digital Programmable Timer, highlighting the LCD screen and control buttons (WEEK, HOUR, MIN, SEC, CLOCK, PROG, R).

4. Setup

4.1. Initial Setup

1. Unpack the timer from its packaging.
2. Plug the timer into a standard wall outlet. The LCD screen should illuminate.
3. If the display is blank or shows erratic characters, press the 'R' (Reset) button using a small pointed object (e.g., a pen tip) to clear all memory and reset the unit.

4.2. Setting Current Time

Before programming, ensure the current time and day are set correctly.

1. Press and hold the **CLOCK** button.
2. While holding **CLOCK**, press the **WEEK** button repeatedly to select the current day of the week (e.g., MO for Monday, TU for Tuesday).
3. Continue holding **CLOCK** and press the **HOUR** button to set the current hour.
4. Continue holding **CLOCK** and press the **MIN** button to set the current minute.
5. Release the **CLOCK** button. The current time is now set.
6. To switch between 12-hour and 24-hour format, press the **CLOCK** and **PROG** buttons simultaneously.

5. Operating Instructions

5.1. Programming ON/OFF Times

The timer allows you to set up to 8 ON/OFF programs. Each program consists of an ON time and an OFF time for specific days.

1. Press the **PROG** button once. The display will show "1 ON" and the time will flash.
2. Press **WEEK** to select the desired day(s) for this program. You can choose individual days, weekdays, weekends, or all 7 days.
3. Press **HOUR** to set the desired ON hour.
4. Press **MIN** to set the desired ON minute.
5. Press **PROG** again. The display will show "1 OFF" and the time will flash.
6. Repeat steps 2-4 to set the desired OFF day(s), hour, and minute for this program.
7. Press **PROG** to advance to the next program (2 ON, 2 OFF, etc.) or to exit programming mode after setting all desired programs.
8. To return to the current time display at any point, press the **CLOCK** button.

5.2. Manual Override

You can manually switch the timer's output mode without affecting the programmed settings.

- Press the button with the hand icon (often labeled **ON**/**AUTO**/**OFF** or similar) repeatedly to cycle through the modes:
  - **ON:** The connected appliance will remain continuously ON.
  - **AUTO:** The connected appliance will operate according to the programmed ON/OFF times.
  - **OFF:** The connected appliance will remain continuously OFF.
- For automatic operation, ensure the timer is set to **AUTO** mode.

5.3. Predefined Functions (Vacation/Random Mode)

The timer may include predefined functions like 'Vacation' or 'Random' mode. Consult the specific button labels on your device for activation.

- **Vacation Mode:** This mode typically turns the appliance ON and OFF at irregular intervals to simulate occupancy, enhancing home security when you are away.
- **Random Mode:** Similar to Vacation mode, it activates and deactivates the connected device randomly within a set timeframe.



Image 5.1: A Garza Digital Programmable Timer plugged into a power strip, demonstrating a typical usage scenario for controlling an appliance.

6. Maintenance

6.1. Cleaning

To clean the timer, first unplug it from the wall outlet. Use a soft, dry cloth to wipe the exterior. Do not use abrasive cleaners, solvents, or immerse the device in water.

6.2. Internal Battery

The device contains an internal, non-user-replaceable battery that retains your programmed settings during power outages or when the timer is unplugged. The lifespan of this battery is finite. Attempting to replace it may damage the unit and void any warranty.

7. Troubleshooting

Problem	Possible Cause	Solution
Display is blank or erratic.	No power or internal error.	Ensure the timer is securely plugged into a live outlet. Press the 'R' (Reset) button with a pointed object.
Programmed settings are not activating.	Timer is not in AUTO mode or incorrect time setting.	Press the manual override button (hand icon) until 'AUTO' is displayed. Verify the current time and day are set correctly. Recheck program settings.
Appliance remains ON/OFF continuously.	Timer is in manual ON or OFF mode.	Press the manual override button (hand icon) until 'AUTO' is displayed.
Time display is incorrect.	Time was not set correctly or power interruption.	Reset the timer using the 'R' button and set the current time and day again as per Section 4.2.

8. Specifications

- **Model:** 400614G
- **Dimensions:** 6 x 10 x 17 cm
- **Weight:** 350 g
- **Input Voltage:** 230V~ 50Hz
- **Max Output Load:** 16A, 3680W
- **Number of Programs:** 8 ON/OFF programs
- **Programming Cycle:** 7 days / 24 hours
- **Child Protection:** Yes



Image 8.1: Rear view of the Garza Digital Programmable Timer, displaying the product label with electrical specifications.

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact

Garza customer service through their official website or your retailer. Keep your proof of purchase for warranty claims.

© 2025 Garza. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F44B1BY

More documents and user manuals: **https://manuals.plus/**