Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Syslux BL-DP-BFX

Syslux LED Snowflake Projector Light Instruction Manual

Model: BL-DP-BFX | Brand: Syslux

1. Introduction

This manual provides essential information for the safe and effective use of your Syslux LED Snowflake Projector Light. This device is designed to project dynamic snowflake patterns, creating a festive atmosphere for various occasions, both indoors and outdoors. Please read these instructions carefully before installation and operation.

2. Safety Information

- Ensure the power source matches the projector's requirements.
- Do not immerse the projector directly in water, despite its IP65 weather protection.
- Keep the projector away from open flames or extreme heat sources.
- Do not attempt to open or modify the projector. Refer all servicing to qualified personnel.
- Avoid direct eye exposure to the LED light source.
- Keep out of reach of children.

3. Package Contents

Verify that all components are present in the package:

- LED Snowflake Projector Light (2 units)
- Ground Stake (2 units)
- Round Base (2 units)
- Power Adapter with 32.8 ft (10m) Cable (2 units)
- Mounting Screws (for wall installation)

4. Product Features

- **High Brightness LED:** Projects clear and vivid snowflake patterns.
- **Dynamic Snowfall Effect:** Simulates falling snow with rotating large snowflakes.
- **IP65 Weatherproof Rating:** Suitable for both indoor and outdoor use, resistant to rain and humidity.
- **Multiple Installation Options:** Includes ground stake for yard/garden and a round base for flat surfaces or wall

mounting.

- **Adjustable Projection Angle:** Projector head can be adjusted up to 270 degrees.
- **6-Hour Auto-Off Timer:** Automatically shuts off after 6 hours of operation in daily circulation.
- **Wide Application:** Ideal for Christmas, holidays, parties, weddings, home, garden, and landscape decoration.

5. Setup

The projector offers flexible installation options:

5.1 Ground Stake Installation (Outdoor)

1. Attach the ground stake to the bottom of the projector unit.
2. Insert the stake firmly into the ground in your garden or yard.
3. Adjust the projector head to the desired angle to direct the light.

5.2 Flat Surface Installation (Indoor/Outdoor)

1. Attach the round base to the bottom of the projector unit.
2. Place the projector on a stable, flat surface such as a floor, table, or deck.
3. Adjust the projector head to the desired angle.

5.3 Wall Mounting (Indoor/Outdoor)

1. Attach the round base to the bottom of the projector unit.
2. Use appropriate screws (provided) to securely mount the base to a wall.
3. Adjust the projector head to the desired angle.



Figure 1: Installation options for the projector, including placement on a flat surface and ground staking.



Figure 2: Optimal projection range and coverage area. For outdoor use, 20-33 ft is recommended, and for indoor use, 26-49 ft. Optimal projection coverage is 538-4300 sq ft.

6. Operating Instructions

1. After installation, connect the power adapter to the projector and then plug it into a standard electrical outlet.
2. The projector will automatically turn on and begin displaying the snowflake effect.
3. The projector features a built-in **6-hour auto-off timer**. It will operate for 6 hours and then automatically shut off, repeating this cycle daily.
4. To manually turn off the projector, unplug it from the power source.



Figure 3: The projector includes a 6-hour auto-off timer for daily operation.

7. Maintenance

- **Cleaning:** Ensure the projector is unplugged before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use abrasive cleaners or solvents.
- **Lens Care:** Gently clean the projection lens with a soft, lint-free cloth to maintain clear image quality.
- **Storage:** When not in use, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Cable Inspection:** Periodically check the power cable for any signs of damage. If damaged, discontinue use and replace the cable.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Projector does not turn on.	No power supply.	Check if the power adapter is securely plugged into the projector and the outlet. Ensure the outlet is functional.
Projection is dim or unclear.	Lens is dirty; Projector is too far from the surface.	Clean the projection lens. Move the projector closer to the projection surface (refer to Figure 2 for optimal distances).
Snowflake effect is not moving.	Internal motor malfunction.	Unplug and replug the projector. If the issue persists, contact customer support.
Projector turns off unexpectedly.	6-hour auto-off timer activated.	This is normal operation. The projector will restart after 18 hours. If it turns off before 6 hours, contact customer support.

9. Specifications

Attribute	Detail
Manufacturer	Shenzhen Bolong Technology Co., Ltd.
Model Number	BL-DP-BFX
Package Dimensions	18.8 x 16.4 x 11.2 cm
Item Weight	827 grams (1.82 pounds)
Color	Black
Shape	Rectangular, Square
Material	Metal
Finish Type	Projector
Light Source Type	LED
Power Source	Corded Electric
Style	Modern
Installation Type	Ground Mount
Weather Protection	IP65
Operating Temperature	-4°F ~ 122°F (-20°C ~ 50°C)

10. Warranty and Support

Your Syslux LED Snowflake Projector Light comes with the following:

- **30-Day Money-Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **12-Month Warranty:** The product is covered by a 12-month warranty against manufacturing defects.
- **Customer Support:** For any questions, issues, or warranty claims, please contact our customer service. We aim to provide a 24-hour quick response and friendly support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09F9819JC

More documents and user manuals: **https://manuals.plus/**