ROCKPOINT HX2021-15

ROCKPOINT 58-inch Corner TV Stand (Model: HX2021-15)

Instruction Manual

Contents Assembly Operation Introduction Maintenance Package Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your ROCKPOINT 58-inch Corner TV Stand, Model HX2021-15. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.

Safety Information

- Always ensure the TV stand is placed on a level and stable surface to prevent tipping.
- Do not exceed the maximum weight capacity of the stand. Refer to the specifications section for details.
- Keep small parts and packaging materials away from children and pets during assembly.
- Use only the provided hardware for assembly. Substituting parts may compromise the stand's stability.

2. Package Contents

Before beginning assembly, carefully unpack all components and verify that all parts are present and undamaged. Refer to the detailed parts list included in your product packaging for a complete inventory. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Tools Required (Not Included)

- Phillips Head Screwdriver
- Hammer (for dowels, if applicable)

3. Assembly Instructions

Full assembly is required for this TV stand. It is recommended to have two people for assembly to ensure stability and ease of handling larger components. Follow the steps below and refer to the visual aids for guidance.

General Assembly Steps

1. **Unpack and Organize:** Lay out all parts on a soft, clean surface to prevent scratches. Group similar hardware together.
2. **Assemble the Base:** Attach the side panels to the bottom panel using the specified hardware. Ensure all connections are secure.
3. **Install Shelves:** Insert shelf support pins into the pre-drilled holes. Place the adjustable shelves onto the pins in your desired configuration.
4. **Attach Top Panel:** Carefully align and attach the top panel to the assembled frame. Secure with the appropriate fasteners.
5. **Install Back Panels:** Secure the back panels to the rear of the stand. Ensure the cable management cutouts are correctly positioned.
6. **Final Check:** Verify all screws and fasteners are tightened. Gently move the stand to ensure stability.

For detailed, step-by-step assembly instructions with diagrams, please refer to the official Installation Manual (PDF) provided with your product.



This image displays the complete ROCKPOINT 58-inch Corner TV Stand, featuring its dark espresso finish and functional design with multiple open shelves for media devices.



An example of the TV stand in use, showcasing its capacity to hold a large flat-screen television and organize various entertainment components within its open shelving.

4. Operating Instructions

Placement and TV Setup

- **Positioning:** Place the TV stand in a corner of your room on a flat, stable, and level surface.
- **TV Placement:** Carefully place your flat panel TV, up to 65 inches, securely on the top surface of the stand. Ensure the TV's base is fully supported and does not overhang.

Storage and Organization

- **Open Shelving:** Utilize the four open storage shelves for media devices such as cable boxes, gaming consoles, DVD players, and soundbars.
- **Adjustable Shelves:** The two adjustable-height shelves (one on each side of the central divider) allow you to customize the storage space to accommodate items of various sizes. To adjust, remove the shelf, reposition the

support pins to the desired height, and reinsert the shelf.

- **Cable Management:** Route power cords and signal cables through the integrated cable management system (circular cutouts) at the back of the stand. This helps to keep cables organized and out of sight, maintaining a neat and tidy appearance.

Your browser does not support the video tag.

This video provides a visual overview of the ROCKPOINT Corner TV Stand, including its design, storage capabilities, and potentially key assembly steps. It highlights the adjustable shelving and overall stability.

5. Maintenance and Care

Cleaning

- Wipe the surface with a dry, soft cloth.
- Avoid using abrasive cleaners, harsh chemicals, or polishes that may damage the finish.
- For stubborn marks, use a slightly damp cloth with mild soap, then immediately dry with a clean, soft cloth.

General Care

- **Regular Inspection:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Avoid Heat and Moisture:** Do not place hot items directly on the surface. Avoid prolonged exposure to direct sunlight or excessive moisture, which can cause warping or fading.
- **Weight Distribution:** Distribute weight evenly across the shelves and top surface to prevent stress on the structure.

6. Troubleshooting

If you encounter issues with your TV stand, refer to the following common problems and solutions:

- **Problem:** The TV stand appears unstable or wobbly after assembly.
  Solution: Ensure all assembly screws and fasteners are fully tightened. Verify that the stand is placed on a completely level surface. If your stand has adjustable feet, ensure they are properly adjusted to compensate for uneven flooring.
- **Problem:** Shelves do not fit correctly or are loose.
  Solution: Recheck the placement of the shelf support pins. Ensure they are fully inserted into the designated holes and that the shelves are resting securely on them. Confirm you are using the correct size pins for the shelves.
- **Problem:** Visible gaps between panels.
  Solution: This may indicate that screws are not fully tightened or panels are not correctly aligned. Disassemble the affected section and reassemble carefully, ensuring all connections are flush and secure.

7. Specifications

Model Number	HX2021-15
Brand	ROCKPOINT
Color	Espresso
Material	High-Grade MDF, Durable Laminate (Engineered Wood)

Overall Dimensions (L x W x H)	58 inches x 16 inches x 23.6 inches (147.57 cm x 39.88 cm x 60.45 cm)
Item Weight	64 pounds (approx. 29 kg)
TV Size Capacity	Up to 65 inches Flat Panel TV
Storage	4 Open Storage Shelves (2 adjustable)
Features	Cable Management System



This diagram provides the precise measurements of the TV stand, indicating its length, width, and height for proper placement and fit.

8. Warranty and Support

For specific warranty information, details on returns, or to contact customer support for assistance with your ROCKPOINT 58-inch Corner TV Stand, please refer to the documentation included with your original purchase. You may also visit the official ROCKPOINT website or contact their customer service department directly using the contact information provided on their product packaging or website.

© 2023 ROCKPOINT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question