Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TECLAST P50

TECLAST P50 11-inch Wi-Fi Tablet User Manual

Model: P50 (2025)

1. Introduction

This manual provides essential information for the safe and efficient use of your TECLAST P50 11-inch Wi-Fi Tablet. Please read this manual thoroughly before using the device and keep it for future reference.

Key Features:

- **Display:** 11-inch IPS display with 1280x800 resolution and 90Hz refresh rate.
- **Operating System:** Android 14.
- **Performance:** Unisoc T606 Octa-core processor with Mali-G57 GPU.
- **Memory & Storage:** 6GB LPDDR4X RAM (expandable to 16GB with virtual memory) and 128GB internal storage (expandable up to 1TB via microSD).
- **Battery:** 8000mAh for extended use.
- **Connectivity:** Dual-band 2.4G/5G Wi-Fi and Bluetooth 5.0.
- **Cameras:** 13MP rear camera and 5MP front camera with AI features and face recognition.
- **Multimedia:** Widevine L1 support for high-definition streaming.



Image 1.1: Overview of TECLAST P50's core specifications including the Unisoc T606 processor, 16GB RAM, and 128GB storage.

2. What's in the Box

Please check the contents of your package. If any items are missing or damaged, contact your retailer.

- TECLAST P50 11-inch Wi-Fi Tablet
- User Manual (this document)

Note: An AC charger is NOT included. Please use a Type-C charger with an output of DC 5.0V --- 2.5A.

3. Product Overview

Familiarize yourself with the tablet's physical components.



Image 3.1: Front view of the TECLAST P50 tablet, showing the display and front camera.



Image 3.2: Side view of the TECLAST P50 tablet, highlighting its slim profile and potential button/port locations.



Image 3.3: Back view of the TECLAST P50 tablet, showing the rear camera module and TECLAST branding.

Component Identification:

- **Display:** 11-inch IPS touchscreen.
- **Front Camera:** Located on the bezel above the display.
- **Rear Camera:** Located on the back of the tablet.
- **Power Button:** (Typically on the side/top edge) Used to power on/off or sleep/wake the device.
- **Volume Buttons:** (Typically on the side edge) Used to adjust volume.
- **USB Type-C Port:** For charging and data transfer. Note: This port is separate from the OTG adapter slot.
- **3.5mm Headphone Jack:** For connecting wired headphones.
- **MicroSD Card Slot:** For expanding storage.

4. Setup

4.1 Charging the Tablet

1. Connect a compatible Type-C charger (DC 5.0V --- 2.5A output) to the tablet's USB Type-C port.
2. Plug the charger into a power outlet.
3. The battery icon on the screen will indicate charging status.
4. For optimal battery life, fully charge the tablet before first use.

Important: Do not use chargers that do not meet the specified voltage and current requirements, as this may damage the tablet or charger.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button until the TECLAST logo appears on the screen.
- **To Power Off:** Press and hold the Power button until a menu appears. Select "Power off" and confirm.
- **To Sleep/Wake:** Briefly press the Power button to put the tablet into sleep mode or wake it up.

4.3 Initial Setup

The first time you power on your tablet, you will be guided through an initial setup process:

1. **Language Selection:** Choose your preferred language.
2. **Wi-Fi Connection:** Select your Wi-Fi network and enter the password to connect to the internet.
3. **Google Account:** Sign in with your Google account or create a new one. This is necessary to download apps from the Google Play Store.
4. Follow the on-screen prompts to complete other settings like date, time, and security options.

4.4 RAM Expansion (Virtual Memory)

Your TECLAST P50 supports virtual RAM expansion, allowing you to utilize up to 10GB of storage as additional RAM, totaling 16GB.

1. Go to **Settings**.
2. Navigate to **System**.
3. Select **Memory Boost** / **Memory Expansion**
4. Choose the desired expansion amount (e.g., 10.0GB).

*If you cannot find the memory expansion option, it is recommended to perform an OTA (Over-The-Air) software update. Go to **Settings** > **About tablet** > **Wireless update**.*

4.5 MicroSD Card Installation

You can expand the tablet's storage up to 1TB using a microSD card.

1. Locate the microSD card slot on the side of the tablet.
2. Gently insert the microSD card into the slot with the gold contacts facing down until it clicks into place.
3. To remove, gently push the card inward until it springs out.

Note: This tablet does not support SIM cards for cellular calls or data.

5. Operating Your Tablet

5.1 Basic Navigation

- **Tap:** Touch the screen once to open an app, select an item, or press a button.
- **Touch & Hold:** Touch and hold an item to access more options or move it.
- **Swipe:** Drag your finger across the screen to scroll through lists or switch between home screens.
- **Pinch:** Use two fingers to zoom in or out on photos and web pages.

5.2 Connecting to Wi-Fi

1. Go to **Settings**.
2. Tap **Network & internet** > **Wi-Fi**.
3. Turn on Wi-Fi. The tablet will scan for available networks.
4. Select your desired network and enter the password if prompted.



Image 5.1: The TECLAST P50 supports dual-band Wi-Fi for fast and stable internet connection.

5.3 Bluetooth Pairing

1. Go to **Settings**.
2. Tap **Connected devices** > **Bluetooth**.
3. Turn on Bluetooth. The tablet will scan for nearby devices.
4. Select the device you want to pair with and follow the on-screen instructions.

5.4 Camera Usage

Your tablet features a 13MP rear camera and a 5MP front camera.

1. Open the **Camera** app.
2. Tap the shutter button to take a photo.
3. Switch between front and rear cameras using the camera switch icon.
4. Explore different modes like video, portrait, or panorama if available.

5.5 Multimedia and Streaming

The TECLAST P50 supports Widevine L1, allowing you to stream high-definition content from services like Amazon Prime Video, Netflix, Disney+, and Hulu.

- Download your preferred streaming apps from the Google Play Store.
- Ensure a stable internet connection for optimal streaming quality.

5.6 Screen Mirroring (Wireless Projection)

You can wirelessly project your tablet's screen to a compatible large-screen TV.

1. Ensure your TV supports screen mirroring or has a compatible dongle.
2. On your tablet, go to **Settings** > **Connected devices** > **Connection preferences** > **Cast**.
3. Select your TV from the list of available devices.
4. Follow any on-screen prompts on both your tablet and TV.

Note: This tablet does not support HDMI output.

5.7 Audio Features

- **3.5mm Headphone Jack:** Connect your wired headphones for private listening.
- **AI Noise Reduction:** The tablet incorporates AI noise reduction technology for clearer audio experiences.



Image 5.2: The TECLAST P50 features an 8000mAh battery, 13MP+5MP cameras, and pure sound audio with a 3.5mm jack.

5.8 Face Recognition

Unlock your tablet quickly and securely using face recognition.

1. Go to **Settings** > **Security & privacy** > **Device unlock** > **Face unlock**.
2. Follow the on-screen instructions to register your face.
3. Ensure good lighting conditions when registering and using face unlock.

5.9 Productivity and User Experience

- **Multi-screen Connection:** Connect to other displays or devices for enhanced workflow.
- **Split Screen:** Use two apps simultaneously by splitting the screen.
- **Widget Function:** Add widgets to your home screen for quick access to information and app functions.
- **Kids Protection Function:** Utilize the new child protection features for a balanced educational and entertainment experience.



Image 5.3: Android OS features on the TECLAST P50, including parallel view, privacy settings, taskbar, and parental controls.

6. Maintenance

6.1 Software Updates (OTA)

Regularly check for and install software updates to ensure optimal performance, security, and access to new features.

1. Ensure your tablet is connected to Wi-Fi and has sufficient battery (at least 50%).
2. Go to **Settings** > **About tablet** > **Wireless update**.
3. Follow the on-screen instructions to download and install any available updates.

6.2 Cleaning Your Tablet

- Use a soft, lint-free cloth (e.g., microfiber cloth) to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics.
- Avoid using harsh chemicals, abrasive materials, or excessive moisture, as these can damage the device.

7. Troubleshooting

7.1 Common Issues and Solutions

Problem	Possible Solution
Tablet does not turn on.	Ensure the tablet is charged. Connect to a charger for at least 30 minutes, then try powering on again.
Cannot connect to Wi-Fi.	• Ensure Wi-Fi is enabled on the tablet. • Check if the Wi-Fi password is correct. • Restart your Wi-Fi router. • Try connecting to a different Wi-Fi network if available.
Apps are crashing or freezing.	• Close and reopen the app. • Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). • Restart the tablet. • Ensure the app is updated to the latest version.
RAM expansion option is missing or not working.	Perform an OTA software update (Settings > About tablet > Wireless update).
Google Play Store not opening or downloading apps.	• Ensure you have a stable internet connection. • Clear cache and data for Google Play Store and Google Play Services (Settings > Apps). • Restart the tablet.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Feature	Detail
Brand	TECLAST

Feature	Detail
Model Name	P50
Operating System	Android 14
Display Size	11 inches
Display Type	IPS
Display Resolution	1280x800 pixels
Refresh Rate	90Hz
Processor	Unisoc T606 Octa-core (1.6 GHz)
GPU	Mali-G57
RAM	16GB (6GB physical + 10GB virtual)
Internal Storage	128GB
Expandable Storage	Up to 1TB via microSD
Battery Capacity	8000mAh (Lithium Polymer)
Wi-Fi	802.11 ac/b/g/n (2.4G/5G Dual-band)
Bluetooth	Bluetooth 5.0
Rear Camera	13MP
Front Camera	5MP
Ports	1x USB Type-C, 1x 3.5mm Headphone Jack
Sensors	Hall Sensor
Dimensions (LxWxH)	25.8 x 17 x 0.9 cm
Weight	555 grams
Color	Blue

9. Safety Information

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to strong impacts.
- Do not attempt to disassemble or repair the tablet yourself. This will void the warranty.
- Use only approved chargers and accessories.
- Keep the tablet away from water and other liquids.
- Do not use the tablet while driving or in situations where it could distract you from important tasks.

- Dispose of the tablet and its battery responsibly according to local regulations.

10. Warranty and Support

10.1 Warranty

Your TECLAST P50 tablet comes with a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.
During the warranty period, return and exchange services are provided for damages or malfunctions occurring under normal use. Repair services are not offered.

10.2 Customer Support

If you encounter any issues or have questions about your TECLAST P50 tablet, please contact customer support through Amazon:

1. Log in to your Amazon account.
2. Go to **Order History**.
3. Locate the relevant order for your TECLAST P50 tablet.
4. Click on **Contact Seller**.

When contacting support, please provide your **order number** and the **ID and SN numbers** found on the back of your tablet for faster assistance.
Support Hours: Monday - Friday, 10:00 AM - 7:00 PM (Japan Standard Time). Closed on Saturdays, Sundays, and public holidays.

© 2025 TECLAST. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FKYRD22

More documents and user manuals: **https://manuals.plus/**