Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SOGO PIC-SS-5262

SOGO PIC-SS-5262 Food Chopper Instruction Manual

Model: PIC-SS-5262

Introduction

Welcome to the SOGO PIC-SS-5262 Food Chopper instruction manual. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

The SOGO PIC-SS-5262 is a versatile kitchen appliance designed for chopping and mincing various food items such as meat, vegetables, fruits, and nuts. It features a powerful 500W motor, a durable 1.8-liter stainless steel bowl, and sharp titanium-coated blades for efficient processing.



Figure 1: The SOGO PIC-SS-5262 Food Chopper. This image shows the assembled appliance, featuring a sleek design with a brushed stainless steel finish on both the motor unit and the 1.8-liter bowl, topped with a transparent lid.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Read all instructions carefully before use.
- Do not immerse the motor unit in water or other liquids.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Always unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Supervise children to ensure they do not play with the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Always ensure the lid is securely locked in place before operating the chopper.
- Avoid processing extremely hard foods that may damage the blades or motor.
- The blades are very sharp. Handle with extreme care during assembly, disassembly, and cleaning.

Product Components

Familiarize yourself with the parts of your SOGO PIC-SS-5262 Food Chopper.



Figure 2: Components of the SOGO PIC-SS-5262 Food Chopper. This image displays the main motor unit, the 1.8-liter stainless steel chopping bowl, the transparent BPA-free lid, and two different sets of titanium-coated blades (a two-blade set and a four-blade set). Also visible are small measuring cups and a non-slip base.

- **Motor Unit:** Contains the powerful 500W motor and control buttons.
- **Lid:** Transparent, BPA-free lid with a secure locking mechanism.
- **Chopping Bowl:** 1.8-liter capacity, made of durable SUS304 stainless steel.
- **Blade Assembly:** Features sharp titanium-coated blades. The unit typically includes a two-blade and a four-blade assembly for different chopping needs.
- **Non-slip Base:** Ensures stability during operation.

Setup and Assembly

1. Place the chopping bowl onto a stable, flat, and dry surface. Ensure the non-slip base is securely positioned.
2. Carefully place the desired blade assembly onto the central shaft inside the chopping bowl. The blades are very sharp; handle them by the plastic top.
3. Add the ingredients you wish to chop into the bowl. Do not overfill the bowl; ensure ingredients are below the "MAX" fill line.
4. Place the transparent lid onto the chopping bowl, aligning it correctly and twisting or pressing down until it locks securely into place.
5. Position the motor unit on top of the lid, ensuring it is properly seated and aligned with the blade shaft.
6. Plug the power cord into a suitable electrical outlet.

Operating Instructions

The SOGO PIC-SS-5262 Food Chopper features a dual-speed function for versatile processing.



Figure 3: The SOGO PIC-SS-5262 in operation, demonstrating its ability to chop meat. Key features such as the 500W pure copper motor, titanium-coated blades, dual-speed function, and stainless steel bowl are highlighted.

1. **Power On:** Once assembled and plugged in, press down on the top of the motor unit to activate the chopping function.
2. **Speed Control:** The appliance typically has two speed settings. Press the "I" button for low speed and the "II" button for high speed. Use short pulses for coarse chopping and longer pulses for finer results.
3. **Processing:** Continue pulsing until the desired consistency is achieved. For best results, do not operate continuously for more than 30 seconds. Allow the motor to rest for a few minutes between cycles to prevent overheating.
4. **Power Off:** Release the button on the motor unit to stop operation.
5. **Disassembly:** Unplug the appliance from the power outlet. Carefully remove the motor unit, then the lid. Carefully remove the blade assembly before emptying the chopped ingredients.

Tips for Best Results

- Cut large ingredients into smaller, uniform pieces (approx. 2-3 cm) before placing them in the bowl.

- Do not overload the bowl. Process in batches if necessary.
- For ingredients like onions or garlic, use short pulses to avoid over-processing.
- For tougher ingredients like meat, ensure it is cut into small cubes and remove any bones or excessive fat.

Cleaning and Maintenance

Regular cleaning ensures the longevity and hygienic operation of your food chopper.



Figure 4: The SOGO PIC-SS-5262 disassembled for cleaning. The image shows the motor unit, the stainless steel bowl, the transparent lid, and the blade assemblies, emphasizing the ease of cleaning due to removable parts.

1. **Unplug:** Always unplug the appliance before cleaning.
2. **Motor Unit:** Wipe the motor unit with a damp cloth. Do not immerse it in water or any other liquid.
3. **Chopping Bowl, Lid, and Blades:** These parts are detachable and can be washed with warm soapy water. Rinse

thoroughly and dry immediately. They are also dishwasher-safe.

4. **Blade Care:** Handle the blades with extreme caution as they are very sharp. Use a brush to clean them if necessary. Store them safely when not in use.
5. **Drying:** Ensure all parts are completely dry before reassembling or storing the appliance.
6. **Storage:** Store the food chopper in a cool, dry place, away from direct sunlight and out of reach of children.

Troubleshooting

If you encounter issues with your SOGO PIC-SS-5262 Food Chopper, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet faulty; motor unit not properly seated; lid not securely locked.	Check power cord connection; try a different outlet; ensure motor unit is correctly placed on the lid; ensure lid is securely locked.
Blades are not rotating or rotating slowly.	Overloaded bowl; ingredients too large or hard; blade assembly not properly installed.	Reduce the amount of ingredients; cut ingredients into smaller pieces; ensure blade assembly is correctly placed on the shaft.
Appliance stops during operation.	Overheating protection activated.	Unplug the appliance and let it cool down for at least 15-20 minutes before resuming operation.
Food is unevenly chopped.	Too many ingredients; not enough liquid (for pureeing); ingredients stuck to sides.	Process in smaller batches; add a small amount of liquid if pureeing; stop and scrape down the sides of the bowl.

Specifications

Feature	Detail
Brand	SOGO
Model	PIC-SS-5262
Power	500W
Capacity	1.8 Liters
Bowl Material	SUS304 Stainless Steel
Blade Material	Titanium-coated
Speed Settings	2 (Dual Speed)
Special Features	BPA-free transparent lid, Non-slip base, Automatic shut-off

Feature	Detail
Dimensions	60 x 60 x 85 cm
Weight	2 Kilograms

Warranty and Support

SOGO products are manufactured to high-quality standards. For warranty information and customer support, please refer to the warranty card included with your product or visit the official SOGO website.

For technical assistance or spare parts, please contact SOGO customer service.

Please retain your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09FTM8JQ1

More documents and user manuals: **https://manuals.plus/**