Eureka Forbes Robo LVac

Eureka Forbes Robo LVAC Robotic Vacuum Cleaner User Manual

Model: Robo LVac

1. Introduction

This manual provides essential instructions for the safe and efficient operation, maintenance, and troubleshooting of your Eureka Forbes Robo LVAC robotic vacuum cleaner. Please read this manual thoroughly before using the appliance and retain it for future reference.



Image 1.1: Top view of the Eureka Forbes Robo LVAC robotic vacuum cleaner, showcasing its sleek black design and control buttons.

2. Product Overview

2.1 Package Contents

- Robotic Vacuum Cleaner
- Charging Dock
- Remote Control
- User Manual

2.2 Key Features

- **2-Stage Cleaning Action:** Combines powerful dry vacuuming and wet mopping capabilities.
- **Smart App Control:** Operate and manage the robot remotely via a dedicated smartphone application.
- **Remote Control Operation:** Provides an alternative method for controlling the robot and setting cleaning

schedules.

- **Powerful Suction:** Equipped with 1400 Pa suction power for effective dirt and debris removal.
- **Thermal Cut-off Mechanism:** Automatically switches off the device to prevent overheating and ensure safety.
- **LDS Navigation:** Laser Distance Sensor (LDS) for precise mapping and navigation.
- **Electric Water Tank:** Allows for controlled mopping and adjustable water flow.
- **Long-lasting Battery:** Provides approximately 100 minutes of runtime on a single charge.
- **Anti-Fall Sensors:** Detects stairs and other drops to prevent falls.
- **Collision Avoidance:** High precision sensors detect obstacles from a distance of 1cm.
- **HEPA Filter:** Traps fine dust particles, hair, pollen, mold, and other minute bacteria.



Image 2.1: The robotic vacuum cleaner performing both dry vacuuming (left) and wet mopping (right) functions on a hard floor.

3. Setup

3.1 Unpacking and Placement

1. Carefully remove all components from the packaging.
2. Choose a suitable location for the charging dock. Ensure it is placed against a wall, with at least 0.5 meters of clear space on either side and 1.5 meters in front, free from obstacles.
3. Connect the power adapter to the charging dock and plug it into a power outlet.

3.2 Initial Charging

Place the Robo LVAC onto the charging dock. Ensure the charging contacts on the robot align with those on the dock. The indicator light on the robot will show charging status. Fully charge the robot before its first use, which may take several hours.

3.3 App Installation and Pairing

1. Download the Eureka Forbes Smart App from your device's app store.
2. Register or log in to your account.
3. Follow the in-app instructions to add your Robo LVAC device. This typically involves connecting the robot to your home Wi-Fi network.



Image 3.1: A hand holding a smartphone with the Eureka Forbes app interface, showing a floor plan and control options for the robotic vacuum cleaner.

4. Operating Instructions

4.1 Starting and Stopping Cleaning

- **Via Robot:** Press the power button on the robot to start or pause cleaning.
- **Via App:** Use the 'Start' or 'Pause' function within the Eureka Forbes Smart App.
- **Via Remote Control:** Use the designated buttons on the remote control.

4.2 Dry Vacuuming

Ensure the dustbin is empty and properly installed. The robot will automatically detect the floor type and adjust suction power. For deep cleaning, activate 'Turbo Mode' via the app or remote.



Image 4.1: An internal diagram illustrating the turbo mode, indicating increased suction power for thorough cleaning.

4.3 Wet Mopping

1. Fill the electric water tank with clean water. Do not use detergents or cleaning solutions not approved by Eureka Forbes.
2. Attach the mop pad securely to the water tank.
3. Install the water tank assembly into the robot.
4. Select the mopping function and desired water flow level via the app or remote control.



Image 4.2: The robotic vacuum cleaner with its electric water tank, demonstrating controlled water release for mopping.

4.4 Scheduling Cleaning

Use the Eureka Forbes Smart App or the remote control to set specific cleaning schedules. The robot will automatically start cleaning at the programmed times.



Image 4.3: The robotic vacuum cleaner operating quietly in a bedroom, with a smartphone displaying a scheduled cleaning time of 12:00 AM.

4.5 Room Mapping and Restricted Zones

The robot utilizes LDS navigation to create a detailed map of your home. Through the app, you can view this map, select specific rooms or areas for cleaning, and define restricted zones where the robot should not enter.



Image 4.4: A visual representation of the robotic vacuum cleaner using laser technology to map the layout of a room.



Image 4.5: The robotic vacuum cleaner operating near a virtual restricted zone, indicated by a red grid, which it will not enter.

4.6 Auto-Charging

When the battery level is low, the Robo LVAC will automatically return to its charging dock. After recharging, it will resume cleaning from where it left off.



Image 4.6: The robotic vacuum cleaner automatically docking with its charging station.

5. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your Robo LVAC.

5.1 Cleaning the Dustbin and Filters

1. Press the dustbin release button and remove the dustbin.
2. Empty the dust and debris into a waste bin.
3. Remove the HEPA filter and primary filter. Tap them gently to remove dust. Do not wash the HEPA filter with water.
4. Rinse the primary filter and dustbin with water if necessary, ensuring they are completely dry before reinstallation.




Image 5.1: A visual representation of the HEPA filter's effectiveness in trapping microscopic dust particles and allergens.

5.2 Cleaning Brushes

- Remove the main brush cover and lift out the main brush.
- Use the cleaning tool (if provided) to remove hair and debris tangled around the main brush.
- Gently pull off the side brushes and remove any tangled hair or debris. Reinstall them securely.




Image 5.2: An illustration of the dual multi-surface brush system, showing how it channels dirt towards the suction inlet.

5.3 Cleaning the Water Tank and Mop Pad

- Empty any remaining water from the electric water tank after each mopping session.
- Remove the mop pad and rinse it thoroughly with water. Allow it to air dry completely before reuse.

5.4 Cleaning Sensors

Wipe all sensors (anti-fall sensors, collision sensors, LDS sensor window) with a clean, dry cloth to ensure proper functionality.

6. Troubleshooting

If you encounter issues with your Robo LVAC, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Robot does not start or respond.	Low battery; Power switch off; Robot stuck.	Charge the robot; Ensure power switch is ON; Clear any obstructions.
Poor cleaning performance.	Full dustbin; Clogged brushes/filters; Low suction mode.	Empty dustbin; Clean brushes and filters; Select 'Turbo Mode'.
Robot cannot return to charging dock.	Dock obstructed; Dock not powered; Robot too far.	Clear area around dock; Check power connection; Manually place robot near dock.
App connectivity issues.	Incorrect Wi-Fi password; Robot out of Wi-Fi range; App not updated.	Verify Wi-Fi credentials; Move robot closer to router; Update app to latest version.
Robot falls down stairs.	Dirty anti-fall sensors.	Clean the anti-fall sensors thoroughly.

7. Specifications

Feature	Detail
Brand	Eureka Forbes
Model Name	Robo LVac
Item Model Number	GFCDFRBLV00000
Product Dimensions	13.2L x 13.2W x 3.8H Centimeters
Item Weight	2 kg 400 g
Colour	Black
Special Features	High Precision Sensors, Lightweight, Spotless Cleaning, Wheels
Battery Life	100 Minutes
Power Source	Battery Powered

Feature	Detail
Control Method	Remote, App
Form Factor	Robotic
Surface Recommendation	Hard Floor

8. Warranty and Support

8.1 Warranty Information

The Eureka Forbes Robo LVAC comes with a**1-year warranty** from the date of purchase. Please retain your purchase receipt as proof of warranty.

8.2 Customer Support

For any service, support, or queries regarding your product, please contact Eureka Forbes customer service. Free post-purchase personalized virtual (online) demo is available for this product.
Refer to the contact information provided in your warranty card or visit the official Eureka Forbes website for assistance.

© 2023 Eureka Forbes. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question