Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZdalaMit NB179UD

ZdalaMit NB179UD Replacement Remote Control User Manual

For Magnavox DVD VCR Player Models: MWD2206A, MWD2205, MWD2206

1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your ZdalaMit NB179UD replacement remote control. This remote is specifically designed to be compatible with select Magnavox DVD VCR Player models, ensuring seamless control of your device.

Please read this manual thoroughly before using the remote control to ensure proper functionality and to maximize your user experience.

2. Product Overview

The ZdalaMit NB179UD is a direct replacement remote control, eliminating the need for complex programming. It replicates the functions of the original remote for your Magnavox DVD VCR player.





Image 1: Front view of the ZdalaMit NB179UD Replacement Remote Control. The remote is dark gray with white and green buttons, including number keys, playback controls, and function buttons for DVD and VCR operations.

Compatible Models:

- Magnavox MWD2206A DVD VCR Player
- Magnavox MWD2205 DVD VCR Player
- Magnavox MWD2206 DVD VCR Player

3. Setup

3.1 Battery Installation

The remote control requires two (2) 1.5V AA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Important: Ensure batteries are inserted with correct polarity. Incorrect installation can damage the remote control.

3.2 Initial Use

No programming is required for this replacement remote control. Once the batteries are correctly installed, the remote is ready for immediate use with your compatible Magnavox DVD VCR Player.

4. Operating Instructions

Point the remote control directly at the infrared sensor on your Magnavox DVD VCR Player. Ensure there are no obstructions between the remote and the player.

4.1 Basic Functions

- **STANDBY-ON:** Powers the device on or off.
- **OPEN/CLOSE / EJECT:** Opens or closes the disc tray, or ejects a VCR tape.
- **Number Buttons (0-9, +10):** Used for direct track/chapter selection or channel input.
- **PLAY, STOP, PAUSE:** Standard playback controls for DVD and VCR.
- **REWIND, FAST FORWARD, SKIP:** Navigation controls for media playback.
- **RECORD:** Initiates recording on the VCR.
- **VCR/TV:** Switches between VCR and TV input modes.
- **MENU, SETUP, TOP MENU:** Accesses various menu options for DVD or VCR settings.
- **DISPLAY:** Shows on-screen information.
- **AUDIO:** Changes audio tracks or modes.
- **ZOOM:** Adjusts the screen zoom level.
- **SUBTITLE:** Toggles or selects subtitle options.
- **CLEAR:** Clears current input or selection.

Refer to your Magnavox DVD VCR Player's original manual for detailed instructions on specific functions and menu navigation.

5. Maintenance

5.1 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's finish or internal components.

5.2 Storage

When not in use for extended periods, store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for several weeks or months, it is recommended to remove the batteries to prevent leakage and potential damage.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old or depleted batteries with new 1.5V AA alkaline batteries.
  - Ensure there is a clear line of sight between the remote control and the infrared sensor on your Magnavox DVD VCR Player. Remove any obstructions.
  - Verify that the remote is pointed directly at the player's sensor.
- **Limited range or intermittent response:**
  - Replace batteries, even if they seem partially functional.
  - Ensure no strong light sources (like direct sunlight or bright fluorescent lights) are interfering with the infrared signal.
  - Clean the remote's infrared emitter and the player's sensor with a soft cloth.
- **Specific button not working:**
  - Ensure the remote is compatible with your specific Magnavox model (MWD2206A, MWD2205, MWD2206).
  - If other buttons work, the specific button might be stuck or damaged.

If troubleshooting steps do not resolve the issue, please refer to the "7. Warranty and Support" section.

7. Specifications

Feature	Detail
Model	NB179UD (also known as NB179)
Compatibility	Magnavox DVD VCR Player models MWD2206A, MWD2205, MWD2206
Power Supply	2 x 1.5V AA Alkaline Batteries (not included)
Connectivity Technology	Infrared (IR)
Product Dimensions	6 x 2 x 0.6 inches (approximately)
Item Weight	1.41 ounces (without batteries)

8. Warranty and Support

This ZdalaMit replacement remote control is designed for reliable performance. For any questions, concerns, or issues not covered in this manual, please contact the seller or manufacturer directly through your purchase platform.

Please retain your proof of purchase for any warranty claims or support inquiries.

© 2025 ZdalaMit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09G9BGH24

More documents and user manuals: **https://manuals.plus/**