ZdalaMit BN59-01357A

ZdalaMit BN59-01357A Replacement Voice Remote Control User Manual

For Samsung Smart TVs

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your ZdalaMit BN59-01357A Replacement Voice Remote Control. Please read this manual thoroughly before using the remote control to ensure proper functionality and to maximize your user experience. This remote is designed as a direct replacement for various Samsung Smart TV models.

2. Product Overview

The ZdalaMit BN59-01357A is a replacement voice-enabled remote control for compatible Samsung Smart TVs. It features essential buttons for navigation, volume, channel control, and quick access to popular streaming services, along with voice command capabilities.





Figure 2.1: Front view of the ZdalaMit BN59-01357A Replacement Voice Remote Control. This image displays the remote's layout, including the power button, number pad access, microphone button, navigation pad, volume and channel controls, and dedicated buttons for Netflix, Prime Video, and Samsung TV Plus.

3. Setup and Pairing

3.1 Battery Installation

The remote control requires two (2) AA batteries for operation. To install batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover until it clicks securely into place.

3.2 Pairing with Your Samsung TV

Before using the remote control, it must be paired with your Samsung Smart TV. Follow these steps to pair the remote:

1. Ensure your Samsung TV is powered on.
2. Point the remote control towards your TV.
3. Simultaneously press and hold the **Return** button (curved arrow) and the **Play/Pause** button (triangle and two vertical lines) for approximately 3 seconds.
4. A pairing message should appear on your TV screen, indicating that the remote control is connecting.
5. Once paired, the remote control is ready for use.

If pairing fails, ensure the batteries are correctly installed and try the pairing process again. Move closer to the TV if necessary.

4. Operating Instructions

This section outlines the primary functions of the buttons on your ZdalaMit BN59-01357A remote control.

- **Power Button** (⏻): Turns the TV on or off.
- **Voice Assistant Button** (🎙): Activates the voice assistant for commands such as searching for content, changing settings, or launching apps. Press and hold to speak your command.







Figure 4.1: Remote control highlighting the Voice Assistant button. This button, marked with a microphone icon, is used to activate voice commands for your Samsung TV.

- **123 Button**: Accesses the on-screen numeric keypad for channel input or other numerical entries.
- **Multi-View/Source Button**: Changes the input source or activates multi-view features on compatible TVs.
- **Navigation Pad (Up, Down, Left, Right, Enter)**: Used to navigate menus, select items, and confirm choices.
- **Return Button**: Returns to the previous screen or menu.
- **Home Button**: Returns to the TV's Smart Hub or home screen.
- **Play/Pause Button**: Controls media playback (play, pause).
- **Volume Up/Down Buttons**: Adjusts the TV volume.
- **Channel Up/Down Buttons**: Changes TV channels.
- **CC/VD Button**: Toggles Closed Captions/Video Description.
- **Dedicated App Buttons (NETFL, prm video, Smsung TV Plus)**: Provides direct access to these streaming applications.



Figure 4.2: The ZdalaMit BN59-01357A remote control shown in a typical living room environment, positioned near a Samsung TV and soundbar setup. This illustrates the remote's intended use with a television system.

5. Maintenance

5.1 Cleaning

To clean your remote control, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals or abrasive materials, as these can damage the remote's surface or internal components.

5.2 Battery Replacement

Replace batteries when the remote control becomes unresponsive or its range decreases significantly. Always replace both AA batteries at the same time with new ones. Do not mix old and new batteries, or different types of batteries.

6. Troubleshooting

- **Remote not responding:**
  - Check if the batteries are correctly installed and have sufficient charge. Replace them if necessary.
  - Ensure there are no obstructions between the remote control and the TV's sensor.

- Re-pair the remote control with your TV by following the instructions in Section 3.2.

- **Voice commands not working:**
  - Ensure the remote is properly paired.
  - Speak clearly and hold the remote closer to your mouth when pressing the Voice Assistant button.
  - Check your TV's settings to ensure the voice assistant feature is enabled.
- **Delayed response from remote:**
  - This can sometimes occur due to interference or a weak battery signal. Try replacing the batteries.
  - Ensure the remote is pointed directly at the TV.
  - If the issue persists, re-pairing the remote might resolve it.

7. Specifications

Model Number	BN59-01357A
Brand	ZdalaMit
Compatible Devices	Samsung Televisions
Special Feature	Voice Search
Color	Black
Batteries Required	2 AA batteries
Product Dimensions	6 x 2 x 0.5 inches
Item Weight	1.41 ounces





Figure 7.1: Image illustrating the dimensions of the ZdalaMit BN59-01357A remote control, showing its length as 6.3 inches and width as 1.38 inches.

8. Compatible Samsung TV Models

This ZdalaMit BN59-01357A replacement remote control is compatible with a wide range of Samsung Smart TV models. A partial list of compatible models includes, but is not limited to:

- QN65QN9DAAFXZA
- QN43LS03AAFXZA
- QN55Q6DAAFXZA
- QN50LS03AAFXZA
- QN55LS03AAFXZA
- QN65LS03AAFXZA

- QN75LS03AAFXZA
- QN50Q6DAAFXZA
- QN60Q6DAAFXZA
- QN50Q80AAFXZA
- QN65Q8DAAFXZA
- QN55Q80AAFXZA
- QN55Q8DAAFXZA
- QN65Q80AAFXZA
- QN75QN9DAAFXZA
- QN75Q80AAFXZA
- QN85Q80AAFXZA
- QN55Q70AAFXZA
- QN75QN850AFXZA
- QN85Q6DAAFXZA
- QN65Q70AAFXZA
- QN75Q70AAFXZA
- QN85Q70AAFXZA
- QN75Q6DAAFXZA
- QN32Q60AAFXZA
- QN85Q8DAAFXZA
- QN43Q60AAFXZA
- QN50Q60AAFXZA
- QN55Q60AAFXZA
- QN60Q60AAFXZA
- QN65Q60AAFXZA
- QN70Q60AAFXZA
- QN75Q60AAFXZA
- QN85Q60AAFXZA
- QN43LS03ADFXZA
- QN50LS03ADFXZA
- QN55LS03ADFXZA
- QN65LS03ADFXZA
- QN75LS03ADFXZA
- QN65QN850AFXZA
- QN70Q60AAVXZA
- QN43Q6DAAFXZA
- QN65Q6DAAFXZA
- QN70Q6DAAFXZA
- QN50Q8DAAFXZA
- QN75Q8DAAFXZA
- QN50QN9DAAFXZA
- QN85QN9DAAFXZA
- QN55Q7DAAFXZA
- QN65Q7DAAFXZA
- QN75Q7DAAFXZA

- QN85Q7DAAFXZA
- QN55QN85DAFXZA
- QN65QN85DAFXZA
- QN75QN85DAFXZA
- QN85QN85DAFXZA

For a complete list of compatible models, please refer to your TV's documentation or the product listing.