Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Techwood Techwood 1200W Single Infrared Ceramic Electric Stove (B09H2JLPQH)

Techwood 1200W Single Infrared Ceramic Electric Stove Instruction Manual

Model: B09H2JLPQH

1. Introduction

Thank you for choosing the Techwood 1200W Single Infrared Ceramic Electric Stove. This portable and versatile appliance is designed to provide efficient cooking for various needs, whether at home, in an RV, or during camping. Its advanced infrared heating technology ensures quick and even heat distribution, compatible with all types of cookware. Please read this manual thoroughly before use to ensure safe and optimal operation.



Figure 1: Techwood 1200W Single Infrared Ceramic Electric Stove. This image displays the compact, black single burner unit with its control knob and indicator light.

2. Important Safety Instructions

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical hazards, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.
- Ensure proper ventilation during initial use to dissipate any protective coating odors.

3. Product Features

- **Advanced Heating Technology:** Features thermostatically controlled heating settings, advanced infrared thermal cycling, and thermal protection for efficient cooking.
- **Portable & Compact Design:** Easy to control with a timeless stainless steel and crystallite glass design. Its mini size saves kitchen space, making it ideal for dorms, offices, RVs, and camping.
- **Multi-Function & Fast Heating:** Works with all types of cookware including aluminum, copper, cast iron, and non-magnetic stainless steel pans. Infrared heating cooks efficiently with minimal heat loss.
- **Safe & Easy to Clean:** Equipped with overheat protection and a stylish indicator light for safe use. An automatic safety shutoff function regulates temperature. The brushed stainless steel body is easy to wipe clean when cool. Non-slip feet ensure stability.



Figure 2: Close-up of the Techwood Hot Plate highlighting its easy controls and smooth, easy-to-clean surface. The image shows the temperature knob and the indicator light.

4. Setup

1. **Unpack:** Carefully remove the hot plate from its packaging. Retain packaging for future storage or transport.
2. **Placement:** Place the hot plate on a stable, flat, heat-resistant surface, away from flammable materials. Ensure there is adequate ventilation around the unit.
3. **Initial Burn-off:** Before first use, turn the appliance to its highest setting for 3-5 minutes without any cookware. This procedure helps to condition the protective coating on the heating elements and internal accessories, which may produce a slight odor or smoke. Ensure the area is well-ventilated during this process. This should only be done once.
4. **Power Connection:** Plug the appliance into a standard 120V AC electrical outlet.

5. Operating Instructions

1. **Place Cookware:** Position your desired cookware (pot or pan) centrally on the 7.1-inch heating surface.

2. **Adjust Temperature:** Turn the temperature and power control knob to your desired heat setting (Min to Max). The indicator light will illuminate, signaling that the burner is heating.
3. **Cooking:** Allow the burner to preheat for a few minutes before adding food for optimal results.
4. **Automatic Shutoff:** The hot plate features an automatic safety shutoff function. The indicator light will turn off when the set temperature is reached and turn back on when heating resumes to maintain the temperature.
5. **After Use:** Once cooking is complete, turn the control knob to the 'OFF' position and unplug the appliance from the wall outlet.



Figure 3: Illustration of the precise temperature control knob, showing settings for 'Keep Warm', 'Stir Fry', and 'Deep Fry'.

6. Maintenance and Cleaning

1. **Cool Down:** Always ensure the hot plate is completely cool before attempting to clean it.
2. **Unplug:** Disconnect the appliance from the power outlet before cleaning.
3. **Cleaning Surface:** Wipe the stainless steel body and crystallite glass cooktop with a damp, soft cloth. For stubborn stains, a mild detergent can be used. Avoid abrasive cleaners, scouring pads, or harsh chemicals that could damage the surface.

4. **Do Not Immerse:** Never immerse the hot plate in water or any other liquid.
5. **Storage:** Store the appliance in a dry place when not in use.

7. Troubleshooting

- **Appliance not heating:**
  - Ensure the power cord is securely plugged into a working 120V outlet.
  - Check if the temperature control knob is turned to an 'ON' position.
  - Verify that the indicator light is illuminated. If not, the unit may not be receiving power or may be in automatic shutoff mode if the desired temperature has been reached.
- **Unusual odor/smoke during initial use:** This is normal due to the protective coating burning off. Ensure good ventilation.
- **Food not cooking evenly:** Ensure your cookware is flat-bottomed and makes full contact with the heating surface. Adjust temperature as needed.

8. Specifications

Brand	Techwood
Model	B09H2JLPQH
Color	Black
Material	Stainless Steel
Heating Elements	1
Cooktop Diameter	7.1 inches
Wattage	1200 watts
Controls Type	Knob
Burner Type	Radiant (Infrared Ceramic)
Product Dimensions	4.4"D x 16"W x 12"H
Item Weight	4.18 pounds
Power Source	Electric
UPC	735279781373, 735279781649

9. Warranty and Support

Techwood products are covered by Product Liability Insurance of the United States. For specific details regarding warranty coverage and claims, please refer to the documentation included with your purchase or contact Techwood customer support. For any questions or assistance, please reach out to our customer service team.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09H2JLPQH

More documents and user manuals: **https://manuals.plus/**