TELESIN TE-RCSS-001

TELESIN Selfie Stick with BT Remote (TE-RCSS-001) User Manual

Model: TE-RCSS-001

1. Introduction

This manual provides detailed instructions for the safe and effective use of your TELESIN Selfie Stick with Bluetooth Remote, model TE-RCSS-001. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity. This versatile accessory is designed for use with smartphones and action cameras, offering extended reach and stable support for photography and videography.

2. Product Overview

The TELESIN Selfie Stick (TE-RCSS-001) combines a telescopic monopod with an integrated tripod and a detachable Bluetooth remote control. Key components include:

- **Telescopic Pole:** Extendable sections for adjustable length.
- **Device Mount:** Universal screw mount for cameras and adjustable clamp for smartphones.
- **Integrated Tripod:** Foldable legs for stable freestanding use.
- **Bluetooth Remote Control:** Detachable remote for wireless shutter control.



Figure 1: TELESIN Selfie Stick with Bluetooth Remote and Tripod Base. The image displays the TELESIN selfie stick fully extended with a camera mounted, a detachable Bluetooth remote control, and the integrated tripod legs deployed.

3. Setup

3.1 Attaching Your Device

1. **For Action Cameras:** Align the camera's mounting bracket with the selfie stick's universal screw

mount. Secure it tightly using the provided screw.

2. **For Smartphones:** Open the adjustable phone clamp and carefully insert your smartphone. Ensure the phone is securely held and balanced.

3.2 Bluetooth Remote Pairing

The Bluetooth remote control allows for wireless photo and video capture.

1. Ensure the remote control is charged (if applicable) and powered on. The power button is typically marked with a **power symbol (circle with a line)**.
2. On your smartphone, navigate to the Bluetooth settings.
3. Search for available devices. The remote will appear as "TELESIN Remote" or similar.
4. Select the remote to pair. Once paired, the indicator light on the remote will typically stop flashing and remain solid.

3.3 Extending the Selfie Stick and Deploying the Tripod

- **To Extend:** Gently pull the telescopic sections upwards until the desired length is achieved. Ensure each section is securely locked in place.
- **To Deploy Tripod:** Locate the base of the selfie stick. Spread the three legs outwards until they form a stable tripod base. Ensure the legs are fully extended and locked.
- **To Retract:** Collapse the tripod legs inward. Push the telescopic sections back into the main body until fully retracted.

4. Operating Instructions

4.1 Using the Bluetooth Remote

- **Shutter Button:** Press the main button (often marked with a camera icon or a large circular button) to take a photo or start/stop video recording.
- **Mode Button (if applicable):** Some remotes may have a 'M' button to switch between photo and video modes on your connected device. Refer to your device's camera app for specific compatibility.

4.2 Adjusting Angles

The device mount typically allows for rotation and tilting. Loosen the adjustment knob, position your device to the desired angle, and then tighten the knob to secure it.

5. Maintenance

- **Cleaning:** Wipe the selfie stick with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the telescopic pole is fully retracted before storage.
- **Battery Care (Remote):** If the remote uses a rechargeable battery, charge it regularly. If it uses a replaceable battery, replace it when power is low.

6. Troubleshooting

- **Remote Not Connecting:**
    a. Ensure the remote is powered on and charged.

b. Check your smartphone's Bluetooth settings to ensure Bluetooth is enabled.
c. Try unpairing and re-pairing the remote.
d. Restart both your smartphone and the remote.

- **Device Not Stable:**

a. Ensure your smartphone or camera is securely fastened in its mount.
b. Verify that all telescopic sections are fully extended and locked.
c. If using the tripod, ensure the legs are fully spread and on a flat, stable surface.

- **Remote Not Triggering Shutter:**

a. Confirm the remote is successfully paired.
b. Check your camera app settings; some apps may require specific settings for external shutter control.
c. Ensure the remote's battery is not depleted.

7. Specifications

Feature	Detail
Brand	TELESIN
Model	TE-RCSS-001
Color	Black
Compatible Devices	Digital Camera, Smartphones
Battery Type (Remote)	Lithium Polymer
Package Dimensions (L x W x H)	18.3 x 6.1 x 4.1 centimeters
UPC	716053672315

8. Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official TELESIN website. You may also contact your retailer for assistance.

© 2023 TELESIN. All rights reserved.