Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dettol No-Touch Automatic Soap Dispenser Kit

Dettol No-Touch Automatic Soap Dispenser and Disinfectant Kit User Manual

Model: No-Touch Automatic Soap Dispenser Kit

Product Overview

This manual provides instructions for the Dettol No-Touch Automatic Soap Dispenser Device with Aloe Vera Refill and the Dettol Liquid Disinfectant, Lime Fresh, 1L. Please read these instructions carefully before use to ensure proper operation and safety.



Image: The Dettol No-Touch Automatic Soap Dispenser Device with an Aloe Vera refill bottle.



Image: Dettol Liquid Disinfectant in Lime Fresh scent, 1000ml bottle.

Package Contents

- 1 x Dettol No-Touch Automatic Soap Dispenser Device
- 2 x Dettol No-Touch Aloe Vera Handwash Refill, 250ml each
- 1 x Dettol Liquid Disinfectant, Lime Fresh, 1L
- Batteries (may be included, check packaging)

Setup: Dettol No-Touch Automatic Soap Dispenser

1. Battery Installation

1. Locate the battery compartment on the bottom or back of the dispenser.
2. Open the battery compartment cover.
3. Insert the required number of AA batteries (typically 3, check dispenser for exact requirement) according to the polarity indicators (+/-).

4. Close the battery compartment cover securely.

2. Refill Installation

1. Ensure the dispenser is turned off or batteries are removed before installing the refill.
2. Remove the protective seal from the Dettol No-Touch Aloe Vera Handwash Refill bottle.
3. Align the refill bottle with the opening in the dispenser unit.
4. Push the refill firmly into the dispenser until it clicks into place. Do not force it.



Image: Illustration of the Dettol No-Touch Dispenser with a refill bottle, demonstrating how it fits together.

Operating Instructions

Using the Dettol No-Touch Automatic Soap Dispenser

1. Place the dispenser on a flat, stable surface near a sink.
2. Turn on the dispenser (if it has an on/off switch).
3. Place your hand under the nozzle. The sensor will detect your hand and dispense a measured amount of soap.

4. Rub your hands together thoroughly for at least 20 seconds, then rinse with water.

Note: For first-time use, you may need to place your hand under the sensor a few times to prime the pump and allow the soap to dispense.

Using the Dettol Liquid Disinfectant, Lime Fresh

The Dettol Liquid Disinfectant is suitable for various household cleaning tasks. Always dilute as directed for specific uses.

- **General Disinfection:** Add 1 capful (approx. 20ml) to 1 liter of water for general surface cleaning.
- **Floor Cleaning:** Add 2 capfuls (approx. 40ml) to 1 liter of water for mopping floors.
- **Laundry Disinfection:** Add 1 capful (approx. 20ml) to the final rinse cycle of your laundry.
- **Personal Hygiene (Bathing):** Add 1 capful (approx. 20ml) to a bucket of water for bathing.

Always read the label on the disinfectant bottle for specific dilution ratios and usage instructions.



Image: A person mopping a floor, illustrating the use of Dettol Disinfectant Liquid for household cleaning.

Maintenance

Dettol No-Touch Automatic Soap Dispenser

- **Cleaning:** Wipe the exterior of the dispenser with a damp cloth. Do not submerge the dispenser in water.
- **Refilling:** When the soap level is low, replace the empty Dettol No-Touch refill bottle with a new one as per the "Refill Installation" steps.
- **Battery Replacement:** When the dispenser stops working or the indicator light (if present) signals low battery, replace all batteries with new ones.

Dettol Liquid Disinfectant

- Store the bottle in a cool, dry place, away from direct sunlight and out of reach of children.
- Ensure the cap is tightly closed after each use.

Troubleshooting: Dettol No-Touch Automatic Soap Dispenser

Problem	Possible Cause	Solution
Dispenser does not turn on.	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with new batteries.
No soap dispenses.	• Soap refill is empty. • Dispenser is not primed. • Sensor is obstructed or dirty. • Dispenser is off.	• Replace soap refill. • Place hand under sensor multiple times to prime. • Clean the sensor area. • Ensure dispenser is switched on.
Soap dispenses inconsistently.	Low battery power.	Replace batteries.

Safety Information

- Keep all Dettol products out of reach of children and pets.
- For external use only. Avoid contact with eyes. In case of contact, rinse immediately with plenty of water.
- Do not ingest. If swallowed, seek medical advice immediately and show this container or label.
- Do not mix Dettol Liquid Disinfectant with other cleaning agents.
- Dispose of used batteries and empty refill bottles according to local regulations.
- Do not expose the automatic dispenser to excessive moisture or direct water spray.

Specifications

- **Brand:** Dettol
- **Dispenser Type:** No-Touch Automatic
- **Handwash Refill Volume:** 250ml (Aloe Vera)
- **Disinfectant Liquid Volume:** 1000ml (Lime Fresh)
- **Power Source (Dispenser):** Batteries (typically AA, quantity varies by model)
- **Special Feature:** Antibacterial
- **Item Form:** Liquid

- **Skin Type (Handwash):** All
- **Recommended Uses:** Hand hygiene, surface disinfection, floor cleaning, laundry.

Warranty and Support

For warranty information and customer support, please refer to the packaging or contact Dettol customer service directly. Keep your purchase receipt as proof of purchase.
Manufacturer: Dettol
Date First Available: 4 May 2022

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HNYVHRK

More documents and user manuals: **https://manuals.plus/**