Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DJI CP.OS.00000193.01

DJI Black Floating Handle User Manual

Model: CP.OS.00000193.01

1. Introduction

This user manual provides comprehensive instructions for the safe and effective use of the DJI Black Floating Handle. Designed for action cameras like DJI Action 2 and Osmo Action, this accessory ensures your camera remains buoyant in water, preventing loss during aquatic activities. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

2. Product Overview

The DJI Floating Handle is an essential accessory for capturing footage in and around water. Its primary function is to provide buoyancy, keeping your action camera afloat if it detaches or is dropped in water. The handle features a comfortable, non-slip grip for secure handling and includes a wrist strap for added security.



Figure 2.1: The DJI Black Floating Handle, showing the main body, wrist strap, and included mounting screw.

3. Components

The DJI Floating Handle package includes the following components:

- **DJI Floating Handle:** The main buoyant handle with a non-slip grip.
- **Osmo Mounting Screw:** A standard screw for attaching compatible action cameras to the handle.
- **Osmo Action Lanyard/Wrist Strap:** A durable strap to secure the handle to your wrist, preventing accidental drops.



Figure 3.1: All components of the DJI Floating Handle package, including the handle, mounting screw, and wrist strap.



Figure 3.2: Side profile of the DJI Floating Handle, highlighting its ergonomic design.

4. Setup Guide

Follow these steps to set up your DJI Floating Handle:

1. **Attach the Wrist Strap:** Thread the lanyard through the designated loop at the base of the handle and secure it. Ensure it is firmly attached.
2. **Mount Your Camera:** Align your DJI Action 2 or Osmo Action camera's mounting bracket with the attachment point on the top of the floating handle.
3. **Secure with Screw:** Insert the provided Osmo Mounting Screw through the camera's bracket and into the handle's attachment point. Tighten the screw firmly by hand until the camera is secure and does not wobble. Do not overtighten.
4. **Test Connection:** Gently tug on the camera to ensure it is securely fastened to the handle before use, especially in water.



Figure 4.1: A DJI Action camera securely mounted on the Floating Handle, ready for use.

5. Operating Instructions

The DJI Floating Handle is designed for intuitive use in aquatic environments.

- **Before Water Use:** Always ensure your camera is properly sealed and waterproof according to its own specifications before attaching it to the floating handle and entering water.
- **Secure Grip:** Hold the handle firmly using its non-slip grip. For added security, always use the wrist strap and keep it around your wrist while filming in water.
- **Buoyancy:** In the event the handle is dropped in water, its hollow design will cause it to float to the surface, making it easy to retrieve your camera.
- **Filming:** Use the handle to stabilize your camera and capture steady footage while swimming, snorkeling, or engaging in other water sports.

6. Maintenance

Proper maintenance will extend the life of your DJI Floating Handle:

- **Rinse After Use:** After each use in saltwater or chlorinated water, rinse the handle thoroughly with fresh water to prevent corrosion and residue buildup.
- **Dry Completely:** Allow the handle to air dry completely before storing. Do not store in damp conditions.
- **Inspect Regularly:** Periodically check the handle and mounting screw for any signs of wear, damage, or corrosion. Replace components if necessary.
- **Storage:** Store the handle in a cool, dry place away from direct sunlight and extreme temperatures.

7. Troubleshooting

If you encounter issues with your DJI Floating Handle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Handle does not float.	Handle is not hollow or has been compromised.	Ensure the handle is genuine DJI product. If damaged, replace the handle.
Camera feels loose on the handle.	Mounting screw is not tightened sufficiently or is worn.	Tighten the mounting screw firmly. If the screw is stripped or damaged, replace it.
Corrosion on metal parts.	Insufficient rinsing after use in saltwater/chlorine.	Rinse thoroughly with fresh water after every use. For existing corrosion, clean gently with a soft brush and fresh water.

8. Specifications

Key specifications for the DJI Floating Handle:

Feature	Detail
Brand	DJI
Model Number	CP.OS.00000193.01
Color	Black
Compatible Devices	DJI Action 2, DJI Osmo Action Camera
Product Dimensions (L x W x H)	19 x 5 x 5 cm (7.5 x 2 x 2 inches)
Item Weight	82 Grams (2.9 ounces)
UPC	190021047761
Included Components	DJI Floating Handle × 1, Osmo Mounting Screw × 1, Osmo Action Lanyard × 1

9. Warranty and Support

For information regarding warranty coverage and customer support for your DJI Floating Handle, please refer to the official DJI website or contact DJI customer service directly. Specific warranty terms may vary by region and purchase location.

Note: Information regarding spare parts availability and software updates for this product is not explicitly provided in the product details. Please consult the manufacturer's official resources for the most current information.

© 2024 DJI. All rights reserved.
This manual is for informational purposes only. DJI reserves the right to change product specifications without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09HPFVW6G

More documents and user manuals: **https://manuals.plus/**