Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ariete 4175

Ariete 4175 Foldable 10-in-1 Steam Mop User Manual

Model: 4175 | Brand: Ariete

1. Product Overview

The Ariete 4175 Foldable 10-in-1 Steam Mop is a versatile cleaning appliance designed to sanitize and clean various surfaces using steam. Its innovative design allows for both upright mop functionality and handheld steam cleaning, making it suitable for a wide range of household tasks. The device operates at 1500W and has a 350cc water capacity, providing efficient and chemical-free cleaning.

Key Features:

- **10-in-1 Functionality:** Comes with a complete kit of interchangeable accessories for comprehensive cleaning and disinfection throughout your home.
- **Articulated Head:** Designed to reach difficult corners and tight spaces with ease.
- **Foldable Body:** Allows for convenient cleaning under furniture, beds, and sofas.
- **Removable Body:** Transforms into a manual handheld steam cleaner for targeted cleaning with appropriate accessories.
- **Immediate Steam:** Steam is ready in moments for deep disinfection.
- **99.9% Germ and Bacteria Elimination:** Cleans and disinfects using only steam, without chemical detergents, offering up to 18 minutes of continuous operation.

2. Safety Instructions

Please read all safety instructions carefully before using the appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is unplugged before filling with water, cleaning, or performing maintenance.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance out of reach of children and pets.
- Do not direct steam at people, animals, or electrical appliances.
- Use only distilled or demineralized water to prevent mineral buildup and prolong the life of the appliance.
- Do not use the appliance on unsealed hardwood floors, delicate fabrics, or surfaces that are sensitive to heat or moisture.
- Always allow the appliance to cool down completely before storing.

- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. Package Contents

Verify that all components are present and in good condition:

- Ariete 4175 Steam Mop main unit (foldable body with removable handheld unit)
- Articulated floor head
- Microfiber pads for floor head
- Water measuring cup
- Accessory kit (various nozzles, brushes, and cloths for different cleaning tasks)
- User Manual

4. Assembly and Setup

4.1 Assembling the Steam Mop

1. Insert the handle into the main body until it clicks into place.
2. Attach the articulated floor head to the bottom of the main unit.
3. Secure a microfiber pad onto the floor head.





Figure 1: Fully assembled Ariete 4175 Steam Mop.

4.2 Filling the Water Tank

1. Ensure the steam mop is unplugged from the power outlet.
2. Locate the water tank cap, usually on the main body. Unscrew or open it.
3. Using the provided measuring cup, fill the water tank with distilled or demineralized water up to the maximum fill line (350cc capacity). Do not overfill.
4. Securely close the water tank cap.

5. Operating Instructions

5.1 General Operation (Mop Mode)

1. Plug the steam mop into a grounded electrical outlet.
2. Turn on the appliance. The indicator light will illuminate, signaling that the water is heating.
3. Wait a few moments for the steam to be ready.
4. To release steam, press and hold the steam trigger or button on the handle.
5. Move the mop slowly and steadily over the surface to be cleaned. The articulated head allows for easy

maneuverability.

6. For stubborn stains, hold the mop over the area for a few seconds to allow the steam to penetrate.
7. When finished, release the steam trigger, turn off the appliance, and unplug it.



Figure 2: Steam mop in use on a carpeted surface.



Figure 3: The foldable body and articulated head allow cleaning under furniture.

5.2 Using as a Handheld Steam Cleaner

1. Unplug the appliance.
2. Press the release button to detach the central handheld unit from the main body.
3. Select the appropriate accessory from the kit for the cleaning task (e.g., small brush for grout, jet nozzle for crevices). Attach it securely to the handheld unit.
4. Plug in the handheld unit and wait for the steam to be ready.
5. Direct the steam towards the surface to be cleaned, maintaining a safe distance.
6. After use, unplug, allow to cool, and remove the accessory.



Figure 4: The central body detaches for handheld use.



Figure 5: Handheld unit cleaning upholstery.



Figure 6: Handheld unit cleaning a kitchen stovetop.

6. Maintenance and Care

6.1 Cleaning the Microfiber Pads

- Remove the microfiber pads from the floor head after each use.
- Machine wash the pads with mild detergent. Do not use bleach or fabric softeners.
- Air dry or tumble dry on low heat.

6.2 Descaling the Water Tank

To prevent mineral buildup, especially if using tap water (though distilled water is recommended), descale the water tank periodically:

1. Mix a solution of equal parts white vinegar and water.
2. Pour the solution into the water tank.
3. Allow it to sit for 30 minutes to an hour.
4. Empty the tank and rinse thoroughly with clean water several times.
5. Run a tank of clean water through the appliance to flush out any remaining vinegar.

6.3 Storage

- Ensure the appliance is unplugged and completely cool before storing.
- Empty any remaining water from the tank.
- Store the steam mop in a dry, cool place, away from direct sunlight and out of reach of children.

7. Troubleshooting

Problem	Possible Cause	Solution
No steam produced	Water tank empty Appliance not plugged in Heating element malfunction	Fill water tank Check power connection Contact customer support
Steam output is weak	Mineral buildup Low water level	Descale the appliance Refill water tank
Water leaking from unit	Water tank cap not secured Overfilled water tank Damaged seal	Ensure cap is tight Do not overfill Contact customer support
Mop leaves streaks	Microfiber pad dirty Too much water/steam	Replace or clean pad Move mop faster or reduce steam output if adjustable

8. Specifications

Feature	Specification
Brand	Ariete
Model Number	4175
Color	White/Blue
Product Dimensions (L x W x H)	30 x 21.5 x 111 cm
Item Weight	2.4 Kilograms
Power	1500W
Voltage	230 Volts
Material	Plastic
Water Tank Capacity	350 cc
Steam Ready Time	Immediate
Continuous Steam Autonomy	Up to 18 minutes
Special Features	Foldable Body, Handheld Cleaner, Articulated Head
Included Components	Interchangeable Accessory Kit

9. Warranty and Support

For warranty information, please refer to the warranty card included in your product packaging or visit the official Ariete website. For technical support, spare parts, or service inquiries, please contact Ariete customer service through their official channels. Keep your proof of purchase for warranty claims.

© 2025 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09J573YTX

More documents and user manuals: **https://manuals.plus/**