Tefal 5528b

Tefal Express Easy Steam Generator Iron User Manual

Model: 5528b

1. Introduction

Thank you for choosing the Tefal Express Easy Steam Generator Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read all instructions carefully before first use and keep them for future reference.



Image 1.1: The Tefal Express Easy Steam Generator Iron, showcasing its compact design with the iron resting securely on its base unit.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Always plug the iron into a grounded electrical outlet.
- Do not leave the iron unattended while it is connected to the mains supply.
- Do not immerse the iron or its base in water or other liquids.
- Keep the iron and its cord out of reach of children.
- Use caution when handling hot steam. Never direct steam at people or pets.
- Unplug the iron from the outlet before filling or emptying the water tank, and when not in use.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.

3. Product Components

Familiarize yourself with the different parts of your Tefal Express Easy Steam Generator Iron:

1. Iron Soleplate
2. Steam Trigger
3. Temperature Control Dial
4. Water Tank (Removable)
5. Base Unit
6. Power Cord Storage
7. Control Panel (On/Off button, Eco mode button)



Image 3.1: Side view of the steam generator iron, highlighting the removable water tank and the compact base unit.

4. Initial Setup

4.1 Unpacking

Carefully remove the appliance from its packaging. Retain the packaging for storage or in case of return. Remove any protective films or stickers from the soleplate and body of the iron.

4.2 Filling the Water Tank

The water tank has a capacity of 1.7 liters. For optimal performance and to prolong the life of your appliance, use tap water. If your water is very hard, consider mixing tap water with demineralized water (50% tap water / 50% demineralized water).

1. Ensure the iron is unplugged from the power outlet.
2. Remove the water tank from the base unit.
3. Fill the tank with water up to the 'MAX' level indicator.
4. Replace the water tank securely into the base unit.



Image 4.1: A user demonstrating the process of filling the removable water tank of the steam generator iron.

4.3 First Use Preparation

During the first few uses, a harmless odor and a small amount of smoke may be produced. This is normal and will disappear after a few uses. It is recommended to iron an old piece of fabric for the first few minutes to ensure any residue is removed from the soleplate.

5. Operating Instructions

5.1 Powering On and Heating Up

1. Place the base unit on a stable, heat-resistant surface.
2. Plug the power cord into a grounded electrical outlet.
3. Press the On/Off button on the control panel. The indicator light will illuminate.
4. Wait for the iron to heat up. The indicator light will stop flashing (or turn solid) when the iron is ready for use. This typically takes a few minutes.

5.2 Ironing Techniques

The Express Easy steam generator iron offers powerful steam for efficient ironing.

- **Horizontal Ironing:** Place the garment on an ironing board. Press the steam trigger under the handle to release steam as you glide the iron over the fabric.
- **Vertical Steaming:** For delicate fabrics, curtains, or garments on a hanger, hold the iron vertically a few centimeters away from the fabric. Press the steam trigger to release steam.



Image 5.1: A woman using the Tefal Express Easy iron for vertical steaming on a dress, demonstrating its versatility.

5.3 Eco Mode

Press the 'Eco' button on the control panel to activate Eco mode. This setting reduces steam output and energy consumption while still providing effective ironing results for most fabrics.

5.4 Powering Off

After use, press the On/Off button to turn off the appliance. Unplug the power cord from the electrical outlet and allow the iron to cool down completely before storing.

6. Cleaning and Maintenance

6.1 Cleaning the Soleplate

To maintain the glide of your soleplate, clean it regularly. Use a damp cloth or a non-abrasive cleaning stick specifically designed for iron soleplates. Do not use abrasive pads or metallic objects.

6.2 Descaling

Regular descaling is crucial for the longevity and performance of your steam generator. Refer to the specific descaling instructions provided in your product's full manual, as procedures can vary. Generally, this involves a rinse cycle to flush out mineral deposits.

6.3 Storage

Once the iron has cooled down completely, empty any remaining water from the tank. Secure the iron to its base unit (if applicable) and wrap the power cord around the designated storage area. Store the appliance in a dry, safe place.

7. Troubleshooting

If you encounter issues with your Tefal Express Easy Steam Generator Iron, consult the table below for common problems and solutions:

Problem	Possible Cause	Solution
No steam or sporadic steam output.	Water tank empty; iron not hot enough; steam trigger not pressed continuously; calcification.	Fill water tank; wait for iron to reach operating temperature; press and hold steam trigger; perform descaling procedure.
Water leaking from soleplate.	Temperature too low for steam; overfilling water tank.	Increase temperature setting; do not fill water tank beyond 'MAX' level.
Iron not heating up.	Not plugged in; power button not pressed; faulty outlet.	Check power connection; press On/Off button; try a different electrical outlet.
Soleplate does not glide smoothly.	Residue on soleplate.	Clean the soleplate as per maintenance instructions.

8. Technical Specifications

Feature	Specification
Brand	Tefal
Model Number	5528b
Power	2200 Watts
Voltage	240 Volts
Frequency	50 Hz
Item Weight	3.84 Kilograms
Base Material	Stainless Steel
Water Tank Capacity	1.7 Liters (approx.)

9. Warranty Information

This product comes with a 2-year warranty from the date of purchase. Please retain your proof of purchase for any

warranty claims. The warranty covers manufacturing defects and faults under normal household use. It does not cover damage caused by misuse, neglect, or failure to follow instructions.

10. Customer Support

For further assistance, technical support, or spare parts, please contact Tefal customer service or the retailer from whom you purchased the product. Contact details can typically be found on the official Tefal website or on your product packaging.

© 2025 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I remove the water tank from the Tefal Express Easy Steam Generator Iron (Model CMMF 1830008042)?

For the Tefal Express Easy Steam Generator Iron, the water tank is designed to be removable for easy filling. While the manual (Model 5528b/CMMF 1830008042) indicates it is removable, it does not always explicitly...

Read full answer